

**GENERAL  
INFORMATION**

**MOTORCYCLE IDENTIFICATION**

**FRAME SERIAL NUMBER**

The frame serial number ① is stamped into the right side of the steering head pipe.

**Frame Serial Number:**

XJ600RL ..... 49F-000101

**ENGINE SERIAL NUMBER**

The engine serial number ① is stamped into the elevated part of the left rear section of the engine.

**NOTE:**

The first three digits of these numbers are for model identifications; the remaining digits are the unit production number.

**Stating Serial Number:**

XJ600RL ..... 49F-000101

**NOTE:**

Designs and specifications are subject to change without notice.



## IMPORTANT INFORMATION


### ALL REPLACEMENT PARTS

1. Use only genuine Yamaha parts for all replacements. Use oil and/or grease recommended by Yamaha for assembly and adjustment. Other brands may be similar in function and appearance, but inferior in quality.

1


### GASKETS, OIL SEALS, AND O-RINGS

1. All gaskets, seals and O-rings should be replaced when an engine is overhauled. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. Properly oil all mating parts and bearings during reassembly. Apply grease to the oil seal lips.



### LOCK WASHERS/PLATES AND COTTER PINS


1. All lock washers/Plates ① and cotter pins must be replaced when they are removed. Lock tab(s) should be bent along the bolt or nut flat(s) after the bolt or nut has been properly tightened.



### BEARINGS AND OIL SEALS

1. Install the bearing(s) and oil seal(s) with their manufacturer's marks or numbers facing outward. (In other words, the stamped letters must be on the side exposed to view.) When installing oil seal(s), apply a light coating of light-weight lithium base grease to the seal lip(s). Oil the bearings liberally when installing.

① Oil seal




### CAUTION:

Do not use compressed air to spin the bearings dry. This causes damage to the bearing surfaces.

① Bearing

# 1




## SPECIAL TOOLS

The proper special tools are necessary for complete and accurate tune-up and assembly. Using the correct special tool will help prevent damage caused by the use of improper tools or improvised techniques.

### FOR TUNE UP


1. Inductive Tachometer  
P/N 90890-03082

This tool is needed for detecting engine rpm.




2. Inductive Timing Light  
P/N 90890-03109

This tool is necessary for adjusting timing.




3. Compression Gauge  
P/N 90890-03081

This gauge is used to measure the engine compression.




4. Fuel Level Gauge  
P/N 90890-01312

This gauge is used to measure the fuel level in the float chamber.



5. Fuel Level Gauge Adapter  
P/N 90890-01329




6. Vacuum Gauge  
P/N 90890-03094

This tool is needed when measuring the carburetor fuel level together with fuel level gauge.


This gauge is needed for carburetor synchronization.

#### FOR ENGINE SERVICE




1. Universal Clutch Holder  
P/N 90890-04086

This tool is used to hold the clutch when removing or installing the clutch boss locknut.



2. Tappet Adjusting Tool  
P/N 90890-01245

This tool is necessary to replace valve adjusting pads.




3. Valve Spring Compressor  
P/N 90890-04019

This tool is needed to remove and install the valve assemblies.






**1**




4. Valve Guide Remover  
P/N 90890-04064

This tool is used to remove the valve guides.




5. Valve Guide Reamer  
P/N 90890-04066

This tool is used to rebores the new valve guide.




6. Valve Guide Installer  
P/N 90890-04065

This tool is needed to install the valve guides properly together with valve guide remover.



7. Valve Seat Cutter Set  
P/N YM-91043


This tool is needed to resurface the valve seat.



8. Rotor Puller  
P/N 90890-01080


This tool is needed to remove the A.C. Generator rotor.

## SPECIAL TOOLS




9. Piston Ring Compressor  
P/N 90890-04047

This tool is used when installing the piston into the cylinder.




10. Piston Base  
P/N 90890-01067

Use 4 of these to hold the pistons during cylinder installation.




11. Piston Pin Puller  
P/N YU-01304

This tool is used to remove the piston pin.



12. Rotor Holding Tool  
P/N 90890-04067

This tool is used to hold the A.C. Generator rotor during removal and installation.




13. Plastigage® Set "Green"  
P/N YU-33210

This gauge is needed to measure the clearance for the connecting rod bearing.

1




**1**



**FOR CHASSIS SERVICE**


1. T-Handle  
P/N 90890-01326 ①  
Front Fork Cylinder Holder  
P/N 90890-01300 ②

This tool is used to loosen and tighten the front fork cylinder holding bolt.




2. Front Fork Cap Socket (17 mm)  
P/N 90890-01104

This tool is needed when loosening and tightening the front fork cap bolt.



3. Front Fork Seal Driver (Weight)  
P/N 90890-01367 ①  
Adapter  
P/N 90890-01370 ②

These tools are used when installing the fork seal.




4. Ring Nut Wrench  
P/N 90890-01268

This tool is used to loosen and tighten the steering ring nut.

**FOR ELECTRICAL COMPONENTS**

1. Electro Tester  
P/N 90890-03021

This instrument is necessary for checking the ignition system components.

**1**

2. Pocket Tester  
P/N 90890-03021

This instrument is invaluable for checking the electrical system.



## PERIODIC INSPECTIONS AND ADJUSTMENTS

## INTRODUCTION

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The

need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

## PERIODIC MAINTENANCE/LUBRICATION INTERVALS

Unit: km (mi)

| ITEM                         | REMARKS  | BREAK-IN<br>1,000<br>(600) | EVERY                           |                                   |
|------------------------------|--|----------------------------|---------------------------------|-----------------------------------|
|                              |  |                            | 6,000<br>(4,000) or<br>6 months | 12,000<br>(8,000) or<br>12 months |
| Cam chain *                  | Adjust chain tension   | ○                          | ○                               | ○                                 |
| Valve clearance*             | Check/Adjust valve clearance.  |                            |                                 | ○                                 |
| Spark plug(s)                | Check/Clean or replace.  | ○                          | ○                               | Replace                           |
| Air filter                   | Clean. Replace if necessary.   |                            | ○                               | ○                                 |
| Carburetor*                  | Check/Adjust/idle speed, synchronization, starter operation.                                   | ○                          | ○                               | ○                                 |
| Fuel line*                   | Check fuel hose and vacuum pipe for cracks or damage.  |                            | ○                               | ○                                 |
| Engine oil                   | Replace (Warm engine before draining).   | ○                          | ○                               | ○                                 |
| Engine oil filter            | Replace.   | ○                          |                                 | ○                                 |
| Drive chain                  | Check tension/alignment/clean/lube   | Every 500 (300)            |                                 |                                   |
| Brake*                       | Check operation/fluid leakage/See NOTE. Adjust if necessary.                                   |                            | ○                               | ○                                 |
| Clutch*                      | Check operation/Adjust if necessary.   |                            | ○                               | ○                                 |
| Rear arm pivot*              | Check rear arm assembly for looseness. Moderately repack every 24,000 (16,000) or 24 months.** |                            |                                 | Check                             |
| Rear suspension* link pivots | Check operation. Apply grease lightly every 24,000 (16,000) or 24 months ***                   |                            |                                 | Check                             |
| Wheels*                      | Check balance/damage/runout.   |                            | ○                               | ○                                 |
| Wheel bearings*              | Check bearings assembly for looseness/damage. Replace if damaged.                              |                            | ○                               | ○                                 |

2

# PERIODIC MAINTENANCE/LUBRICATION INTER VALS



Unit: km (mi)

| ITEM                 | REMARKS  | BREAK-IN<br>1,000<br>(600) | EVERY                           |                                   |
|----------------------|--|----------------------------|---------------------------------|-----------------------------------|
|                      |  |                            | 6,000<br>(4,000) or<br>6 months | 12,000<br>(8,000) or<br>12 months |
| Steering bearing*    | Check bearings assembly for looseness.<br>Moderately repack every 24,000 (16,000)<br>or 24 months.** |                            |                                 | Check                             |
| Front forks*         | Check operation/oil leakage  |                            | ○                               | ○                                 |
| Rear shock absorber* | Check operation/oil leakage  |                            | ○                               | ○                                 |
| Fittings/Fasteners*  | Check all chassis fittings and fasteners.  | ○                          | ○                               | ○                                 |
| Center and sidestand | Check operation.   | ○                          | ○                               | ○                                 |
| Battery*             | Check specific gravity. Check breather<br>pipe for proper operation.                                 |                            | ○                               | ○                                 |
| A.C. Generator*      | Replace generator brushes.   |                            |                                 | ○                                 |

\*: It is recommended that these items be serviced by a Yamaha dealer.

\*\*: Medium weight wheel bearing grease.

\*\*\*: Lithium soap base grease.

## NOTE:



### Brake fluid replacement:

- When disassembling the master cylinder or caliper cylinder, replace the brake fluid. Normally check the brake fluid level and add the fluid as required.
- On the inner parts of the master cylinder and caliper cylinder, replace the oil seals every two years.
- Replace the brake hoses every four year if cracked or damaged, replace immediately.


2


**ENGINE**
**VALVE CLEARANCE ADJUSTMENT**

- |                   |                 |
|-------------------|-----------------|
| 1. Washer         | 9. Spring seat  |
| 2. Rubber washer  | 10. Oil seal    |
| 3. Pad            | 11. Valve       |
| 4. Valve lifter   | 12. Gasket      |
| 5. Valve retainer | 13. Spark plug  |
| 6. Spring seat    | 14. Valve guide |
| 7. Inner spring   | 15. Circlip     |
| 8. Outer spring   | 16. Stud bolt   |


**2**


|                           |                                      |
|---------------------------|--------------------------------------|
| A VALVE CLEARANCE (COLD): |                                      |
| B Intake:                 | 0.11 ~ 0.15 mm<br>(0.004 ~ 0.006 in) |
| C Exhaust:                | 0.16 ~ 0.20 mm<br>(0.006 ~ 0.008 in) |



|                                 |  |
|---------------------------------|--|
| D TYPE/GAP:                     |  |
| DR8ES-L                         |  |
| 0.6 ~ 0.7 mm (0.024 ~ 0.028 in) |  |

|                             |  |
|-----------------------------|--|
| E CYLINDER HEAD WARP LIMIT: |  |
| 0.03 mm (0.0012 in)         |  |



## VALVE CLEARANCE ADJUSTMENT

INSP  
ADJ



### Removal

1. Remove:
  - Headlight unit assembly

2. Remove:
  - Cowling

3. Remove:
  - Side cover
  - Seat
  - Fuel tank
  - Relay assembly
  - Spark plug

4. Remove:
  - Cylinder head cover

5. Remove:
  - Left crankcase cover



2



ENGINE

## Inspection and Adjustment



### NOTE:

- Valve clearance must be measured and adjusted when the engine is cool to the touch.
- Measure and adjust valve clearance when piston is at TDC on compression stroke.

### 1. Measure:

- Valve clearance

2



|   |       | 0° | 180° | 360° | 540° | 720° |
|---|-------|----|------|------|------|------|
| A |       |    |      |      |      |      |
| B | No. 1 | ⑥  |      |      |      |      |
|   | No. 2 |    | ⑥    |      |      |      |
|   | No. 3 |    |      |      |      | ⑥    |
|   | No. 4 |    |      | ⑥    |      |      |

### Valve Clearance Measurement Steps:

- Turn the crankshaft counterclockwise.
- Align the "T" mark ① on the timing plate with the upper pickup coil mark ② when #1 piston is at TDC on compression stroke.
- Lower pickup coil mark.
- Measure the valve clearance using feeler gauge ④.
- Record the measured amount if the clearance is incorrect.



### Intake Valve (cold):

0.11 ~ 0.15 mm  
(0.004 ~ 0.006 in)

### Exhaust Valve (cold):

0.16 ~ 0.20 mm  
(0.006 ~ 0.008 in)

- Measure valve clearance, in sequence, for No. 2, 4, and No. 3 cylinders.
- Out of specification → Adjust clearance.

### Firing Sequence:

1 - 2 - 4 - 3

### ⑤ Front

### No. 2 and 3 cylinders

- Align "T" mark with the lower pickup coil mark.

A Crankshaft counterclockwise turning angle.

B Cylinder

⑥ Combustion

## VALVE CLEARANCE ADJUSTMENT

INSP  
ADJ



No. 4 cylinder

- Align "T" mark with upper pickup coil mark

2. Adjust:

- Valve clearance

### Valve Clearance Adjustment Steps:

- Position the valve lifter slots (intake and exhaust side) facing each other.
- Depress the valve lifter and install the Tappet Adjusting Tool (90890-01245) onto the cylinder head.

- Turn the camshaft until the lobe of the Tappet Adjusting Tool ① depresses the valve lifter.
- Remove the pads ② from the lifter. Use a small screwdriver and a magnetic rod for removal. Note pad numbers.



### CAUTION:

Turn the camshaft as follows:


(view from left side of the motorcycle)

Intake: Carefully rotate **CLOCKWISE**.

Exhaust: Carefully rotate **COUNTER-CLOCKWISE**.



2



- Select the proper valve adjusting pad from the chart below:

| Pad range                      | Pad Availability:<br>25 increments               |
|--------------------------------|--|
| No. 200 ~ 200 mm<br>(0.079 in) | Pads stepped in 0.05 mm<br>(0.002 in) increments |
| No. 320 320 mm<br>(0.130 in)   |  |

**NOTE:**

The thickness of each pads is marked on the pad face that contacts the valve lifter (not the cam)

- Round off the hundredths digit of the original pad number to the nearest 0.05 mm increment.

| Hundredths digit | Rounded valve     |
|------------------|-------------------|
| 0 or 2           | 0                 |
| 5                | (NOT ROUNDED OFF) |
| 8                | 10                |

**EXAMPLE:**

Original pad number = 258 (2.58 mm)

Rounded off digit = 260

**NOTE:**

Pads can only be selected in 0.05 mm (0.002 in) increments.

- Locate the "Installed Pad Number" on the chart, and then find the measured valve clearance. The point where these coordinates intersect is the new pad number.

**NOTE:**

Use the new pad number as a guide only as the number must be verified.

**Pad Number Verification Steps:**

- Install the new pad with the number down.
- Remove the adjusting tool.
- Recheck the valve clearance.
- If the clearance is incorrect, repeat all of the clearance adjustment steps until the proper clearance is obtained.

**3. Assembly**

Reverse removal steps.

**Note the Following Assembly Step:**

- Install head cover



**Head Cover Bolt:**  
10 Nm (1.0 m·kg, 7.2 ft·lb)

# VALVE CLEARANCE ADJUSTMENT

INSP  
ADJ



## INTAKE

| [B]<br>MEASURED<br>CLEARANCE | [A] INSTALLED PAD NUMBER |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
|------------------------------|--------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|--|--|--|--|--|--|--|--|
|                              | 200                      | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |  |  |  |  |  |  |  |  |
| 0.00 ~ 0.05                  |                          |     |     | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |  |  |  |  |  |  |  |  |
| 0.06 ~ 0.10                  |                          | 200 | 205 | 210 |     | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |  |  |  |  |  |  |  |  |
| 0.11 ~ 0.15                  |                          |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.16 ~ 0.20                  | 205                      | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.21 ~ 0.25                  | 210                      | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.26 ~ 0.30                  | 215                      | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.31 ~ 0.35                  | 220                      | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.36 ~ 0.40                  | 225                      | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.41 ~ 0.45                  | 230                      | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.46 ~ 0.50                  | 235                      | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.51 ~ 0.55                  | 240                      | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.56 ~ 0.60                  | 245                      | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.61 ~ 0.65                  | 250                      | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.66 ~ 0.70                  | 255                      | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.71 ~ 0.75                  | 260                      | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.76 ~ 0.80                  | 265                      | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.81 ~ 0.85                  | 270                      | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.86 ~ 0.90                  | 275                      | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.91 ~ 0.95                  | 280                      | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 0.96 ~ 1.00                  | 285                      | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 1.10 ~ 1.05                  | 290                      | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 1.06 ~ 1.10                  | 295                      | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 1.11 ~ 1.15                  | 300                      | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 1.16 ~ 1.20                  | 305                      | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 1.21 ~ 1.25                  | 310                      | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 1.26 ~ 1.30                  | 315                      | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |
| 1.31 ~ 1.35                  | 320                      |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |  |  |  |  |

VALVE CLEARANCE (cold):  
0.11 ~ 0.15 mm (0.004 ~ 0.006 in)  
Example: Installed is 250  
Measured clearance is 0.32 mm (0.013 in)  
Replace 250 pad with 270 pad  
\*Pad number : (example)  
Pad No. 250 = 2.50 mm (0.098 in)  
Pad No. 225 = 2.55 mm (0.100 in)  
Always install pad with number down.

VALVE CLEARANCE (cold):

0.11 ~ 0.15 mm (0.004 ~ 0.006 in)

Example: Installed is 250

Measured clearance is 0.32 mm  
(0.013 in)

Replace 250 pad with 270 pad

\*Pad number : (example)

Pad No. 250 = 2.50 mm (0.098 in)

Pad No. 225 = 2.55 mm (0.100 in)

Always install pad with number down.

## EXHAUST

| B<br>MEASURED<br>CLEARANCE | A<br>INSTALLED PAD NUMBER |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
|----------------------------|---------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|--|--|--|--|
|                            | 200                       | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |  |  |  |  |
| 0.00 ~ 0.05                |                           |     |     | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |  |  |  |  |
| 0.06 ~ 0.10                |                           |     | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |  |  |  |  |
| 0.11 ~ 0.15                |                           | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |  |  |  |  |
| 0.16 ~ 0.20                |                           |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 0.21 ~ 0.25                | 205                       | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |  |  |  |  |
| 0.26 ~ 0.30                | 210                       | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |  |  |  |  |
| 0.31 ~ 0.35                | 215                       | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |  |  |  |  |
| 0.36 ~ 0.40                | 220                       | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |  |  |  |  |
| 0.41 ~ 0.45                | 225                       | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |  |  |  |  |
| 0.46 ~ 0.50                | 230                       | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 0.51 ~ 0.55                | 235                       | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 0.56 ~ 0.60                | 240                       | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 0.61 ~ 0.65                | 245                       | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 0.66 ~ 0.70                | 250                       | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 0.71 ~ 0.75                | 255                       | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 0.76 ~ 0.80                | 260                       | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 0.81 ~ 0.85                | 265                       | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 0.86 ~ 0.90                | 270                       | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 0.91 ~ 0.95                | 275                       | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 0.96 ~ 1.00                | 280                       | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 1.10 ~ 1.05                | 285                       | 290 | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 1.06 ~ 1.10                | 290                       | 295 | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 1.11 ~ 1.15                | 295                       | 300 | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 1.16 ~ 1.20                | 300                       | 305 | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 1.21 ~ 1.25                | 305                       | 310 | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 1.26 ~ 1.30                | 310                       | 315 | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 1.31 ~ 1.35                | 315                       | 320 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |
| 1.36 ~ 1.40                | 320                       |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |  |  |

VALVE CLEARANCE (cold):  
0.16 ~ 0.20 mm (0.006 ~ 0.008 in)

Example: Installed is 250  
Measured clearance is 0.32 mm (0.013 in)  
Replace 250 pad with 265 pad

\*Pad number : (example)  
Pad No. 250 = 2.50 mm (0.098 in)  
Pad No. 225 = 2.55 mm (0.100 in)



Always install pad with number down.



**CAM CHAIN ADJUSTMENT**

1. Remove:
  - Left crankcase cover
2. Turn:
  - Crankshaft  
(Counterclockwise)
3. Align:
  - Timing plate "C" mark ①  
(with the upper pickup coil mark ②)

**2**



4. Loosen:
  - Tensioner locknut ①
  - Tensioner stopper bolt ②


5. Tighten:
  - Tensioner stopper bolt
  - Tensioner locknut



**Stopper Bolt:**  
6 Nm (0.6 m·kg, 4.3 ft·lb)  
**Locknut:**  
9 Nm (0.9 m·kg, 6.5 ft·lb)

6. Install:
  - Left crankcase cover

## SPARK PLUG/CRANKCASE VENTILATION SYSTEM



### SPARK PLUG

1. Inspect:
  - Electrode ①  
Wear/Damage → Replace.
  - Insulator color ②
2. Measure:
  - Plug gap ③  
Out of specification → Regap.  
Use a wire gauge.



**Spark Plug Gap:**  
0.6 ~ 0.7 mm (0.024 ~ 0.028 in)

2

Clean the plug with a spark plug cleaner if necessary.

**Standard Spark Plug:**  
**DR8ES-L/NGK**

Before installing a spark plug, clean the gasket surface and plug surface.

3. Tighten:
  - Spark plug(s)



**17.5 Nm (1.75 m·kg, 12.5 ft·lb)**

### NOTE:

Finger-tighten the spark plug(s) before torquing to specification.

### CRANKCASE VENTILATION SYSTEM

1. Inspect:
  - Crankcase ventilation hose  
Cracks/Damage → Replace.  
(Refer to chapter 4, "CARBURETION".)

### FUEL LINE

- Inspect:
  - Fuel hoses
  - Vacuum lines
  - Cracks/Damage → Replace.

### INTAKE MANIFOLD

- Tighten:
  - Carburetor clamps
  - Carburetor joint bolts
  - Carburetor joint nuts
- Inspect:
  - Carburetor joint
  - Gaskets
  - Cracks/Damage → Replace.

### EXHAUST SYSTEM

- Inspect:
  - Exhaust pipe
  - Muffler clamp gasket(s)
  - Damage → Replace.
- Tighten:
  - Exhaust pipe bolts
  - Muffler bolts



Exhaust Pipe Joint:  
20 Nm (2.0 m·kg, 14 ft·lb)  
Exhaust Pipe Flange:  
10 Nm (1.0 m·kg, 7.2 ft·lb)  
Muffler:  
25 Nm (2.5 m·kg, 18 ft·lb)

### CARBURETOR SYNCHRONIZATION

Carburetors must be adjusted to open and close simultaneously.

#### NOTE:

Valve clearance must be set properly before synchronizing the carburetors.

- Remove:
  - Vacuum plugs ①







2. Remove:
  - Side cover
  - Seat
  - Fuel tank mounting bolt
3. Install:
  - Vacuum Gauge (90890-03094)
4. Start the engine and let it warm up.
5. Adjust:
  - Idle speed
 Turn throttle stop screw to adjust.



1,200 ± 50 r/min

2



## Carburetor Adjustment Steps:

- Lift up the rear of fuel tank
- Synchronize carburetor No. 1 to carburetor No. 2 by turning synchronizing screw ① until both gauges read the same.
- Rev the engine for a fraction of a second, two or three times, and check the synchronization again.

## Vacuum Pressure at Idle Speed:

23.33 ± 0.6 kPa

(175 ± 5 mm Hg, 6.89 ± 0.2 in Hg)

## Vacuum Synchronous Difference:

1.33 kPa (10 mm Hg, 0.4 in Hg)

- Repeat the above steps to synchronize carburetor No. 4 to carburetor No. 3 by turning synchronizing screw ③ until both gauges read the same.
- Repeat the same steps to synchronize No. 2 carburetor to No. 3 carburetor by turning synchronizing screw ② until both gauges read the same.

7. Adjust
  - Idle speed
8. Install
  - Fuel tank mounting bolt
  - Seat
  - Side cover
  - Vacuum plugs






## IDLE SPEED

- Adjust:
  - Idle speed  
Warm up engine and turn throttle stop screw ① to adjust.



1,200 ± 50 r/min

2



## ENGINE OIL



At 5°C (40°F) or Higher:  
SAE 20W40 Type SE Motor Oil ①  
At 15°C (60°F) or Lower:  
SAE 10W30 Type SE Motor Oil ②

## Oil Level Measurement

- Check
  - Oil level  
Oil level low → Add sufficient oil.


### Oil Level Visual Inspection Steps:

- Place the motorcycle on its centerstand and warm up the engine for several minutes.

### NOTE:

Position motorcycle straight up when checking oil level, a slight tilt to the side can produce false readings.

- Stop the engine and visually check the oil level through the level window ①.



- ② Maximum
- ③ Minimum

## Oil Change (Without filter)

- Remove:
  - Lower cowl
- Warm up the engine for several minutes, then place a receptacle under the engine.






3. Remove:
  - Oil filler cap
4. Remove:
  - Drain plug ①
 Drain the engine oil.
5. Tighten:
  - Drain plug ①



43 Nm (4.3 m·kg, 31 ft·lb)

2



6. Fill:
  - Crankcase



2.3 L (2.0 Imp qt, 2.4 US qt)

#### CAUTION:

Do not allow foreign material to enter the crankcase.

7. Install:
  - Filler cap
  - Lower cowl


#### Oil and Filter Change (Refer to "Oil Change")

1. Warm up the engine and place a receptacle underneath.
2. Remove:
  - Lower cowl
  - Oil filler cap
  - Drain plug
 Drain the engine oil.
3. Remove:
  - Oil filter bolt ①
  - Filter cover ②
  - Oil filter ③
4. Install:
  - Drain plug




Drain Plug:  
43 Nm (4.3 m·kg, 31 ft·lb)

- Oil filter (New) ③
- Oil filter cover ②





2

**NOTE:**

Be sure the O-ring ① is positioned properly.

## 5. Tighten:

- Oil filter bolt



15 Nm (1.5 m·kg, 11 ft·lb)

## 6. Fill:

- Crankcase



2.6 L (2.3 Imp qt, 2.7 US qt)


## 7. Install:

- Oil filler cap
- Lower cowl

8. Warm up engine and check for oil leaks.  
Stop engine instantly if leaking occurs.  
Leaks → Check cause.

## 9. Check:

- Oil level  
Level low → Add sufficient oil.

**CAUTION:**



After replacing the engine oil, be sure to check the oil flow in the following procedures:

- Slightly loosen the oil gallery bolt ① in the cylinder head.
- Start the engine and keep it idling until oil begins to seep from the oil gallery bolt. If no oil comes out after one minute, turn the engine off so it will not seize.
- Restart the engine after solving the problem(s), and recheck the oil pressure.
- After checking, tighten the oil gallery bolt to specification.



Oil Gallery Bolt:  
7 Nm (0.7 m·kg, 5.1 ft·lb)

## CLUTCH ADJUSTMENT/IGNITION TIMING CHECK



### CLUTCH ADJUSTMENT

1. Loosen:
  - Adjuster locknut ①
2. Adjust:
  - Clutch lever free play (a)  
(by turning adjuster ② in or out)



Free play:  
10 ~ 15 mm (0.4 ~ 0.6 in)

3. If free play can not be adjusted, adjust by clutch cable length adjuster.
4. Loosen:
  - Adjuster locknut ①
5. Adjust:
  - Clutch lever free play  
(by turning clutch cable length adjuster ②.)

2

### IGNITION TIMING CHECK

1. Check:
  - Ignition timing

#### Ignition Timing Check Steps:

- Remove the left crankcase cover.
- Connect the Timing Light (90890-03109) to No. 1 or No. 4 cylinder spark plug cord.
- Warm up the engine and let it idle at the standard idle speed.
- Visually check the upper pickup coil mark 1 is within the firing range 2 indicated on timing plate.

Incorrect firing range → Check flywheel and/or pickup assembly (tightness damage)  
Refer to Chapter 6, "ELECTRICAL" for further information.



## COMPRESSION PRESSURE MEASUREMENT

## NOTE:

Insufficient compression pressure will result in performance loss.

1. Measure:
  - Valve clearance  
Out of specification → Adjust.  
Warm up the engine.
2. Remove:
  - Spark plugs

## Compression Pressure Measurement Steps:

- Install the Compression Gauge (90890-03081) ① using an adapter.
- Crank over the engine with the electric starter (be sure the battery is fully charged) with the throttle wide open until the compression reading on the gauge stabilizes.
- Check readings with specified levels (See chart).

## Compression Pressure (at sea level):

## Standard:

1,079 kPa (11 kg/cm<sup>2</sup>, 156 psi)

## Minimum:

980 kPa (10 kg/cm<sup>2</sup>, 142 psi)

## Maximum:

1,128 kPa (11.5 kg/cm<sup>2</sup>, 164 psi)

## WARNING:

When cranking the engine, ground spark plug lead to prevent sparking.

- Repeat the previous steps for the other cylinders.
- If pressure falls below the minimum level:
  1. Squirt a few drops of oil into the affected cylinder.
  2. Measure the compression again.

Compression Pressure  
(with oil introduced into cylinder)

| Reading                 | Diagnosis   |
|-------------------------|---|
| Higher than without oil | Worn or damaged pistons   |
| Same as without oil     | Defective ring(s), valves, cylinder head gasket or piston is possible.      |
| Above maximum level     | Inspect cylinder head, valve surfaces, or piston crown for carbon deposits. |


## NOTE:


The difference between the highest and lowest cylinder compression readings must not vary more than the specified value.

## Difference Between Each Cylinder:

Less than 98 kPa (1 kg/cm<sup>2</sup>, 14 psi)

2



**CHASSIS****FUEL COCK**

- ① O-ring
- ② Filter screen
- ③ Gasket
- ④ Cock plate



**Removal and Inspection**

1. Inspect:
  - Fuel cock operation
  - Leakage/Contamination → Disassemble
2. Remove:
  - Seat
  - Fuel tank
  - Position tank so that fuel will not spill when cock is removed.
  - Fuel cock
3. Inspect:
  - Filter screen
  - Contamination → Replace screen.
4. Remove:
  - Screws
  - Cock plate
  - O-ring
  - Gasket
5. Inspect:
  - Fuel cock components (all)
  - Damage → Replace.
  - Diaphragm
  - Damage → Replace cock assembly.
6. Inspect:
  - Gasket surfaces
  - Scratches/Corrosion → Replace cock assembly.

**2****NOTE:**

Drain and flush fuel tank if abrasive damage to any components is evident.

7. Assemble:
  - Fuel cock
8. Install:
  - Fuel cock
  - (On to fuel tank)



## AIR FILTER

1. Remove:
  - Left side cover
  - Air filter case cover
  - Air filter element ①

### CAUTION:

The engine should never be run without the air/filter element installed; excessive piston and/or cylinder wear may result.



2. Blow out dust in the element from the inner surface. Use compressed air.
3. Inspect:
  - Element
  - Damage → Replace.
4. Install:
  - Element
  - Air filter case cover
  - Left side cover

## FRONT AND REAR BRAKE

### Brake Fluid Inspection

- ① Check:
  - Brake fluid level

Fluid at lower level → Replenish.
- ① Front brake fluid lower level




Brake Fluid: DOT #3

### WARNING:

- Use only designated quality brake fluid to avoid poor brake performance.
- Refill with same type and brand of brake fluid; mixing fluids could result in poor brake performance.
- Be sure that water or other contaminants do not enter master cylinder when refilling.
- Clean up spilled fluid immediately to avoid erosion of painted surfaces or plastic parts.


- ① Rear brake fluid lower level






## Brake Pad Inspection

1. Depress the brake lever.
  2. Inspect:
    - Wear indicator  
Indicator almost contacts disc → Replace pads.  
(Refer to Chapter 5 "CHASSIS")
- ① Front brake pad wear indicator



- ① Rear brake pad wear indicator



## Front Brake Lever Free Play Adjustment

1. Loosen:
  - Adjuster locknut ①
2. Adjust:
  - Free play  
Turn the adjuster ② until the free play ③ is within the specified limits.




5 ~ 8 mm (0.2 ~ 0.3 in)

## CAUTION:

Proper lever free play is essential to avoid excessive brake drag.

3. Tighten:
  - Adjuster locknut





## Rear Brake Pedal Height Adjustment

1. Loosen:
  - Adjuster locknuts ①
2. Adjust:
  - Brake pedal height.
 Turn the adjuster ② until the brake pedal position is at the specified height.




**Brake Pedal Height ③ :**  
 30 mm (1.2 in)  
 Below the Top of the Footrest

### **WARNING:**

After adjusting the brake pedal height, visually check the adjuster end through the hole of the joint holder. The adjuster end must appear within this hole.

**2**



## Rear Brake Light Switch Adjustment

1. Remove:
  - Right side cover
2. Hold the switch body ① with your hand so it does not rotate and turn the adjusting nut ②




## DRIVE CHAIN

### Drive Chain Tension Check

#### NOTE:

Before checking and/or adjusting, rotate the rear wheel through several revolutions and check the tension several times to find the tightest point. Check and/or adjust chain tension with rear wheel in this "tight chain" position.




1. Lift the rear wheel by applying centerstand.
2. Measure:
  - Chain deflection ①  
(at the position shown in the photograph.)  
Out of specification → Adjust chain

2



**Chain Deflection:**  
20 ~ 30 mm (0.8 ~ 1.2 in)



### Drive Chain Tension Adjustment

1. Remove:
  - Cotter pin ①
2. Loosen:
  - Axle nut ②
  - Chain puller locknut ③
- ④ Adjusting bolt
- ⑤ Mark for alignment
3. Adjust:
  - Chain tension  
(by turning adjusting bolt in or out)

| Adjusting bolt | Chain tension |
|----------------|---------------|
| Turn in        | Tighten       |
| Turn out       | Loosen        |


## NOTE:

There are marks on each side of rear arm and on each chain puller; use them to check for proper alignment.

## 4. Tighten:

- Locknut
- Axle nut

# 2



**Axle Nut:**  
105 Nm (10.5 m·kg, 75 ft-lb)

## 5. Install:

- Cotter pin ① (new)

## NOTE:

Do not loosen the axle nut after torque tightening.

If the axle nut groove is not aligned with the wheel shaft cotter pin hole, align groove to hole by tightening up on the axle nut.

# CABLE INSPECTION AND LUBRICATION

## Cable Inspection and Lubrication Steps:

- Remove the two grip end that secure throttle to handlebar.
- Hold cable end high and apply several drops of lubricant to cable.
- Coat metal surface of disassembled throttle twist grip with suitable all-purpose grease to minimize friction.
- Check for damage to cable insulation. Replace any corroded or obstructed cables.
- Lubricate any cables that do not operate smoothly.



SAE 10W30 Motor Oil

**BRAKE AND CHANGE PEDALS  
BRAKE AND CLUTCH LEVERS**



**BRAKE AND CHANGE PEDALS/  
BRAKE AND CLUTCH LEVERS**

Lubricate pivoting parts of each lever and pedal.



SAE 10W30 Motor Oil

**CENTERSTAND AND SIDESTAND**

Lubricate centerstand and sidestand at their pivot points.




SEA 10W30 Motor Oil

**2**



**FRONT FORK OIL CHANGE**

- |                      |                              |
|----------------------|------------------------------|
| 1. Rubber cap        | 10. Retaining clip           |
| 2. Cap bolt          | 11. Oil seal                 |
| 3. O-ring            | 12. Washer                   |
| 4. Fork spring       | 13. Bushing                  |
| 5. Damper rod spring | 14. Outer fork tube          |
| 6. Damper rod        | 15. Drain bolt               |
| 7. Inner fork tube   | 16. Damper rod securing bolt |
| 8. Taper spindle     | 17. Front fork brace         |
| 9. Dust cover        |                              |

**2**


## FRONT FORK OIL CHANGE

INSP  
ADJ



### WARNING:

Securely support the motorcycle so there is no danger of it falling over.

1. Remove:
  - Handlebar installing bolt (1)
  - Handlebar
2. Loosen:
  - Upper front fork pinch bolt (1)
3. Remove:
  - Fork cap bolts (2)Use Front Fork Cap Socket (90890-01104)
4. Remove:
  - Drain screws (1)Drain the fork oil.

2

### WARNING:

Do not allow any oil to contact the disc brake components. If oil is discovered, be sure to remove it, otherwise diminished braking capacity and damage to the rubber components of the brake assembly will occur.

5. Inspect:
  - Cap bolt O-ring (1)
  - Drain screw gasketsWear/Damage → Replace.
6. Install:
  - Drain screws
7. Fill:
  - Front forks



### Each Fork:

269 cm<sup>3</sup> (9.46 Imp oz, 9.1 US oz)

SEA 10W30 Type SE Motor Oil

After filling pump the forks slowly up and down to distribute the oil.

8. Tighten:
  - Cap bolts
  - Pinch bolts



Cap Bolt:  
23 Nm (2.3 m·kg, 17 ft·lb)  
Pinch Bolt:  
23 Nm (2.3 m·kg, 17 ft·lb)

9. Install:
  - Handles

## 2



## SHOCK ABSORBER ADJUSTMENT

1. Remove:
  - Right side cover
2. Adjust
  - Shock absorber preload

|                    | ← Stiffer |   |   | Std. | Softer |
|--------------------|-----------|---|---|------|--------|
| Adjusting position | 5         | 4 | 3 | 2    | 1      |

① Macth mark




## STEERING HEAD

1. Handle cover
2. Washer
3. Steering stem bolt
4. Handle crown
5. Ring nut
6. Bearing cover
7. Upper bearing races
8. Lower bearing races
9. Bearing (Upper)
10. Bearing (Lower)


A

- Tight specified torque.
- If steering is binded loosen the ring nut so that there is no free play on bearing.



2





### Steering Head Inspection

1. Place the motorcycle on its centerstand, then elevate the front wheel.
2. Check:
  - Steering assembly bearings  
Grasp the bottom of the forks and gently rock the fork assembly back and forth.  
Looseness → Adjust steering head.

### Steering Head Adjustment

1. Remove:
  - Handle cover
  - Washer ①
2. Loosen:
  - Upper front fork pinch bolts
3. Remove:
  - Steering stem bolt
4. Lift the handle crown and handlebar assembly.
5. Tighten:
  - Ring nut ①  
Use the Ring Nut Wrench ② (90890-01268)
6. Install:
  - Handle crown/Handlebar assembly
  - Steering stem bolt



**Ring Nut**  
**38 Nm (3.8 m·kg, 27ft·lb)**

#### NOTE:

If steering is binded, loosen the ring nut so that there is no free play on bearing.



**54 Nm (5.4 m·kg, 39ft·lb)**

## STEERING HEAD



7. Tighten:
- Upper front fork pinch bolts




20 Nm (2.0 m·kg, 14 ft·lb)

8. Install:
- Washer
  - Handle cover

2


**WHEEL BEARINGS**
**Front Wheel**


- |                  |                        |
|------------------|------------------------|
| 1. Front axle    | 7. Bearing             |
| 2. Collar        | 8. Meter clutch        |
| 3. Oil seal      | 9. Clutch retainer     |
| 4. Bearing       | 10. Oil seal           |
| 5. Spacer        | 11. Gear unit assembly |
| 6. Spacer flange |                        |

**2**





## Rear Wheel

- |                  |               |
|------------------|---------------|
| 1. Rear axle     | 7. Bearing    |
| 2. Chain puller  | 8. Clutch hub |
| 3. Oil seal      | 9. Collar     |
| 4. Bearing       | 10. Bearing   |
| 5. Spacer flange | 11. Oil seal  |
| 6. Spacer        | 12. Collar    |



2



### Front Wheel Bearings

1. Raise the front end of the motorcycle, and spin the wheel by hand. Touch the axle or front fender while spinning the wheel.  
Excessive vibration → Replace bearings.

### Rear Wheel Bearings

1. Remove:
  - Rear wheel
2. Check:
  - Bearing movement  
With the fingers.  
Roughness/Wear → Replace.

## TUBELESS TIRES AND ALUMINUM WHEELS

### WARNING:


Do not attempt to use tubeless tires on a wheel designed for tube type tires only. Tire failure and personal injury may result from sudden deflation.

| Wheel     | Tire                  |
|-----------|-----------------------|
| Tube type | Tube type only        |
| Tubeless  | Tube type or tubeless |

Be sure to install the correct tube when using tube type tires.

Always perform the following steps to ensure safe operation, maximum tire performance, and long service.

1. Measure:
  - Tire pressure  
Out of specification → Adjust.



**A** Tubeless tire

**B** Tube type tire

**1** Air valve

**2** Aluminum wheel (tubeless type)


**3** Tube

**4** Aluminum wheel (tube type)

|   |   |   |
|---|---|---|
| Basic weight:<br>With oil and<br>full fuel tank | 208 kg (459 lb)                                 |   |
| Maximum load*                                   | 188 kg (414 lb)                                 |   |
| Cold tire pressure                              | Front   | Rear  |
| Up to 90 kg<br>(198 lb) load*                   | 177 kPa<br>(1.8 kg/cm <sup>2</sup> ,<br>26 psi) | 196 kPa<br>(2.0 kg/cm <sup>2</sup> ,<br>28 psi) |
| 90 kg (198 lb) ~<br>Maximum load*               | 196 kPa<br>(2.0 kg/cm <sup>2</sup> ,<br>28 psi) | 226 kPa<br>(2.3 kg/cm <sup>2</sup> ,<br>32 psi) |
| High speed riding                               | 196 kPa<br>2.0 kg/cm <sup>2</sup> ,<br>28 psi)  | 226 kPa<br>2.3 kg/cm <sup>2</sup> ,<br>32 psi)  |

\* Load is the total weight of cargo, rider, passenger, and accessories.

2



2. Inspect:
- Tire surfaces
- Wear/Damage → Replace.



**Minimum Tire Tread Depth:**  
(Front and Rear)  
0.8 mm (0.03 in)

- ① Tread depth  
② Side wall  
③ Wear indicator

3. Inspect:
- Aluminum wheels
- Damage/Bends → Replace.  
Never attempt even small repairs to the wheel.

**NOTE:**

Always balance the wheel when a tire or wheel has been changed or replaced.


4. Tighten:
- Valve stem locknut



1.5 Nm (0.15 m·kg, 1.1 ft·lb)

**WARNING:**


Ride conservatively after installing a tire to allow it to seat itself properly on the rim.

**ELECTRICAL****BATTERY**

1. Check:
    - Fluid level  
Incorrect → Refill  
Fluid level should be between upper and lower level marks.
- ① Upper level  
② Lower level


**CAUTION:**

Refill with distilled water only; tap water contains minerals harmful to a battery.

**2**


2. Connect:
  - Breather pipe ①  
Be sure the hose is properly attached and routed.
3. Inspect:
  - Breather pipe  
Obstruction → Remove.  
Damage → Replace.

**A** HOW TO LAY OUT BATTERY BREATHER PIPE.

**CAUTION:**

Always charge a new battery before using it to ensure maximum performance.

Charging Current:  
1.2 amps/10 hrs  
Specific Gravity:  
1.280 at 20°C (68°F)

**WARNING:**

Battery electrolyte is dangerous; it contains sulfuric acid and therefore is poisonous and highly caustic.

Always follow these preventive measures:

- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.
- Wear protective eye gear when handling or working near batteries.

**Antidote (EXTERNAL):**

- SKIN – Flush with water.
- EYES – Flush with water for 15 minutes and get immediate medical attention.

**Antidote (INTERNAL):**


- Drink large quantities of water or milk (follow with milk of magnesia) beaten egg, or vegetable oil. Get immediate medical attention.

Batteries also generate explosive hydrogen gas, therefore you should always follow these preventive measures:

- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks, or open flames (e.g., welding equipment, lighted cigarettes, etc.)
- **DO NOT SMOKE** when charging or handling batteries.


**KEEP BATTERIES AND ELECTROLYTE OUT OF REACH OF CHILDREN.**

2

**HEADLIGHT****Headlight Bulb Replacement**

1. Remove:
  - Headlight holding screws
2. Disconnect:
  - Headlight leads
3. Remove:
  - Bulb  
Turn the bulb holder counterclockwise to release bulb.
4. Install:
  - Bulb (new)  
Secure the new bulb with the bulb holder.




**WARNING:**

Do not touch headlight bulb when it is on as bulb generates enormous heat; keep flammable objects away.

**CAUTION:**

Avoid touching glass part of bulb. Also keep it free from oil otherwise, transparency of glass, bulb life and illuminous flux will be adversely affected. If oil gets on bulb, clean it with a cloth moistened thoroughly with alcohol or lacquer thinner.

① Don't touch

5. Install:

- Light until assembly

**2**

**HEADLIGHT ADJUSTMENT**
**Horizontal Adjustment**

1. Rotate:

- Horizontal adjusting screw ①


| Horizontal adjustment of headlight beam |                |
|---|----------------|
| Adjusting screw                         | Beam direction |
| Turn clockwise                          | →<br>Right     |
| Turn counterclockwise                   | ←<br>Left      |

**Vertical Adjustment**

1. Rotate:

- Vertical adjusting screw ②

| Vertical adjustment of headlight beam |                |
|---------------------------------------|----------------|
| Adjusting screw                       | Beam direction |
| Turn clockwise                        | ↑ To raise     |
| Turn counterclockwise                 | ↓ To lower     |



## FUSE

The fuse panel is located under the seat.

### 1. Inspect:

- Fuses

Defective → Replace.

Blown fuse (new) → Inspect circuit.

### NOTE:

Install new fuses of proper amperage.

### ① Spare fuses

| Description | Amperage   | Quantity |
|-------------|------------|----------|
| Main        | 30A        | 1        |
| Headlight   | 20A        | 1        |
| Signal      | 10A        | 1        |
| Ignition    | 10A        | 1        |
| Reserve     | 30A<br>20A | 1<br>1   |

### Blown fuse procedure steps

- Turn off ignition and the circuit.
- Install a new fuse of proper amperage.
- Turn on switches to verify operation of electrical device.
- If fuse blows immediately again, check circuit in question.

### WARNING:

Do not use fuses of higher amperage rating than recommended. Extensive electrical system damage and fire could result from substitution of a fuse of improper amperage.

**2**



## ENGINE OVERHAUL

### ENGINE REMOVAL

**NOTE:**

It is not necessary to remove the engine in order to remove the following components.

- Carburetor      ● Clutch
- AC magneto

# 3

**Preparation steps:**

- Remove all dirt, mud, dust, and foreign material before removal and disassembly.
- Use proper tools and cleaning equipment.

**NOTE:**

When disassembling the engine, keep mated parts together. This includes gears, cylinders, pistons, and other parts that have been "mated" through normal wear. Mated parts must be reused as an assembly or replaced.


- During engine disassembly, clean all parts and place them in trays in the order of disassembly. This will speed up assembly time and help assure that all parts are correctly reinstalled in the engine.
- Drain engine oil completely.

**COWLING AND LOWER COWL**

1. Remove:
  - Headlight unit assembly
2. Remove:
  - Cowling
3. Remove:
  - Lower cowl

**3****SEAT AND FUEL TANK**

1. Remove:
  - Side cover
  - Seat
2. Turn fuel cock to "ON"
3. Disconnect
  - Fuel cock vacuum hose ①
  - Fuel feed hose ②
4. Remove:
  - Fuel tank bolt
  - Fuel sender unit lead
  - Fuel tank






## EXHAUST PIPE AND MUFFLER


1. Remove:
  - Exhaust pipe



2. Loosen:
  - Exhaust pipe clamp



3. Remove:
  - Footrest bracket bolt ①
  - Lower cowl clamp ②



## CARBURETOR AND CABLE

1. Remove:
  - Throttle cable ①
  - Starter cable ②




2. Loosen:
  - Carburetor joint clamp screw ①
  - Air cleaner joint clamp screw ②






3. Loosen:
  - Air cleaner bolt ①



4. Remove:
  - Carburetor
5. Disconnect:
  - Clutch cable ①
  - Crankcase ventilation hose ②




## CHANGE PEDAL AND DRIVE CHAIN

1. Remove:
  - E-clip ①
  - Washer ②
  - Bolt ③
  - Change pedal assembly
  - Crankcase cover ④

2. Loosen:
  - Rear axle nut
  - Adjusting bolt
  - Drive chain




3. Remove:
  - Bolts ①
  - Stopper ②
  - Drive chain sprocket ③



### BATTERY AND WIRING


1. Disconnect:
  - Battery minus lead ①
  - Pulser coil lead ②
  - Oil level switch lead ③
  - Neutral switch lead ④
2. Remove:
  - Brake fluid tank screw ⑤



3. Disconnect:
  - Stator motor lead ①
  - Battery plus lead ②
4. Remove:
  - Battery cover ③
  - Battery ④




5. Disconnect:
  - Ground lead



### OIL COOLER

1. Remove:
  - Oil filter bolt ①
  - Oil filter clamp nuts ②
  - Spacer nut ③




### ENGINE REMOVAL

1. Place a suitable stand under the engine
2. Remove:
  - Front upper mounting bolt ①
  - Bracket bolt ②
  - Front lower mounting bolt ③
  - Rear mounting bolt ④
  - Engine assembly (from right chassis.)




## ENGINE DISASSEMBLY


### CYLINDER HEAD AND CAMSHAFT




1. Remove:
  - Cylinder head cover ①
  - Spark plug ②
  - Left crankcase cover




2. Turn:
  - Crankshaft (Counterclockwise)
3. Align:
  - Timing plate "C" mark ① (with the upper pick up coil mark ② )



4. Remove:
  - Tensioner assembly ①
  - Upper chain guide ②




5. Remove:
  - Chain guide stopper ①
  - Exhaust side chain guide ②
  - No. 3 intake cam cap
  - No. 3 exhaust cam cap



6. Remove:
  - Sprocket bolts ①
7. Dismount the sprockets from the camshaft sprocket seats

3






8. Remove:
- Cam caps

**CAUTION:**

Do not rotate the camshaft or valve damage may occur.




9. Remove:
- Camshafts

**NOTE:**

Fasten safety wire (1) to the cam chain to prevent it from falling into the crankcase.



3




10. Remove:
- Cylinder head

**NOTE:**

Loosen the nuts in their proper loosening sequence.



11. Remove:
- Damper (1)
  - Front engine mount spacer (2)
  - Nut (3)
  - Cylinder



### PISTON AND INTAKE SIDE CAM CHAIN GUIDE

1. Mark:

- Pistons  
(with piston number ① designations as shown)



2. Remove:

- Piston pin circlips

**NOTE:**

Before removing piston pin circlip, cover crankcase with a clean rag to prevent circlip from falling into crankcase cavity.

**3**

3. Remove:


- Piston pins
- Pistons

Push piston pin from the opposite side, then pull it out.




4. Remove:

- Bolt ①
- Plate washer
- Spring ②
- Stopper shaft ③
- Intake side cam chain guide ④

**PICK UP COIL, GENERATOR AND STARTER MOTOR**


1. Remove:
  - Screw
  - Timing plate (1)



2. Remove:
  - Pick up coil assembly (1)
  - Generator cover (2)








3. Remove:
  - Stator coil (1)



4. Remove:
  - Rotor securing bolt (1)
  - RotorUse Rotor Holding Tool (2) (90890-04067) and Rotor Puller (3) (90890-01080).



5. Remove:
  - Starter motor

**CLUTCH****1. Remove:**

- Right crankcase cover (1)
- Dowels (2)
- Gasket (3)

**2. Remove:**

- Bolts (1)
- Plate washers (2)
- Springs (3)
- Pressure plate (4)
- Friction plates
- Clutch plates

**3. Loosen:**

- Nut (1)


Use universal Clutch Holder (2) (90890-04086)

**NOTE:**



If you need to remove the primary drive gear at this stage, place a piece of rolled rug (1) or lead between the primary drive gears. Then loosen the drive gear nut (2).

**4. Remove:**


- Nut (1)
- Lock washer (2)
- Clutch boss (3)
- Thrust washer (4)
- Clutch housing (5)


**OIL PUMP AND SHIFT SHAFT**

1. Remove:
  - Circlip ①
  - Oil pump driven gear ②
  - Oil pump assembly ③
  - O-rings ④
2. Remove:
  - Collar ①
  - Plate washer ②  
(from left side shift shaft.)
3. Unhook the shift lever 2 ③ and pull the shift shaft.
4. Unhook the stopper lever ①
5. Remove:
  - Shift shaft assembly ②

**CRANKCASE DISASSEMBLY**

1. Remove:
  - Right-front crankcase cover
2. Remove:
  - Oil pan





## 3. Remove:

- Upper crankcase bolts **A**
- Lower crankcase bolts **B**

**NOTE:**

- Remove the bolts starting with the highest numbered one.
- The embossed numbers in the crankcase designate the crankcase tightening sequence.

## 4. Remove:

- Lower crankcase  
Use a rubber hammer


**3**

- 6 mm bolts
- 8 mm bolts

**UPPER CRANKCASE**


## 1. Remove:


- Drive axle assembly **①**
- Main axle assembly **②**



## 2. Remove:


- Nut **①**
- Lock washer **②**
- Primary drive gear **③**
- Collar **④**






## 3. Remove:

- Screw ①
- Cover plate ②
- Oil spray nozzle ③
- Bearing housing ④
- A.C.G. shaft ⑤




## 4. Remove:

- Starter clutch damper assembly ①
- Crankshaft assembly ②
- Cam chain ③
- HY-VO chain ④



## 5. Remove:


- Screws ①
- Bearing stopper ②
- Shaft ③
- Starter idler gear ④



## LOWER CRANKCASE

## 1. Remove:


- Lock washer ①
- Stopper screw ②
- Screws ③
- Guide bar stopper ④
- Bearing stopper ⑤



## 2. Remove:


- Guide bar ①
- Shift forks ②
- Shift cam assembly ③






## 3. Remove:

- HY-VO chain guide (1)
- HY-VO chain tensioner (2)
- Tensioner plunger (3)
- Spring (4)



## 4. Remove:

- Oil strainer (1)
- Screw (2)
- Strainer housing (3)
- Relief valve (4)
- Tensioner side relief valve (5)



## INSPECTION AND REPAIR CYLINDER HEAD

## 1. Remove:

- Valve pads
- Lifters
- Spark plugs


**NOTE:**

Identify each lifter and pad position very carefully so that it can be reinstalled in its original place.



## 2. Attach:


- Valve Spring Compressor (90890-04019) (1)



## 3. Remove:

- Valve retainers (1)
- Valve spring seat (2)
- Valve springs (3)
- Oil seal (4)
- Valve spring seat (5)
- Valve (6)



**NOTE:**

Deburr any deformed valve stem end. Use an oil stone to smooth the stem end.

- ① Deburr
- ② Valve stem

4. Eliminate:
- Carbon deposit (from combustion chamber)
- Use rounded scraper

**NOTE:**



Do not use a sharp instrument and avoid damaging or scratching:

- Spark plug threads
- Valve seat
- Aluminum

5. Measure:
- Warpage
- Exceeds allowable limit → Resurface.



**Cylinder Head Warpage:**  
Less than 0.03 mm (0.0012 in)  
**Allowable Limit:**  
0.25 mm (0.010 in)



### VALVE, VALVE GUIDE, VALVE SEATS, AND VALVE SPRING

1. Measure:
- Valve stem clearance




$$\text{Valve stem clearance} = \text{Valve guide inside diameter } ① - \text{Valve stem diameter } ②$$

Out of specification → Replace valve or guide.



|         | Valve Stem Clearance                     | Maximum               |
|---------|--|-----------------------|
| Intake  | 0.010 ~ 0.037 mm<br>(0.0004 ~ 0.0015 in) | 0.10 mm<br>(0.004 in) |
| Exhaust | 0.025 ~ 0.052 mm<br>(0.0010 ~ 0.0020 in) | 0.12 mm<br>(0.005 in) |

- ③ Bore gauge



## 2. Measure:

- Valve face  
Pitting/Wear → Re grind.  
Out of specification → Replace.

**Minimum Thickness**

(Service limit) ① :

0.7 mm (0.0276 in)

Beveled ② : 0.5 mm (0.020 in)

**Minimum Length**

(Service limit) ③ :

4.0 mm (0.157 in)

## 3. Check

- Valve stem end  
Mushroom shape or diameter larger than rest of stem → Replace.
- Runout  
Out of specification → Replace.

**Maximum Valve Stem Runout:**

0.03 mm (0.0012 in)

3

## 4. Measure:

- Valve guide (inside diameter) ①  
Out of specification → Replace.

**Guide Inside Diameter:**


Limit: 6.10 mm (0.240 in)

## 5. Inspect:

- Valve guide  
Wear/Oil leakage → Replace.

**NOTE:**

Heat the cylinder head in an oven to 100°C (212°F) to ease valve guide removal and reinstallation and to maintain correct interference fit.




**Valve Guide Replacement**

## 1. Remove:

- Valve guide  
Use Valve Guide Remover (90890-04064) ①.

**NOTE:**

- Always replace valve guide if valve is replaced.
- Always replace oil seal if valve is removed.



## 2. Install:

- Valve Guide (new)  
Use Valve Guide Installer (90890-04065)  
and Valve Guide Remover (90890-04064)

## 3. Bore valve guide (2) to obtain proper valve stem clearance.

- Use 6 mm Reamer (90890-04066) (1)

**Valve Seat**

## 1. Inspect:

- Valve seat  
Pitting/Wear → Cut.

## 2. Measure:

- Valve seat width (1)  
Out of specification → Follow next steps.

|                  | Standard Width                      | Wear Limit           |
|------------------|-------------------------------------|----------------------|
| Valve Seat Width | 1.0 ± 0.1 mm<br>(0.039 ± 0.0039 in) | 1.7 mm<br>(0.067 in) |

## 3. Apply:

- Mechanic's bluing dye (Dykem)  
(to valve and seat)
- Fine grinding compound (Small amount)  
(to valve face surface)


## 4. Position:

- Valve  
(into cylinder head)

## 5. Spin it rapidly back and forth, then lift valve and clean off all grinding compound.

## 6. Inspect:

- Valve seat surface  
Wherever valve seat and valve face made contact, bluing will have been removed.






## 7. Measure:

- Valve seat width

Valve seat width must be uniform in contact area.

Out of specification → Cut.





## 8. Cut valve seat.

**NOTE:**

Cut valve seat using valve seat cutter ① if valve seat width exceeds limit or if valve seat is pitted or worn.

**CAUTION:**

When twisting cutter, keep an even downward pressure to prevent chatter marks.

**3**

**Valve seat recutting steps are necessary if:**

- Valve seat is uniform around perimeter of valve face but too wide or too narrow or not centered on valve face.

**Cut Valve Seat As Follows:**





|           |            |
|-----------|------------|
| Section A | 0° Cutter  |
| Section B | 45° Cutter |
| Section C | 60° Cutter |

- Valve face indicates that valve seat is centered on valve face but is wide (See "a" diagram).

| Valve Seat Cutter Set |            | Desired Result              |
|-----------------------|------------|-----------------------------|
| Use                   | 0° Cutter  | to reduce valve seat width. |
|                       | 60° Cutter |                             |



3



- Valve seat is in the middle of the valve face but too narrow (See "b" diagram).

| Valve Seat Cutter Set |            | Desired Result  |
|-----------------------|------------|---|
| Use                   | 45° Cutter | to achieve a uniform valve seat width (Standard specification). |

- Valve seat is too narrow and right up near valve margin (See "c" diagram).

| Valve Seat Cutter Set |                  | Desired Result                |
|-----------------------|------------------|-------------------------------|
| Use                   | 0° Cutter, first | to obtain correct seat width. |
|                       | 45° Cutter       |                               |

- Valve seat is too narrow and is located down near the bottom edge of the valve face (See "d" diagram).

| Valve Seat Cutter Set |                   | Desired Result                |
|-----------------------|-------------------|-------------------------------|
| Use                   | 60° Cutter, first | to obtain correct seat width. |
|                       | 45° Cutter        |                               |

**NOTE:**

Lap valve/valve seat assembly if:


- Valve face/valve seat are used or severely worn.
- Valve and valve guide has been replaced.
- Valve seat has been cut.

**Valve/Valve Seat Assembly Lapping****1. Apply:**

- Coarse lapping compound (Small amount)  
(to valve face)

**2. Position**

- Valve  
(in cylinder head)




3. Rotate:
  - Valve  
Turn until valve and valve seat are evenly polished, then clean off compound.
4. Repeat above steps with fine compound and continue lapping until valve face shows a completely smooth surface uniformly.
5. Eliminate:
  - Compound  
(from valve face)
6. Apply:
  - Mechanic's bluing dye (Dykem) ①  
(to valve face and seat)
7. Rotate:
  - Valve  
Valve must make full seat contact indicated by grey surface all around valve face where bluing was removed.
8. Apply:
  - Solvent  
(into each intake and exhaust port)  
Leakage past valve seat → Replace valve until seal is complete.

**3****NOTE:**

Pour solvent into intake and exhaust ports only after completion of all valve work and assembly of head parts.

**Relapping steps:**

- Reassemble head parts.
- Repeat lapping steps using fine lapping compound.
- Clean all parts thoroughly.
- Reassemble and check for leakage again using solvent.
- Repeat steps as often as necessary to effect a satisfactory seal.

**Valve Spring Measurement**


## 1. Measure:

- Valve spring free length ①  
Out of specification → Replace.

**Valve Spring Free Length**

| Inner Spring          |                       | Outer Spring          |                       |
|-----------------------|-----------------------|-----------------------|-----------------------|
| Standard              | Wear limit            | Standard              | Wear limit            |
| 35.5 mm<br>(1.398 in) | 33.5 mm<br>(1.319 in) | 37.2 mm<br>(1.465 in) | 35.2 mm<br>(1.386 in) |

3




## 2. Measure:

- Valve spring installed force ①  
Out of specification → Replace.

**Valve Spring Installed Force**

| Inner Spring         |                     | Outer Spring         |                      |
|----------------------|---------------------|----------------------|----------------------|
| ②                    | ①                   | ②                    | ①                    |
| 30.5 mm<br>(1.20 in) | 9.3 kg<br>(20.5 lb) | 32.0 mm<br>(1.26 in) | 18.5 kg<br>(40.8 lb) |

② Installed length

**Valve Installation****1. Lubricate**

- Valve stem
- Oil seal



**High-Quality Molybdenum Disulfide  
Motor Oil or Molybdenum Disulfide  
Grease.**



**2. Install:**

- Valve (1)
- Valve spring seat (2)
- Oil seal (3)
- Valve springs (4)
- Valve spring seat (5)
- Valve retainers (6)



**NOTE:**

Install all springs with wider-gapped coils facing upwards as shown.





3



## CAMSHAFT, CAM CHAIN, AND CAM SPROCKET

### Camshaft

#### 1. Measure:

- Large cam lobe length ①
- Small cam lobe length ②

Use a micrometer.

Out of specification → Replace.

|   | Intake                               | Exhaust                            |
|---|--------------------------------------|------------------------------------|
| ① | 36.25~36.35 mm<br>(1.427~1.431 in)   | 35.75~35.85 mm<br>(1.408~1.411 in) |
| ② | 28.10~28.20 mm<br>(1.106 ~ 1.110 in) | 28.05~28.15 mm<br>(1.104~1.108 in) |

### Camshaft/Cap Clearance Measurement

#### 1. Install

- Camshaft

#### 2. Position:

- Strip of Plastigage® (YU-33210)  
(onto camshaft.)

#### 3. Install:

- Camshaft caps ①



10 Nm (1.0 m·kg, 7.2 ft·lb)

#### NOTE:

Do not turn the camshaft when measuring clearance with plastigage.

#### 4. Remove:

- Camshaft caps

#### 5. Measure:

- Width of Plastigage® ①

Out of specification → Follow step 6.



#### Camshaft-to-cap Clearance:

Standard: 0.020 ~ 0.054 mm  
(0.0008 ~ 0.0021 in)

Maximum: 0.160 mm (0.006 in)



## 6. Measure:

- Camshaft bearing surface diameter  
Use micrometer.  
Out of specification → Replace camshaft.  
Within specification → Replace cylinder head.


**Bearing Surface Diameter:**

Standard: 24.967~24.980 mm  
(0.9830~0.9835 in)

**Cam Chain**

## 1. Inspect:

- Cam chain  
Chain stretch/Cracks → Replace.

**Cam Sprockets**

## 1. Inspect:


- Cam sprockets  
Wear/Damage → Replace.

3

**Cam Chain Dampers**


## 1. Inspect:

- Upper damper ①
- Exhaust side chain guide ②
- Intake side chain guide ③
- Chain guide stopper ④
- Spring ⑤
- Guide stopper plate ⑥  
Wear/Damage → Replace

**Cam Chain Tensioner**

## 1. Inspect:



- All parts  
Damage/Wear → Replace.



- ① Tensioner rod (Small)
- ② Damper
- ③ Tensioner rod (Large)
- ④ Spring
- ⑤ Gasket
- ⑥ Tensioner body
- ⑦ O-ring



3

**CYLINDER**

1. Inspect:
  - Cylinder walls
  - Vertical scratches → Rebore or Replace cylinder.
2. Measure:
  - Cylinder inside diameter

**NOTE:**

Obtain measurements at three depths by placing measuring instrument parallel to and at right angles to crankshaft.

Out of specification → Rebore cylinder, and replace piston and piston rings.

|                   | Standard              | Wear limit            |
|-------------------|-----------------------|-----------------------|
| Cylinder Bore: C  | 58.5 mm<br>(2.303 in) | 58.6 mm<br>(2.307 in) |
| Cylinder Taper: T | —                     | 0.05 mm<br>(0.002 in) |

C = Maximum D

T = Maximum  $D_1, D_2$  — Minimum  $D_5, D_6$

**PISTON, PISTON RING, AND PISTON PIN****Piston**

1. Measure:
  - Piston skirt diameter "P"

**NOTE:**

Measure the piston skirt diameter where the distance 7.0 mm (0.276 in) ① from the piston bottom edge.

|           | Piston size            |
|-----------|------------------------|
| Standard  | 58.50 mm<br>(2.303 in) |
| Overize 2 | 59.00 mm<br>(2.323 in) |
| Overize 4 | 60.00 mm<br>(2.362 in) |




2. Measure:
- Piston clearance

Out of specification → Rebore cylinder or replace piston.



**Piston Clearance = C – P:**  
 0.025 ~ 0.045 mm  
 (0.0010 ~ 0.0019 in)

C: Cylinder bore P: Piston outside diameter



### Piston Ring

1. Measure:
- Ring side clearance
- Use a feeler gauge.  
 Out of specification → Replace piston.

#### NOTE:

Clean carbon from piston ring grooves and rings before measuring side clearance.



#### Piston Ring Side Clearance:

|     |  |
|-----|--|
| Top | 0.03 ~ 0.07 mm<br>(0.0012 ~ 0.0028 in) |
| 2nd | 0.02 ~ 0.06 mm<br>(0.0008 ~ 0.0024 in) |

2. Position:
- Piston ring  
(in cylinder)

#### NOTE:

Insert a ring into cylinder, and push it approximately 20 mm (0.8 in) into cylinder. Push ring with piston crown so that ring will be at a right angle to cylinder bore.




## 3. Measure:



- Ring end gap  
Out of specification → Replace.

**NOTE:**

You cannot measure end gap on expander spacer of oil control ring. If oil control ring rails show excessive gap, replace all three rings.

|  | Standard                           | Limit                  |
|---|------------------------------------|------------------------|
| Top ring  | 0.15~0.30 mm<br>(0.0059~0.0118 in) | 0.70 mm<br>(0.0276 in) |
| 2nd ring  | 0.15~0.30 mm<br>(0.0059~0.0118 in) | 0.70 mm<br>(0.0276 in) |
| Oil control<br>(Rails)  | 0.2~0.7 mm<br>(0.008~0.028 in)     | —                      |

3

**Piston Ring Oversize**

- Top and 2nd piston ring




Oversize top and middle ring sizes are stamped on top of ring.

|            |                     |
|------------|---------------------|
| Oversize 2 | 0.50 mm (0.0197 in) |
| Oversize 4 | 1.00 mm (0.0394 in) |

- Oil control ring

Expander spacer of bottom ring (oil control ring) is color-coded to identify sizes.

| Size       | Color  |
|------------|--------|
| Oversize 2 | Blue   |
| Oversize 4 | Yellow |

**Piston Pin**

1. Lubricate:
  - Piston pin (Lightly)
2. Install:
  - Piston pin  
(into small end of connecting rod)
3. Check:
  - Free play  
Free play → Inspect connecting rod for wear.  
Wear → Replace connecting rod and piston pin.
4. Position:
  - Piston pin  
(into piston)
5. Check:
  - Free play  
(into piston)  
Free play → Replace piston pin and/or piston.

**3****CRANKSHAFT AND CONNECTING ROD****Crankshaft Runout**

1. Place both ends of crankshaft on V-blocks.
2. Rotate:
  - Crankshaft
3. Measure:
  - Crankshaft runout  
(at main journal bearings)  
Use a Dial Gauge (90890-03097).



**Maximum Crankshaft Runout:**  
**0.03 mm (0.0012 in)**

**Connecting Rod Bearings**

1. Inspect:
  - Bearings  
Burns/Flaking/Roughness/Scratches → Replace.

**Connecting Rod Bearing Clearance**

1. Clean all parts thoroughly.
2. Install:
  - Connecting rod bearings  
(into connecting rod and cap)
3. Attach:
  - Plastigage®  
(onto crankpin)
4. Position:
  - Connecting rod  
(onto crankshaft)
  - Connecting rod cap



5. Apply:
- Molybdenum disulfide grease  
(to bolt threads)
- Torque both ends of rod cap evenly.

**NOTE:**

Do not move connecting rod until a clearance measurement has been completed.

**CAUTION:**

Tighten to full torque specification without pausing. Apply continuous torque between 2.0 and 2.5 m·kg. Once you reach 2.0 m·kg DO NOT STOP TIGHTENING until final torque is reached. If tightening is interrupted between 2.0 and 2.5 m·kg, loosen nut to less than 2.0 m·kg and start again.

**3**

25 Nm (2.5 m·kg, 18 ft·lb)



6. Remove:
- Connecting rod cap  
Remove carefully.
7. Measure:
- Plastigage width  
Out of specification → Replace connecting rod bearing.



Connecting Rod Bearing Clearance:  
0.016 ~ 0.040 mm  
(0.0006 ~ 0.0016 in)



### Crankshaft Main Bearing Clearance Measurement

1. Clean all parts.
2. Position:
  - Upper crankcase half  
Place on a bench in an upside down position.
3. Install:
  - Bearings  
(into the upper crankcase)
  - Crankshaft
4. Attach:
  - Plastigage® (YU-33210)  
(onto the crankshaft journal surface)

#### NOTE:

Do not move crankshaft until clearance measurement has been completed)

5. Install:
  - Bearings  
(into lower crankcase)
  - Lower crankcase

6. Tighten:
  - Bolts

#### CAUTION:

Tighten to full torque in torque sequence cast on the crankcase.




8 mm (0.3 in) Bolt:  
24 Nm (2.4 m·kg, 17 ft·lb)

7. Remove:
  - Bolts  
Reverse assembly order
  - Lower crankcase  
Use care in removing.




8. Measure:
  - Plastigage width® ① (YU-33210)  
Out of specification → Replace bearings;  
replace crankshaft if necessary.



Main Bearing Oil Clearance:  
0.021 ~ 0.044 mm  
(0.0008 ~ 0.0017 in)







### Crankshaft Main and Connecting Rod Bearing Selection

- Numbers used to indicate crankshaft journal sizes are stamped on the LH crankweb. The first five (5) are main bearing journal numbers, starting with the left journal. The four (4) rod bearing journal numbers follow in the same sequence.
- The upper crankcase half is numbered J1, J2, J3, J4, and J5 on the rear right boss as shown.

- The connecting rods are numbered 4 or 5. The numbers are stamped in ink on the rod cap ①.

| BEARING COLOR CODE |        |
|--------------------|--------|
| No. 1              | Blue   |
| No. 2              | Black  |
| No. 3              | Brown  |
| No. 4              | Green  |
| * No. 5            | Yellow |

\* No. 5 applies only to the crankshaft main bearing selection.





Example 1: Selection of the crankshaft main bearing; If the crankcase J1 and crankshaft J1 sizes are No. 4 and No. 1, respectively, the bearing size No. is:

$$\begin{aligned} \text{Bearing size No.} &= \\ \text{Crankcase No.} - \text{Crankshaft No.} &= \\ 4 - 1 &= 3 \text{ (Brown)} \end{aligned}$$

Example 2: Selection of the connecting rod bearing; If the connecting rod P1 and crankshaft P1 sizes are No. 4. and No. 1, respectively, the bearing size No. is:

$$\begin{aligned} \text{Bearing size No.} &= \\ \text{Connecting rod No.} - \text{crankshaft No.} &= \\ 4 - 1 &= 3 \text{ (Brown)} \end{aligned}$$

3



## OIL PUMP

1. Remove:
  - Screw ①
  - Pump cover ②
  - Shaft ③
  - Pin ④
  - Inner rotor ⑤
  - Outer rotor ⑥
  - Pump housing ⑦
2. Measure:
  - Clearance "A"  
(between inner rotor ① and outer rotor ②)
  - Clearance "B"  
(between outer rotor ② and pump housing ③)
  - Clearance "C"  
(between pump housing ③ and rotors ①, ②)

Out of specification → Replace oil pump.



### Oil Pump Clearance:

|               |                                 |
|---------------|---------------------------------|
| Clearance "A" | 0.03~0.09 mm (0.0012~0.0035 in) |
| Clearance "B" | 0.03~0.08 mm (0.0012~0.0031 in) |
| Clearance "C" | 0.03~0.09 mm (0.0012~0.0035 in) |




3. Install:
  - Oil pump parts.
4. Tighten:
  - Screw



7 Nm (0.7 m·kg, 5.1 ft·lb)

# 3



## PRIMARY DRIVE

1. Inspect:
  - HY-VO chain ①
  - Crankshaft drive sprocket ②
  - Clutch damper driven sprocket ③
  - Primary drive gear ④
  - Primary driven gear ⑤

Wear/Damage → Replace both gears.  
Excessive noises during operation → Replace both gears.

### Primary Reduction Ratio:

| No. of teeth |       | Ratio |
|--------------|-------|-------|
| ③ / ②        | ⑤ / ④ |       |
| 22/21        | 65/25 | 2.432 |


## STARTER DRIVES

### Electric Starter Clutch

1. Check:
  - Ball operation
  - Spring operation
  - Spring cap operation

Unsmooth operation → Replace one-way clutch.
2. Inspect:
  - Surface of the idle gear

Pitting/Wear/Damage → Replace.



## 3. Installation

## a. Install:

- Cover ①
- Outer starter clutch ②

## b. Tighten:

- Bolts ③




24 Nm (2.4 m·kg, 17 ft·lb)

LOCTITE®

Stake Over the End of the Bolt

## c. Install:

- Spring
- Spring cap
- Ball ④
- Idler gear ⑤
- Collar ⑥




## Starter Clutch Shaft

## 1. Check:

- Shaft ①  
Wear/Damage → Replace
- Bearing ②  
Unsmooth operation → Replace

3




## CLUTCH

## 1. Inspect:

- Clutch housing dogs ①  
Cracks/Pitting (edges):  
Moderate → Deburr.  
Severe → Replace clutch housing.

## NOTE:

Pitting on friction plate dogs of clutch housing will cause erratic operation.




2. Inspect:
- Clutch housing bearing  
Damage → Replace.

3. Inspect:
- Clutch boss spline ①  
Pitting:  
Moderate → Deburr.  
Severe → Replace.



**NOTE:**

Pitting on clutch plate splines of clutch boss will cause erratic operation.




4. Measure:
- Clutch plate warpage **A**
  - Friction plate thickness **B**  
Out of specification → Replace.  
Clutch or friction plate as a set.

|                          | Standard            | Wear limit          |
|--------------------------|---------------------|---------------------|
| Friction Plate Thickness | 3.0 mm<br>(0.12 in) | 2.8 mm<br>(0.11 in) |
| Clutch Plate Warp Limit  | —                   | 0.1<br>(0.004 in)   |





5. Inspect:
- Washer ①
  - Thrust bearing ②
  - Pull rod ③  
Damage → Replace.



6. Measure:
- Clutch spring free play  
Out of specification → Replace spring as a set.



**Clutch Spring Minimum Free Length:**  
40.2 mm (1.583 in)

**TRANSMISSION**

## 1. Inspect:

- Shift fork cam follower ①
  - Shift fork pawl ②
- Scoring/Bends/Wear → Replace.

## 2. Check:

- Guide bar ③
- Roll across a surface plate.  
Bends → Replace

## 3. Inspect:

- Shift cam groove ①
  - Shift cam dowel ② and side plate
  - Shift cam stopper plate ③ circlip and stopper.
- Wear/Damage → Replace.


## 4. Measure:

- Transmission shaft runout
- Use centering device and dial gauge.  
Out of specification → Replace bent shaft.



**Maximum Runout:**  
0.08 mm (0.0031 in)

3




## 5. Inspect:

- Gear teeth
- Blue discoloration/Pitting/Wear  
→ Replace.
- Mated dogs
- Rounded edges/Cracks/Missing portions  
→ Replace.

## 6. Check:

- Proper gear engagement (Each gear)  
(to its counter part)
- Incorrect → Resemble
- Gear movement
- Roughness → Replace.





## HY-VO CHAIN GUIDE AND TENSIONER


## 1. Check:

- HY-VO chain guide ①
  - Tensioner plunger ②
  - Spring ③
- Damage/Wear → Replace



## 2. Check:

- HY-VO chain tensioner ①
  - Oil delivery pipe ②
  - O-ring ③
  - Cotter pin ④
- Damage → Replace




3

## RELIEF VALVES


## 1. Check:

- Relief valve body ①
  - Plunger ②
  - Spring ③
  - O-ring ④
- Damage/Wear → Replace



## 2. Check:

- Tensioner side relief valve body ①
  - Plunger ②
  - Spring ③
- Damage/Wear → Replace



## CRANKCASE

## 1. Inspect:


- Case halves
  - Bearing seat
  - Fitting
- Damage → Replace.

**BEARINGS AND OIL SEALS**

1. Inspect:
  - Bearing  
Clean and lubricate, then rotate inner race with finger.  
Roughness → Replace bearing (see Removal).
2. Inspect:
  - Oil seals  
Damage/Wear → Replace (see Removal).

**CIRCLIPS AND WASHERS**

1. Inspect:
  - Circlips
  - Washers  
Damage/Looseness/Bends → Replace.

**ENGINE ASSEMBLY AND ADJUSTMENT****LOWER CRANK CASE**

1. Install:
  - Tensioner side relief valve ⑤

**20 Nm (2.0 m·kg, 14 ft·lb)**

- Relief valve ④
- Strainer housing ③
- Screws ②

**10 Nm (1.0 m·kg, 7.2 ft·lb)**

- Oil strainer ①






2. Install:
- HY-VO chain tensioner (2)



**Screw:**  
10 Nm (1.0 m·kg, 7.2 ft·lb)  
Apply LOCTITE®

- HV-VO chain guide (1)
- Spring (4)
- Tensioner plunger (3)




3. Install:
- Shift cam assembly
  - Shift forks (1)
  - Guide bar

**NOTE:**

All shift fork numbers shift should face the right side and be in sequence (1,2,3) beginning from the right.

3



4. Install:
- Bearing stopper (5)
  - Guide bar stopper (4)
  - Screws (3)




10 Nm (1.0 m·kg, 7.2 ft·lb)

- Stopper screw (2)



22 Nm (2.2 m·kg, 16 ft·lb)


- Lock washer (1)



## UPPER CRANKCASE

## 1. Install:

- Starter idler gear (4)
- Shaft (3)
- Bearing stopper (2)
- Screws (1)




## 2. Install:

- HY-VO chain (1)
- Cam chain (2)
- Oil seal (3)
- Plug (5)  
(onto crankshaft)
- Crankshaft assembly (4)
- Starter clutch damper assembly (5)

3

## NOTE:

- The crankshaft pin (6) (timing plate stopper pin) should face to the left.
- Pass the cam chain through the cam chain cavity. Be sure to attach a retaining wire (7) to the cam chain.




## 3. Install:

- A.C.G shaft (5)
- Bearing housing (4)
- Oil sprag nozzle (3)
- Cover plate (2)
- Screw (1)




10 Nm (1.0 m·kg, 7.2 ft·lb)  
Apply LOCTITE®



4. Install:
- Collar ④
  - Primary drive gear ③
  - Lock washer ②
  - Nut ①



**Primary Drive Gear Nut:**  
50 Nm (5.0 m·kg, 36 ft·lb)



5. Install:
- Main axle assembly ①
  - Drive axle assembly ②
  - Dowels ③
  - Circlip ④
- Insert bearing circlips completely into upper crankcase positioning grooves.


# 3

## CRANKCASE ASSEMBLY


1. Apply Yamaha bond No. 5 to crankcase matching surfaces.

### NOTE:

DO NOT ALLOW any sealant to come in contact with the oil gallery O-ring, or crankshaft bearings. Do not apply sealant to within 2 ~ 3 mm (0.08 ~ 0.12 in) of the bearings.




2. Set shift cam and transmission gears in NEUTRAL position.
3. Place suitable bar on the upper crankcase.



4. Place lower crankcase assembly on the upper crankcase assembly.

### NOTE:

Push HY-VO chain damper ① to prevent tensioner plunger ② from falling into crankcase cavity.



## 5. Install:

- Lower crankcase

Carefully guide shift forks so that they mesh smoothly with transmission gears.

**CAUTION:**

Before tightening the crankcase bolts, check the following points:

- Remove bar ① after shift fork meshed.
- Be sure the gear shifts correctly while hand-turning the shift cam.

## 6. Tighten:


- Lower crankcase bolt **B**
  - Upper crankcase bolt **A**
- (Follow proper tightening sequence.)





- 6 mm (0.24 in):  
12 Nm (1.2 m·kg, 8.7 ft·lb)
- 8 mm (0.31 in):  
24 Nm (2.4 m·kg, 17 ft·lb)

3


A



B

**NOTE:**

- Install the clamp ① on Bolt No. 26
- Install the clamp ② on Bolt No. 33 and ground lead ③ on Bolt No. 32.



7. Install:  
● Oil pan



10 Nm (1.0 m·kg, 7.2 ft·lb)



8. Install:  
● Right-front crankcase cover




10 Nm (1.0 m·kg, 7.2 ft·lb)

3





### OIL PUMP AND SHIFT SHAFT

1. Install:  
● Shift shaft assembly (2)
2. Mesh the stopper lever (1) with shift cam stopper



3. Pull the shift lever 2 (3) and push shift shaft assembly

4. Install:  
● Plate washer (2)  
● Collar (1)  
(on left side shift shaft)



5. Install:  
● O-rings (4)  
● Oil pump assembly (3)




7 Nm (0.7 m·kg, 5.1 ft·lb)

- Oil pump driven gear (2)  
● Circlip (1)




## CLUTCH


- |                        |                       |
|------------------------|-----------------------|
| 1. Plate washer        | 8. Clutch plate       |
| 2. Oil seal            | 9. Clutch boss spring |
| 3. Circlip             | 10. Spring seat       |
| 4. Lock washer         | 11. Thrust plate      |
| 5. Clutch plate (#1)   | 12. Bearing           |
| 6. Friction plate (#1) | 13. Pull rod          |
| 7. Wire clip           | 14. Match mark        |



# 3



1. Install:
  - Clutch housing (5)
  - Thrust washer (4)
  - Clutch boss (3)
  - Lock washer (2)
  - Nut (1)




2. Tighten:
  - Nut (1)
 Use Universal Clutch Holder (2)  
(90890-04046)



70 Nm (7.0 m·kg, 50 ft·lb)

Bend lock washer tab against nut flat.


3




3. Install:
  - Friction plates
  - Clutch plates

**NOTE:**

- Mount friction and clutch plates alternately.
- Align the clutch plate mark (1) as shown.



4. Install:
  - Thrust bearing (2)
  - Plate washer (3)  
(on the pull rod)
  - Pull rod (1)  
(into the pressure plate)




5. Install:
  - Pressure plate (4)
  - Spring (3)
  - Plate washer (2)
  - Bolt (1)




8 Nm (0.8 m·kg, 5.8 ft·lb)





### NOTE:

Align the pressure plate mark (1) with the clutch boss mark (2).




### 6. Install:

- Gasket (3)
- Dowels (2)
- Right crankcase cover (1)



10 Nm (1.0 m·kg, 7.2 ft·lb)


# 3



### NOTE:

Be sure the pull rod gear (1) face to rear of engine.


(2) upper



## PICK UP COIL, GENERATOR AND STARTER MOTOR

### 1. Install:

- Starter motor



### 2. Install:

- Rotor
  - Bolt (1)
- Use Rotor Holding Tool (90890-04067) (2)



35 Nm (3.5 m·kg, 25 ft·lb)






3. Install:
- Stator coil ①

**NOTE:**

Align the stator core grooves with the bolt holes.




4. Install:
- Generator cover ②
  - Pick up coil assembly ①



Coil screw:  
8 Nm (0.8 m·kg, 5.8 ft·lb)

3




5. Install:
- Timing plate ①
  - Screw




24 Nm (2.4 m·kg, 17 ft·lb)

Mesh the timing plate groove ② with the crankshaft pin ③.



6. Clamp the A.C.G. leads and pick up leads.




### PISTON AND INTAKE SIDE CAM CHAIN GUIDE

#### 1. Install:

- Intake side cam chain guide (4)
- Stopper shaft (3)
- Spring (2)
- Plate washer
- Bolt (1)

#### NOTE:

The lower end of chain guide must rest in the cam chain guide slot in the crankcase.




#### 2. Install:

- Piston rings

#### NOTE:

Be sure to install rings so that Manufacturer's marks or numbers are located on the top side of the rings. Oil the pistons and rings liberally.





#### 3. Install:

- Piston pin
- Piston
- Piston pin Circlip (New)



#### NOTE:

- Be sure the piston arrow mark (1) face to exhaust side.
- Before installing piston pin circlip, cover crankcase with a clean rag to prevent circlip from falling into crankcase cavity.
- Be sure the marked piston numbers (2) should be in sequence (1,2,3,4) beginning from the left.





3



## CYLINDER

## 1. Install:

- Dowels ①
- O-rings ②
- Cylinder gasket ③

## 2. Oil liberally:

- Piston
- Rings
- Cylinders

## 3. Set:

- Top ring end ①
- Oil ring end (Lower) ②
- Oil ring end (Upper) ③
- 2nd ring end ④

## 4. Install:

- Cylinder  
Use Piston Ring Compressor ① (90890-04047) and Piston Base ② (90890-01067) Pass the cam chain and exhaust side cam chain guide through cam chain cavity.

## 5. Tighten:

- Cylinder nut ③



20 Nm (2.0 m·kg, 14 ft·lb)

## 6. Install:


- Front engine mount spacer ②
- Damper ①




### CYLINDER HEAD AND CAMSHAFT

#### CYLINDER HEAD


- |                  |                |
|------------------|----------------|
| 1. Washer        | 5. Valve guide |
| 2. Rubber washer | 6. Circlip     |
| 3. Gasket        | 7. Stud bolt   |
| 4. Spark plug    |                |



# 3




1. Install:
  - Dowels ①
  - O-rings ②
  - Head gasket ③ (New)
  - Cylinder head



2. Tighten:
  - Cylinder head nuts
 In sequence as shown and torque nuts in two stages.

3



Nut No. ① ~ ⑫:  
22 Nm (2.2 m·kg, 16 ft·lb)  
Nut No. ⑬ ~ ⑯:  
10 Nm (1.0 m·kg, 7.2 ft·lb)




NOTE: \_\_\_\_\_  
※ Use copper washers.




## CAMSHAFT

- |                          |                              |                         |
|--------------------------|------------------------------|-------------------------|
| 1. Cam chain             | 9. Guide stopper plate       | 17. Inner spring        |
| 2. Cam sprocket          | 10. Upper chain guide        | 18. Outer spring        |
| 3. Camshaft (Exhaust)    | 11. Exhaust side chain guide | 19. Spring seat         |
| 4. Camshaft (Intake)     | 12. Intake side chain guide  | 20. Oil seal            |
| 5. Chain tensioner body  | 13. Adjusting pad            | 21. Valve               |
| 6. Tensioner lock bolt   | 14. Valve lifter             | 22. Chain guide stopper |
| 7. Tensioner rod (Large) | 15. Valve retainer           | 23. Match mark          |
| 8. Tensioner rod (Small) | 16. Spring seat              |                         |




| A VALVE CLEARANCE (COLD): |         |                                      |
|---------------------------|---------|--------------------------------------|
| B                         | Intake  | 0.11 ~ 0.15 mm<br>(0.004 ~ 0.006 in) |
|                           | Exhaust | 0.16 ~ 0.20 mm<br>(0.006 ~ 0.008 in) |



3




1. Rotate:
  - Crankshaft
  - Counter clockwise.



2. Align:
  - "T" mark ①
 On the timing plate with the upper pick up coil mark ② when No. 1 piston is at TDC on compression stroke.


③ Lower pickup coil mark



3. Install:
  - Cam chain sprockets (on the camshafts)
  - "I" and "E" camshafts
 Apply engine oil to camshaft bearing surfaces before installing camshafts.
4. Remove:
  - Retaining wire ①

#### NOTE:

- "I" mark ① for intake camshaft
- "E" mark ② for exhaust camshaft
- Make sure the timing mark ③ on the camshaft faces upward.



5. Install:
  - Cam caps




10 Nm (1.0 m·kg, 7.2 ft·lb)

#### NOTE:

Do not install No. 3 intake (I-3) and No. 3 exhaust (E-3) cam caps at in this stage.



**CAUTION:**

The cam caps must be tightened evenly or damage to the cylinder head, cam caps and cam will result. The spaces between the caps and cylinder head should be equal.

**Cam Chain**

1. Rotate:
  - Exhaust camshaft
2. Align:
  - Exhaust camshaft timing mark  
(with the "E-2" cam cap arrow mark)

**CAUTION:**

Do not rotate the camshaft over 1/2 turn or damage to the piston and valve will result.

3. Position:
  - Cam chain  
(onto sprockets)
4. Install:
  - Sprockets  
(onto camshafts)
5. Force the exhaust sprocket clockwise (viewing from left side engine) to remove all cam chain slack.
6. Align:
  - Sprocket, hole  
(with the exhaust camshaft thread hole)


**NOTE:**

If the sprocket hole do not align with the camshaft hole, Adjust chain links between crankshaft and exhaust camshaft.

7. Install:
  - Exhaust sprocket bolt  
(temporarily tighten)

**3**





8. Rotate:
  - Intake camshaft
9. Align:
  - Intake camshaft timing mark ①  
(with the "I-2" cam cap arrow mark ②)

- ③ Exhaust camshaft timing mark
- ④ "E-2" cam cap arrow mark

**CAUTION:**

Do not rotate the camshaft over 1/2 turn or damage to the piston and valve will result.

10. Force the intake sprocket clockwise (viewing from left side engine) to remove all cam chain slack.


3

11. Align:
  - Intake sprocket hole  
(with the intake camshaft thread hole)


**NOTE:**

If the sprocket hole do not align with the camshaft thread hole, Adjust chain links between exhaust and intake camshafts.

12. Install:
  - Intake sprocket bolt  
(temporarily tighten)

**NOTE:**

- Be sure the camshaft timing warks ① align with the cam cap arrow mark ②
- Be sure the "T" mark on the timing plate align with the upper pickup coil mark.




## 13. Rotate:

- Crankshaft  
Counterclockwise

## 14. Align:

- Timing plate "C" mark ①  
(with the upper pickup coil mark ②)

3



## 15. Install:

- Exhaust side chain guide ②
- Chain guide stopper ①
- Bolt
- Lock washer

## 16. Bend the lock washer tab against bolt flat.



## 17. Install:

- Upper chain guide ①



## 18. Install:

- Cam chain tensioner ①



10 Nm (1.0 m·kg, 7.2 ft·lb)

## 19. Loosen

- Locknut ②
- Tensioner lock bolt ③



## 20. Tighten:


- Tensioner lock bolt
- Locknut

**Bolt:**

8 Nm (0.8 m·kg, 5.8 ft·lb)

**Locknut:**

9 Nm (0.9 m·kg, 6.5 ft·lb)

**Cam Chain Tensioner Installation Steps:**


- Install the spring (4), large tensioner rod (3), Damper (2), Small spring (4), and small tensioner rod (1) into the tensioner body (6).
- Push the tensioner rod assembly into the body

**NOTE:**

Face the large rod flat surface to the lock bolt 7.

- Tighten lock bolt.
- Lock the locknut.

## 5. Gasket



## 21. Rotate:

- Crankshaft  
Counterclockwise

## 22. Install:


- Sprocket bolts (1) (all)



24 Nm (2.4 m·kg, 18 ft·lb)

**NOTE:**


- Be sure the camshaft timing marks ① align with the cam cap arrow mark ②
- Be sure the "T" mark on the timing plate align with the upper pick up coil mark.

**13. Rotate:**


- Crankshaft Counterclockwise

**14. Align:**

- Timing plate "C" mark ① (with the upper pickup coil mark ②)

**15. Install:**

- Exhaust side chain guide ②
- Chain guide stopper ①
- Bolt
- Lock washer

**16. Bend the lock washer tab against bolt flat.****17. Install:**

- Upper chain guide ①

**18. Install:**

- Cam chain tensioner ①



10 Nm (1.0 m·kg, 7.2 ft·lb)

**19. Loosen**

- Locknut ②
- Tensioner lock bolt ③



## 20. Tighten:


- Tensioner lock bolt
- Locknut

**Bolt:**

8 Nm (0.8 m·kg, 5.8 ft·lb)

**Locknut:**

9 Nm (0.9 m·kg, 6.5 ft·lb)



3

**Cam Chain Tensioner Installation Steps:**


- Install the spring (4), large tensioner rod (3), Damper (2), Small spring (1), and small tensioner rod (1) into the tensioner body (6).
- Push the tensioner rod assembly into the body

**NOTE:**

Face the large rod flat surface to the lock bolt 7.

- Tighten lock bolt.
- Lock the locknut.

## 5. Gasket



## 21. Rotate:


- Crankshaft  
Counterclockwise

## 22. Install:

- Sprocket bolts (1) (all)



24 Nm (2.4 m·kg, 18 ft·lb)



23. Install:

- No. 3 intake cam cap
- No. 3 exhaust cam cap



**Cam Bolt:**  
10 Nm (1.0 m·kg, 7.2 ft·lb)

24. Install:

- Left crankcase cover



**Screw:**  
10 Nm (1.0 m·kg, 7.2 ft·lb)

25. Install:

- Spark plug ②



17.5 Nm (1.75 m·kg, 12.7 ft·lb)

- Head cover gasket
- Head cover ①




**Bolt:**  
10 Nm (1.0 m·kg, 7.2 ft·lb)

**3**



## REMounting ENGINE


1. Refer to engine removal. Reverse those removal steps that apply.



2. Tighten:
  - Engine mounting bolts



Front Upper Bolts ① :  
42 Nm (4.2 m·kg, 30 ft·lb)  
Front Bracket Bolt ② :  
32 Nm (3.2 m·kg, 23 ft·lb)  
Front Lower Bolts ③ :  
42 Nm (4.2 m·kg, 30 ft·lb)  
Rear Bolts ④ :  
90 Nm (9.0 m·kg, 65 ft·lb)



3. Tighten:



Spacer Nut ③ :  
50 Nm (5.0 m·kg, 36 ft·lb)  
Oil Filter Clamp Nut ② :  
10 Nm (1.0 m·kg, 7.2 ft·lb)  
Oil Filter Bolt ① :  
15 Nm (1.5 m·kg, 11 ft·lb)

4. Tighten:




Drive Chain Sprocket Bolt:  
10 Nm (1.0 m·kg, 7.2 ft·lb)

5. Tighten:



Footrest Bracket Bolt:  
25 Nm (2.5 m·kg, 18 ft·lb)  
Exhaust Pipe Clamp Bolt:  
20 Nm (2.0 m·kg, 14 ft·lb)  
Exhaust Pipe Nut:  
10 Nm (1.0 m·kg, 7.2 ft·lb)



## 6. Measure:

- Change pedal height ①



**Standard Change Pedal Height:**  
15 mm (0.6 in)  
from the rear engine mounting  
bolt ④.

**Adjustment steps:**

- Loosen the locknut ② and turn the rod ③ in or out until proper pedal height is achieved.
- Lock the locknut



**Locknut:**  
10 Nm (1.0 m·kg, 7.2 ft·lb)

3



## 7. Adjust:

- Drive chain deflection ①



**Standard Drive Chain Deflection ①:**  
20 ~ 30 mm (0.8 ~ 1.2 in)

## 8. Tighten:



**Rear Axle Nut:**  
105 Nm (10.5 m·kg, 75 ft·lb)

## 9. Fill:

- Crankcase



**Engine Oil:**  
3.0 L (2.6 Imp qt, 3.2 US qt)





## CARBURETOR

- |                     |                         |
|---------------------|-------------------------|
| 1. Jet needle cover | 10. Main jet            |
| 2. Set spring       | 11. Float               |
| 3. Jet needle       | 12. Float plin          |
| 4. Piston valve     | 13. Drain screw         |
| 5. Starter plunger  | 14. Float valve         |
| 6. Main nozzle      | 15. Synchronizing screw |
| 7. Starter lever    | 16. O-ring              |
| 8. Pilot jet        | 17. Pilot air jet       |
| 9. Main jet washer  | 18. Throttle stop screw |


**CAUTION:**


The pilot screw settings are adjusted for maximum performance at the factory. Any attempt to change these settings will decrease engine performance.

## SPECIFICATIONS

|                              |                                  |
|------------------------------|----------------------------------|
| Main jet                     |                                  |
| For No. 1 and No. 2 Cylinder | # 105                            |
| For No. 3 and No. 4 Cylinder | # 102.5                          |
| Jet needle                   |                                  |
| No. 1, 3 and 4 Cylinder      | 4CP3-3                           |
| No. 2 Cylinder               | 4CP7-3                           |
| Needle jet                   | N-8                              |
| Starter jet                  | # 42.5                           |
| Fuel level                   | 3.0 ± 1.0 mm<br>(0.12 ± 0.04 in) |
| Pilot screw                  | 2-1/2 turns out                  |
| Float valve seat             | φ2.0                             |
| Engine idle speed            | 1200 ± 50 r/min                  |

4






### SECTION VIEW

- ① Throttle valve
- ② Pilot screw
- ③ Pilot jet
- ④ Main jet
- ⑤ Main nozzle
- ⑥ Jet needle
- ⑦ Vacuum piston
- ⑧ Pilot air jet
- ⑨ Main air jet

### Removal

1. Remove:
  - Carburetor assembly
 Refer to engine removal section.




### DISASSEMBLY


#### NOTE:

The following parts can be cleaned and inspected without carburetor separation.


- Piston valve
- Starter plunger
- Float chamber components

1. Remove:
  - Starter lever shaft
2. Remove:
  - Upper bracket ①
  - Lower bracket ②







3. Remove:
- Vacuum chamber cover (1)
  - Spring (2)
  - Vacuum piston assembly (3)




4. Remove:
- Jet needle cover (1)
  - Jet spring (2)
  - Jet needle (3)



5. Remove:
- Float chamber cover
  - Gasket
  - Float pin (1)
  - Float (2)
  - Valve seat plate (3)
  - Valve seat assembly (4)



6. Remove:
- Main jet (1)
  - Washer (2)
  - Pilot jet (3)
  - Main nozzle (4)



7. Remove:
- Starter plunger (1)
  - Pilot air jet (2)

**4**

**INSPECTION**

1. Inspect:
  - Carburetor body
  - Fuel passage
 Contamination → Clean as indicated.

**Carburetor cleaning steps:**

- Wash carburetor in petroleum based solvent. (Do not use any caustic carburetor cleaning solution).
- Blow out all passages and jets with compressed air.



2. Inspect:
  - Floats
 Damage → Replace.


3. Inspect:
  - Float needle valve ①
  - Seat ②
  - O-ring ③
 Damage/Wear/Contamination → Replace as a set
  - Vacuum piston
  - Rubber diaphragm
 Scratches (piston)/Tears (diaphragm) → Replace.

4. Inspect:
  - Jet needle
 Bends/Wear → Replace.

5. Inspect:
  - Starter plunger
 Wear/Damage → Replace.

4



**ASSEMBLY**

Reverse disassembly steps. Pay close attention to installation of vacuum piston diaphragm and location of each jet.

## 1. Install:


- Main nozzle (4)
- Pilot jet (3)
- Washer (2)
- Main jet (1)

## 2. Install:

- Vacuum piston

**NOTE:**

Note position of tab (1) on diaphragm. This tab must be placed in the cavity of the carburetor body during reassembly.

**FUEL LEVEL ADJUSTMENT**

## 1. Measure:

- Fuel level (1)


**Fuel level inspection steps:**

- Install Fuel Level Gauge Adapter (2) (90890-01329).
- Connect Fuel Level Gauge (3) (90890-01312) or vinyl tube, 6 mm (0.24 in) inside diameter, to Adapter.
- Place tube vertically next to the center of the mating line of the mixing body and float chamber cover.
- Set fuel cock to "ON".
- Loosen the drain screw (4).
- Warm up the engine, then shut it off after a few minutes.
- Check the fuel level. It should be within the specified range.

**Fuel Level:**

$3.0 \pm 1.0$  mm ( $0.12 \pm 0.04$  in)  
above the carburetor body.

Out of range → Follow next steps.

**NOTE:**

Fuel level readings of both side of carburetor line should be equal.

2. Remove:
  - Carburetors


3. Inspect:
  - Float valve assembly
  - Float

Damage → Replace.  
Components OK → Adjust float height by bending float arm tang ① slightly.

**4**

4. Observe:
  - Fuel level

Level should be within specified range.
5. Repeat these steps for the other carburetor.



### AIR CLEANER AND CRANKCASE VENTILATION SYSTEM

REFER TO "CHAPTER 2, Air Cleaner Maintenance."

- ① Carburetor
- ② Air cleaner
- ③ Blow-by gas
- ④ Fresh air


**CHASIS**



**FRONT WHEEL**

- |                  |                        |
|------------------|------------------------|
| 1. Front axle    | 7. Bearing             |
| 2. Collar        | 8. Meter clutch        |
| 3. Oil seal      | 9. Clutch retainer     |
| 4. Bearing       | 10. Oil seal           |
| 5. Spacer        | 11. Gear unit assembly |
| 6. Spacer flange |                        |

| TIRE AIR PRESSURE (COLD):         |   |   |
|-----------------------------------|---|---|
| Basic weight:                     | 208 kg (459 lb)                               |   |
| With oil and full fuel tank       |   |   |
| Maximum load*                     | 188 kg (414 lb)                               |   |
| Cold tire pressure                | Front   | Rear  |
| Up to 90 kg (198 lb) load*        | 177 kPa<br>(1.8 kg/cm <sup>2</sup><br>26 psi) | 196 kPa<br>(2.0 kg/cm <sup>2</sup><br>28 psi) |
| 90 kg (198 lb) ~<br>Maximum load* | 196 kPa<br>(2.0 kg/cm <sup>2</sup><br>28 psi) | 226 kPa<br>(2.3 kg/cm <sup>2</sup><br>32 psi) |
| High speed riding                 | 196 kPa<br>(2.0 kg/cm <sup>2</sup><br>28 psi) | 226 kPa<br>(2.3 kg/cm <sup>2</sup><br>32 psi) |

\* Load is the total weight of cargo, rider, passenger, and accessories.



**REMOVAL**

1. Place the motorcycle on its centerstand.
2. Remove:
  - Speedometer cable (1)
  - Brake caliper (2)


3. Loosen:
  - Pinch bolt (1)
4. Remove:
  - Axle
  - Front wheel

**CAUTION:**

Make sure the motorcycle is properly supported.

**NOTE:**


Do not depress the brake lever when the wheel is off the motorcycle otherwise the brake pads will be forced shut.

**INSPECTION**

1. Eliminate any corrosion from parts.
2. Inspect:
  - Front axle
 Roll the axle on a Flat Surface.  
 Bends → Replace.

**WARNING:**

Do not attempt to straighten a dent axle.





3. Inspect:
  - Wheel
 Cracks/Bends/Warp → Replace.
4. Measure:
  - Wheel runout
 Over specified limit → Replace, wheel or check bearing play (3).

**Rim Runout Limits:**

Radial (1) : 2.0 mm (0.08 in)  
 Lateral (2) : 2.0 mm (0.08 in)





## 5. Check:

## ● Wheel balance

Wheel is not statically balanced if it comes to rest at the same point after several light rotations.

Out of balance → Install appropriate balance weight at lightest point (on top).

**NOTE:**

- Balance wheel with brake disc installed.


**WARNING:**

- After mounting a tire, ride conservatively to allow proper tire to rim seating. Failure to do so may cause an accident resulting in motorcycle damage and possible operator injury.
- After a tire repair or replacement, be sure to torque tighten the valve stem locknut ① to specification.



**Valve-Stem Locknut:**  
1.5 Nm (0.15 m·kg, 1.1 ft·lb)

5

**WHEEL BEARING REPLACEMENT**

## 1. Inspect:

## ● Wheel bearings

Wheel hub play/Wheel turns roughly → Replace.

**Wheel bearing replacement steps:**

- Clean wheel hub exterior.
- Drive bearing out by pushing spacer aside and tapping around perimeter of bearing inner race. Use soft metal drift punch and hammer. The spacer ① "floats" between bearings. Remove both bearings as described.

**WARNING:**

Eye protection is recommended when using striking tools.

- To install the wheel bearing, reverse the above sequence. Use a socket that matches outside diameter of bearing outer race to drive in bearing.

**CAUTION:**

Do not strike the center race or balls of bearing. Contact should be made only with the outer race.





## INSTALLATION

## 1. Install

- Front wheel

Reverse removal procedure.

**Front wheel installation points:**

- Lightly grease lips of front wheel oil seals and gear teeth of speedometer drive and driven gears.
- Install speedometer cable holder securing bolt.
- Be sure the two projections inside the wheel hub are meshed with the two slots in the speedometer housing.
- Be sure that the projecting portion (torque stopper ①) of the speedometer housing is positioned correctly.
- Tighten the axle.

**Axle:**

**105 Nm (10.5 m·kg, 75 ft·lb)**

- Tighten the axle pinch bolt.

**Axle Pinch Bolt:**

**20 Nm (2.0 m·kg, 14 ft·lb)**

- Tighten the brake caliper bolt.

**Brake Caliper Bolt:**

**35 Nm (3.5 m·kg, 25 ft·lb)**

### REAR WHEEL

- |                  |               |
|------------------|---------------|
| 1. Axle          | 7. Bearing    |
| 2. Chain puller  | 8. Clutch hub |
| 3. Oil seal      | 9. Collar     |
| 4. Bearing       | 10. Bearing   |
| 5. Spacer flange | 11. Oil seal  |
| 6. Spacer        | 12. Collar    |

105 Nm (10.5 m·kg, 75 ft·lb)

G USE A NEW ONE

|   |                  |
|---|------------------|
| A | TIRE SIZE:       |
|   | 110/90-18 61H    |
| B | WEAR LIMIT:      |
|   | 0.8 mm (0.03 in) |

SD 25-47



6303

1.5 Nm (0.15 m·kg, 1.1 ft·lb)

6303 DDU

SD-32-52

|   |                     |
|---|---------------------|
| C | WHEEL SIZE:         |
|   | MT 2.50 x 18        |
| D | WHEEL RUNOUT LIMIT: |
| E | Vertical            |
|   | 2.0 mm (0.08 in)    |
| F | Lateral             |
|   | 2.0 mm (0.08 in)    |



## REMOVAL

1. Place the motorcycle on its centerstand.
2. Remove:
  - Brake caliper

3. Remove:
  - Cotter pin ①
  - Axle nut ②
  - Axle ③
  - Chain puller ④
  - Collar ⑤
  - Drive chain
  - Rear wheel

## INSPECTION

1. Rear Axle  
Refer to "Front Axle Inspection"
2. Wheel Runout  
Refer to "Front Wheel Runout"
3. Wheel Balance  
Refer to "Front Wheel Balance"
4. Wheel Bearing Replacement  
Refer to "Front Wheel Braring Replacement"



## REAR WHEEL

- |                  |               |
|------------------|---------------|
| 1. Axle          | 7. Bearing    |
| 2. Chain puller  | 8. Clutch hub |
| 3. Oil seal      | 9. Collar     |
| 4. Bearing       | 10. Bearing   |
| 5. Spacer flange | 11. Oil seal  |
| 6. Spacer        | 12. Collar    |

105 Nm (10.5 m·kg, 75 ft·lb)

G USE A NEW ONE

|   |                  |
|---|------------------|
| A | TIRE SIZE:       |
|   | 110/90-18 61H    |
| B | WEAR LIMIT:      |
|   | 0.8 mm (0.03 in) |

SD 25-47



6303

1.5 Nm (0.15 m·kg, 1.1 ft·lb)

6303 DDU

SD-32-52

|   |                     |
|---|---------------------|
| C | WHEEL SIZE:         |
|   | MT 2.50 x 18        |
| D | WHEEL RUNOUT LIMIT: |
|   | Vertical            |
| E | 2.0 mm (0.08 in)    |
| F | Lateral             |
|   | 2.0 mm (0.08 in)    |



## REMOVAL

1. Place the motorcycle on its centerstand.
2. Remove:
  - Brake caliper

3. Remove:
  - Cotter pin ①
  - Axle nut ②
  - Axle ③
  - Chain puller ④
  - Collar ⑤
  - Drive chain
  - Rear wheel


## INSPECTION

1. Rear Axle  
Refer to "Front Axle Inspection"
2. Wheel Runout  
Refer to "Front Wheel Runout"
3. Wheel Balance  
Refer to "Front Wheel Balance"
4. Wheel Bearing Replacement  
Refer to "Front Wheel Bearing Replacement"



## REAR WHEEL

1. Axle
2. Chain
3. Drive
4. Spring
5. Tire
6. Rim



## INSTALLATION

## 1. Install:

- Rear wheel
- Reverse removal procedure.

## Rear wheel installation points:

- Lightly grease lips of rear wheel oil seals and bearings.
- Be sure that the projecting portion (torque stopper ①) of rear arm is meshed with caliper bracket.
- Adjust drive chain.
- Tighten



## Axle:

105 Nm (10.5 m·kg, 75 ft·lb)

## Brake Caliper Bolts:


35 Nm (3.5 m·kg, 25 ft·lb)

- Always use a new cotter pin on the axle nut.

## FRONT BRAKE

- |                            |                        |
|----------------------------|------------------------|
| 1. Retaining clips         | 6. Brake disc          |
| 2. Air bleed screw         | 7. Master cylinder kit |
| 3. Caliper piston assembly | 8. Joint               |
| 4. Pad spring              | 9. Copper washer       |
| 5. Brake pad               | 10. Union bolt         |

\* Install the pad spring with its longer tangs in the disc rotation direction.



# 5




**CAUTION:**

Disc brake components rarely require disassembly. **DO NOT:**

- Disassembly components unless absolutely necessary.
- Use solvents on internal brake component.
- Use contaminated brake fluid for cleaning. Use only clean brake fluid.
- Allow brake fluid to come in contact with the eyes otherwise eye injury may occur.
- Allow brake fluid to contact painted surfaces or plastic parts otherwise damage may occur.
- Disconnect any hydraulic connection otherwise the entire system must be disassembled, drained, cleaned, and then properly filled and bled after reassembly.

**NOTE:**

Drain the brake fluid before removing brake hose.

**CALIPER PAD REPLACEMENT**

It is not necessary to disassemble brake caliper and brake hose to replace brake pads.

**1. Remove:**


- Cover
- Retaining clips ①
- Retaining pins ②
- Pad spring ③
- Pads ④

**2. Install:**

- Pads
- Reverse removal steps.

**NOTE:**


- Install the pad spring with its longer tangs ⑤ facing upwards.
- Replace pads as a set if either is found to be worn to the wear limit.

**CALIPER DISASSEMBLY**


1. Remove:
  - Brake hose ①
  - Caliper securing bolts ②
  - Brake pads
2. Remove:
  - Caliper piston assembly
 Use compressed air and procede carefully.

**WARNING:**

- Cover piston with rag and use extreme caution when expelling piston from cylinder.
- Never attempt to pry out piston.

**MASTER CYLINDER DISASSEMBLY**

1. Remove:
  - Brake light leads ①
  - Brake hose ②
  - Brake lever ③ and spring
  - Master cylinder assembly ④



2. Remove:
  - Cap ①
  - Drain remaining fluid
  - Master cylinder dust boot ②
  - Circlip ③
  - Master cylinder cup assembly.

**NOTE:**

Be sure to reinstall the larger diameter lips of the cylinder cups first.

- ④ Master cylinder kit

**INSPECTION AND REPAIR**

**Recommended Brake Component Replacement Schedule**

|                        |                                       |
|------------------------|---------------------------------------|
| Brake pads             | As required                           |
| Piston seal, dust seal | Every 2 years                         |
| Brake hoses            | Every 4 years                         |
| Brake fluid            | Replace only when brakes disassembled |

**1. Inspect:**

- Caliper piston assembly  
Damage/Scratches → Replace.
- Brake pad  
Over wear limit ① → Replace as a set.



**Brake Pad Wear Limit:**  
0.5 mm (0.02 in)

② Wear indicator

**2. Inspect:**

- Master cylinder body  
Scratches → Replace.  
Clean all passages with new brake fluid.
- Brake hoses  
Cracks/Frayed/Damage → Replace.


**3. Inspect:**

- Brake disc ②  
Wear/Deflection out of specification → Replace.




**Maximum Deflection:**  
0.15 mm (0.006 in)  
**Minimum Disc Thickness:**  
4.0 mm (0.16 in)

① Dial gauge



**5**



## ASSEMBLY

## Caliper

## NOTE:

- All internal parts should be cleaned in new brake fluid only.
- Internal parts should be lubricated with brake fluid when installed.
- Replace the piston and dust seals whenever the caliper is disassembled.

## 1. Install:

- Caliper piston assembly
- Brake pads
- Caliper assembly

## 2. Tighten:

- Caliper securing bolts ①



35 Nm (3.5 m·kg, 25 ft·lb)

- Brake hose ② union bolts



26 Nm (2.6 m·kg, 19 ft·lb)



## Master Cylinder

## 1. Assemble:

- Master cylinder



Union Bolt ① :  
26 Nm (2.6 m·kg, 19 ft·lb)  
Master Cylinder Holding Bolt ② :  
8.5 Nm (0.85 m·kg, 6.1 ft·lb)



- ③ Copper washer
- ④ Master cylinder kit

**AIR BLEEDING****WARNING:**

Bleed the brake system if:

- The system has been disassembled.
- A brake hose has been loosened or removed.
- The brake fluid is very low.
- The brake operation is faulty.

A dangerous loss of braking performance may occur if the brake system is not properly bled.

**Air bleeding steps:**

- Add proper brake fluid to the reservoir.
- Install diaphragm.  
Be careful not to spill any fluid or allow the reservoir to over flow.
- Connect the clear plastic tube (4.5 mm, 3/16 in inside dia.) tightly to the caliper bleed screw ①.
- Place the other end of the tube into a container.
- Slowly apply the brake lever or pedal several times.
- Pull the lever in or push down on the pedal. Hold the lever or pedal in position.
- Loosen the bleed screw and allow the lever or pedal to travel towards its limit.
- Tighten the bleed screw when the lever or pedal limit has been reached; then release the lever or pedal.
- Repeat steps (e) to (h) until the air bubbles have been removed from the system.

**NOTE:**


If bleeding is difficult, it may be necessary to let the brake fluid system stabilize for a few hours. Repeat the bleeding procedure when the tiny bubbles in system have disappeared.

## REAR BRAKE

1. Brake pad
2. Pad spring
3. Retaining clips
4. Bleed screw
5. Caliper piston assembly
6. Brake disc

7. Master cylinder kit
8. Copper washer
9. Union bolt

- \* Install the pad spring with its longer tangs in the disc rotation direction.



# 5

**CAUTION:**

Disc brake components rarely require disassembly. **DO NOT:**

- Disassembly components unless absolutely necessary.
- Use solvents on internal brake component.
- Use contaminated brake fluid for cleaning. Use only clean brake fluid.
- Allow brake fluid to come in contact with the eyes otherwise eye injury may occur.
- Allow brake fluid to contact painted surfaces or plastic parts otherwise damage may occur.
- Disconnect any hydraulic connection otherwise the entire system must be disassembled, drained, cleaned, and then properly filled and bled after reassembly.

**NOTE:**

Drain the brake fluid before removing brake hose.

**CALIPER PAD REPLACEMENT**

Refer to "Front Brake Pad Replacement"


**CALIPER DISASSEMBLY**

Refer to "Front Caliper Disassembly"

1. Remove:
  - Brake hose ①
  - Caliper securing bolts ②
  - Brake pads
2. Remove:
  - Caliper piston assemblyUse compressed air and proceed carefully.

**WARNING:**


- Cover piston with rag and use extreme caution when expelling piston from cylinder.
- Never attempt to pry out piston.





## MASTER CYLINDER DISASSEMBLY

1. Remove:
  - Footrest bracket
2. Loosen:
  - Locknut ①
3. Remove
  - Brake hose ②
  - Master cylinder assembly ③
4. Remove:
  - Master cylinder kit (from master cylinder body)



## INSPECTION AND REPAIR

Refer to "Front Brake Inspection and Repair".

### ASSEMBLY

#### Caliper

Refer to "Front Brake Caliper Assembly".

#### Master Cylinder

1. Assemble:
  - Master cylinder



**Master Cylinder Bolt:**  
20 Nm (2.0 m·kg, 14 ft·lb)


### AIR BLEEDING

Refer to "Front Brake Air Bleeding"



FRONT FORK

- |                      |                              |
|----------------------|------------------------------|
| 1. Rubber cap        | 10. Retaining clip           |
| 2. Cap bolt          | 11. Oil seal                 |
| 3. O-ring            | 12. Washer                   |
| 4. Fork spring       | 13. Bushing                  |
| 5. Damper rod spring | 14. Outer fork tube          |
| 6. Damper rod        | 15. Drain bolt               |
| 7. Inner fork tube   | 16. Damper rod securing bolt |
| 8. Taper spindle     | 17. Front fork brace         |
| 9. Dust cover        |                              |






## REMOVAL AND DISASSEMBLY

**WARNING:**

Support the motorcycle securely so there is no danger of it falling over.




1. Remove:
  - Brake caliper
  - Front wheel
2. Remove:
  - Front fender
  - Front fork brace
  - Rubber cap
3. Loosen:
  - Upper front fork pinch bolts ①
  - Lower front pinch bolts ②

**CAUTION:**

Support the fork before loosening the pinch bolts.

4. Remove:
  - Front fork  
(from steering crown)
5. Tighten
  - Lower front fork pinch bolt
6. Loosen:
  - Cap bolt ①  
Use Front Fork Cap Socket (90890-01104).
  - Lower front fork pinch bolt
7. Remove:
  - Front fork assembly  
(from the underbracket)
8. Remove:
  - Cap bolt
  - Fork spring
  - Dust cover
  - Retaining clip
9. Fill:
  - Fork inner tube  
(with fork oil)  
Stretch the inner tube before filling.
10. Install:
  - Cap bolt



## 11. Remove:

- Oil seal  
(from outer tube.)

Press the inner tube to facilitate removal.

**CAUTION:**

- If air enters the inner tube or it is compressed abruptly oil may spurt out or the oil seal may be ejected.
- Never touch the inner tube during a disassembly operation.
- Be sure to warp the oil seal with a rag for safety.

- ① Wrap with rag
- ② Spacer
- ③ Turn slowly


## 12. Remove:

- Oil seal
- Washer
- Cap bolt

## 13. Drain:


- Fork

5



## 14. Remove:

- Damper rod securing bolt
- Use T-handle ① (90890-01326) and Front Fork Cylinder Holder (90890-01300) ② to lock the damper rod.



## 15. Remove:

- Damper rod
- Damper rod spring
- Inner fork tube
- Guide bushing  
(from outer tube)
- Taper spindle

- ① Pull inner tube from outer tube.



## INSPECTION

## 1. Inspect:

- Inner fork tube  
Severe scratches/Bends → Replace.  
Damaged oil lock valve → Replace.

**WARNING:**

**Do not attempt to straighten a bent fork tube as this may dangerously weaken the tube.**

## 2. Inspect:



- Outer fork tube  
Bends → Replace.  
Damaged fork seal seat → Replace.
- Fork oil seal  
Lip damage → Replace.  
Outer surface damage → Replace.

## 3. Inspect:

- Fork spring ①  
Over specified limit → Replace.



**Fork Spring Free Length Limit:  
510.5 mm (20.1 in)**



## 4. Inspect:

- Damper rod  
Worn damper rod seal ① → Replace.  
Contamination → Wash and blow out all passages.
- Inner fork tube  
Worn inner fork slide bushing ② → Replace.
- Cap bolt O-ring ③  
Damage → Replace.

**ASSEMBLY**

**NOTE:**

Be sure all components are clean before assembly.

**1. Install:**

- Damper rod spring
- Damper rod  
Allow rod to slide slowly down the inner fork tube until it protrudes from the bottom.
- Taper spindle
- Inner fork tube

**2. Install:**


- Damper rod securing bolt  
Hold damper rod with Front Fork Cylinder Holder (90890-01300) and T-handle (90890-01326).




**23 Nm (2.3 m·kg, 17 ft·lb)**  
**LOCTITE®**


**3. Install:**

- Guide bushing ①  
Press guide bushing into the outer fork tube with Fork Seal Driver ② (90890-01367) and Adapter (90890-01370) ③.



**5**






## 4. Install:

- Washer ①
- Fork oil seal ②

Press fork oil seal into the outer fork tube with Fork Seal Driver ③ (90890-01367) and Adapter (90890-01370) ④

## CAUTION:

Be sure oil seal numbered side face upward.



## 5. Install:

- Circlip ①
- Dust seal ②

Use Fork Seal Driver (90890-01367) and Adapter (90890-01370).

## 6. Fill:

- Inner tube (with fork oil)



## Capacity (each):

269 cm<sup>3</sup> (9.46 Imp oz,  
9.11 US oz)


## Type:

SAE 10W30 Type SE Motor Oil

## NOTE:

After filling, slowly pump the fork up and down to distribute oil.

# 5



## 7. Install:

- Fork spring

## NOTE:

Be sure the short pitch ① side face upward.

- Cap bolt (into the inner fork tube)

## 8. Install:

- Front fork assembly (into the underbracket)


## 9. Tighten:

- Lower front fork pinch bolts
- Cap bolt ①



## Cap Bolt:

23 Nm (2.3 m·kg, 17 ft·lb)





## 10. Loosen:

- Lower front fork pinch bolt

## 11. Install:

- Front fork  
(into the steering crown.)

**NOTE:**

Be sure the inner fork tube end is flush with the top of the steering crown.

## 12. Tighten:

- Upper front fork pinch bolt ①
- Lower front fork pinch bolts ②

**Upper Pinch Bolt:**

20 Nm (2.0 m·kg, 14 ft·lb)

**Lower Pinch Bolts:**

23 Nm (2.3 m·kg, 17 ft·lb)

## 13. Continue assembly by reversing of Removal and Disassembly sequence.

Install and torque/tighten each component as specified.

**Disc Brake Caliper:**

35 Nm (3.5 m·kg, 25 ft·lb)

**Front Wheel Axle:**

105 Nm (10.5 m·kg, 75 ft·lb)

**Wheel Axle Pinch Bolt:**


20 Nm (2.0 m·kg, 14 ft·lb)

## STEERING HEAD

- |                       |                        |
|-----------------------|------------------------|
| 1. Handle cover       | 6. Bearing cover       |
| 2. Washer             | 7. Upper bearing races |
| 3. Steering stem bolt | 8. Lower bearing races |
| 4. Handle crown       | 9. Bearing (Upper)     |
| 5. Ring nut           | 10. Bearing (Lower)    |

A

- Tighten to specified torque.
- If steering is binded, loosen the ring nut so that there is no free play on bearing.




5




## ADJUSTMENT

Refer to Chapter 2, "STEERING HEAD ADJUSTMENT".

## REMOVAL



1. Remove:
  - Headlight
  - Cowling
  - Cowling stay ①
2. Disconnect:
  - Flasher light leads ②




3. Remove:
  - Horn securing bolt ①
  - Brake hose joint securing bolt ②
4. Disconnect:
  - Horn leads ③

**5**




5. Remove:
  - Front wheel
  - Fender
  - Front fork brace
  - Front fork ①
 Refer to "FRONT FORK".

6. Disconnect:
  - Throttle cable
  - Starter cable
  - Clutch cable



7. Remove:
  - Meter panel securing bolts (1)
  - Steering stem bolt (2)
  - Handlebar and steering crown assembly



8. Remove:
  - Ring nut (1)
  - Use Ring Nut Wrench (2) (90890-01268)
  - Bearing cover
  - Bearing
  - Steering stem (3)

### INSPECTION

1. Check:
  - Bearing
  - Pitting/Damage → Replace races and bearing.

### ASSEMBLY

1. Lubricate:
  - Bearings




Wheel Bearing Grease



2. Install:
  - Lower bearing (onto steering stem)
  - Steering stem
  - Upper bearing

Lower & Upper Bearing  
19 P.C.S/¼ in



3. Install:
  - Bearing cover
  - Ring nut

4. Tighten:
  - Ring nut ①



38 Nm (3.8 m·kg, 27 ft·lb)

5. Install:
  - Steering crown
  - Handlebar assembly
  - Steering stem bolt
  - Meter panel assembly

6. Position:
  - Front fork (into steering crown)

This will facilitate alignment of under bracket holes with steering crown holes.



7. Tighten:
  - Steering stem nut ①



54 Nm (5.4 m·kg, 39 ft·lb)

8. Continue assembly by reversing removal sequence.

9. Check:
  - Steering head operation

Turn it from lock to lock.

Looseness/Binding → Readjust tightness of steering stem.

5

## REAR SHOCK ABSORBER/REAR ARMS


- |                              |                    |
|------------------------------|--------------------|
| 1. Spring preload match mark | 7. Arm 2           |
| 2. Thrust cover              | 8. Relay arm       |
| 3. Bushing                   | 9. Dust cover      |
| 4. Oil seal                  | 10. Pulley bracket |
| 5. Collar                    | 11. Pulley         |
| 6. Arm 1                     |                    |


### SPRING PRELOAD ADJUSTMENT:

|                    | H |   |   | STD | S |
|--------------------|---|---|---|-----|---|
| Adjusting position | 5 | 4 | 3 | 2   | 1 |

### NOTE:


Coat the bushings, thrustwashers, dust seals, and bolts with a liberal amount of molybdenum disulfide grease before installing. After installing, thoroughly wipe off excess grease.





**REMOVAL**

1. Remove:
  - Mufflers (Left and right)
2. Remove:
  - Shock absorber lower securing bolt ①
  - Thrust covers
  - Collars




3. Remove:
  - Battery  
(Refer to "ENGINE REMOVAL")
  - Seat
  - Battery case ①




4. Remove:
  - Pulley bracket ①
  - Shock absorber upper securing bolt ②
  - Shock absorber
  - Adjusting belt ③

**5**




5. Remove:
  - Relay arm ①
  - Thrust covers
  - Collar
6. Remove:
  - Arm securing bolt ②
  - Screws ③
  - Thrust covers ④




## INSPECTION


1. Inspect:
  - Rear shock absorber  
Oil leaks/Damage → Replace.
  - Dust cover ①  
Damage → Replace.



2. Inspect:
  - Arm ①
  - Thrust cover ②  
Damage/Wear → Replace



3. Inspect:
  - Relay arm ①
  - Collar ②
  - Thrust cover ③  
Damage/Wear → Replace.



4. Inspect:
  - Adjusting belt
  - Adjusting belt pulley ①  
Wear/Damage → Replace

### INSTALLATION

Reverse removal steps.

- Grease the bushing and dust seals.



**Molybdenum Grease**

- Install:
  - Relay arm



**Relay Arm/Frame:**  
65 Nm (6.5 m·kg, 47 ft·lb)

#### NOTE:

The relay arm should be installed so that the "UP" mark ① on the arm faces upward.

- Install:
  - Arms (on swingarm)



**Arm Screw:**  
40 Nm (4.0 m·kg, 29 ft·lb)

- Arm securing bolts



**20 Nm (2.0 m·kg, 14 ft·lb)**


- Install:
  - Rear shock absorber assembly




**Upper: 40 Nm (4.0 m·kg, 29 ft·lb)**  
**Lower: 65 Nm (6.5 m·kg, 47 ft·lb)**

#### NOTE:

Be sure the "YAMAHA" mark ② faces shock absorber upper boss center ③.



**5**



① Front




5. Pull the pulley ① by a force of 20 kg (44 lb) using a spring scale.
6. Tighten:
  - Pulley bracket bolt ②



## SWINGARM AND DRIVE CHAIN

1. Pivot shaft
2. Thrust cover
3. Shim
4. Bearing





# FREE PLAY INSPECTION

## 1. Check:

- Swingarm side play ①  
Side play → Adjust shim thickness.
- Swingarm up and down movement ②  
Tightness/Binding/Rough spots → Replace bearings.

## Free Play Inspection Step:

- Remove the rear wheel.
- Remove the shock absorber lower securing bolt.
- Inspect swingarm side play by moving it frame side to side. (There should be no noticeable side play)
- Inspect swingarm up and down movement by moving it up and down.

2. Select the proper shim ① thickness to obtain standard swingarm side play (A+B).




## Standard Side Play (A+B):

0.2 ~ 0.4 mm  
(0.008 ~ 0.016 in)




## Available Shim Thickness:

1.95 mm (0.75 in), 2.05 mm  
(0.0815 in), 2.15 mm (0.084 in)



5


## SWINGARM



### REMOVAL


1. Remove:
  - Rear wheel
  - Shock absorber lower securing bolt
  - Pivot shaft caps
2. Remove:
  - Pivot shaft nut (1)
  - Pivot shaft (2)
  - Swingarm assembly
  - Arm 1 and 2
3. Remove:
  - Change pedal assembly
  - Crankcase cover
  - Refer to ENGINE REMOVAL.
  - Drive chain


## 5



### INSPECTION


1. Wash the bearings in a solvent.
2. Inspect:
  - Bearings (1) (Race/Balls)  
Pitting/Damage → Replace.
  - Oil seal (2)  
Damage → Replace.
  - Collar (4)
  - Pivot shaft (5)  
Damage → Replace
- (3) Shim
3. Check:
  - Drive chain wear  
Pull (2) the chain away from the driven sprocket.  
Distance chain/sprocket higher than 1/2 tooth (1) → Replace drive chain





4. Check:


- Drive chain stiffness  
Clean and oil the chain and hold as illustrated  
Stiff → Replace drive chain



5. Inspect:

- Drive sprocket  
More than 1/4 teeth ① wear → Replace Sprocket.

- ② Correct
- ③ Roller
- ④ Sprocket



6. Inspect:

- Drive Sprocket  
Bent teeth ② → Replace sprocket

- ① Slip off


INSTALLATION

Reverse removal steps

1. Grease the bearings oil seal and collar.



Lithium Base Waterproof Wheel Bearing Grease



2. Install:
- Shim ①
  - Oil seal ②
  - (into the cover ③ as illustrated)

3. Install:
- Drive chain
  - Swing arm assembly



**Swingarm Pivot Shaft:**  
90 Nm (9.0 m·kg, 65 ft·lb)

4. Install:
- Arms
  - (On swingarm)



**Arm Screw:**  
40 Nm (4.0 m·kg, 29 ft·lb)

- Arm securing bolts



20 Nm (2.0 m·kg, 14 ft·lb)

5. Install:
- Shock absorber lower securing bolt




65 Nm (6.5 m·kg, 47 ft·lb)

6. Install:
- Rear wheel
7. Adjust:
- Drive chain tension




**Chain Deflection ① :**  
20 ~ 30 mm (0.8 ~ 1.2 in)



8. Tighten:
- Axle nut
  - Brake caliper bolts



**Axle Nut:**  
105 Nm (10.5 m·kg, 75 ft·lb)  
**Brake Caliper Bolts:**  
35 Nm (3.5 m·kg, 25 ft·lb)



9. Install:
- Cotter pin (New)

**NOTE:**

Do not loosen the axle nut after torque tightening.

If the axle nut groove is not aligned with the wheel shaft cotter pin hole, align groove to hole by tightening up on the axle nut.

## CABLES AND FITTINGS

### CABLE MAINTENANCE

#### NOTE:

See "Maintenance and Lubrication" intervals charts. Cable maintenance is primarily concerned with preventing deterioration and providing proper lubrication to allow the cable to move freely within its housing. Cable removal is straightforward and uncomplicated. Removal is not discussed within this section.

#### WARNING:

Cable routing is very important. For details of cable routing, see cable routing diagrams at end of this manual. Improperly routed or adjusted cables may make motorcycle operation unsafe.

1. Remove:
  - Cable
2. Check:
  - Cable free movement  
Obstruction → Inspect for Wear/Damage.  
Kinking/Frayed strands/Damage → Replace.
3. Lubricate the cable.

#### Cable Lubrication Steps:

- Hold the cable in a vertical position.
- Apply lubricant to the uppermost end of the cable.
- Leave in a vertical position until the lubricant appears at the bottom.
- Allow excess to drain, then reinstall the cable.

#### NOTE:

Choice of lubricant depends upon conditions and preferences; however, a semi-drying chain and cable lubricant will perform adequately under most conditions.

**THROTTLE MAINTENANCE**

1. Remove:
  - Philips head screws  
(from throttle housing assembly)  
Separate the housing halves.
2. Disconnect:
  - Cable  
(from throttle grip assembly)
3. Remove:
  - Throttle grip assembly
4. Clean:
  - All parts  
Use mild solvent.
  - Right-hand end of handlebar
5. Inspect:
  - Contact surfaces  
Burrs/Damage → Deburr or replace.
  - Right-hand end of handlebar
6. Lubricate all contact surfaces with a light coat of lithium-soap base grease and reassemble.

**NOTE:**


Tighten the housing screws evenly to maintain an even gap between housing halves.

7. Check:
  - Throttle (For smooth operation)  
Un smooth operation → Lubricate
  - Spring (For quick return)  
Sluggish operation → Replace
  - Housing (For tightness)  
Looseness → Replace



**ELECTRICAL**

**XJ600RL CIRCUIT DIAGRAM**





1. AC Magneto
2. Rectifier/Regulator
3. Main switch
4. Main fuse
5. Ignition fuse
6. "ENGINE STOP" switch
7. "OIL LEVEL" indicator light
8. Oil level switch
9. Clutch switch
10. "LIGHTS" switch
11. Ignitor unit
12. Ignition coil
13. Spark plug
14. "PASS" switch
15. Pickup coil
16. Starter motor
17. Starter relay
18. "START" switch
19. Battery
20. Signal fuse
21. Front brake switch
22. Rear brake switch
23. "NEUTRAL" indicator light
24. Relay assembly
25. "TURN" switch
26. Horn
27. "HORN" switch
28. Tachometer
29. Fuel meter
30. Fuel sender
31. "LIGHTS" (Dimmer) switch
32. Head fuse
33. "HIGH BEAM" indicator light
34. Headlight
35. Meter illumination light
36. Brake/Tail light
37. Neutral switch
38. Flasher/Indicator light
39. Reed switch
40. Auxiliary light

## COLOR CODE


|    |            |      |              |     |              |
|----|------------|------|--------------|-----|--------------|
| O  | Orange     | Lg   | Light green  | B/Y | Black/Yellow |
| R  | Red        | Y/G  | Yellow/Green | L/W | Blue/White   |
| L  | Blue       | Y/R  | Yellow/Red   | L/G | Blue/Green   |
| Br | Brown      | Y/B  | Yellow/Black | L/R | Blue/Red     |
| B  | Black      | Y/L  | Yellow/Blue  | L/B | Blue/Black   |
| Y  | Yellow     | Br/W | Brown/White  | G/L | Green/Blue   |
| W  | White      | R/B  | Red/Black    | G/R | Green/Red    |
| G  | Green      | R/L  | Red/Blue     | G/Y | Green/Yellow |
| P  | Pink       | R/W  | Red/White    | G/W | Green/White  |
| Dg | Dark green | R/Y  | Red/Yellow   | W/R | White/Red    |
| Ch | Chocolate  | B/R  | Black/Red    | W/B | White/Black  |
| Gy | Gray       | B/W  | Black/White  | W/G | White/Green  |
| Sb | Sky blue   |      |              |     |              |



# ELECTRICAL COMPONENTS 1

1. Fuse
2. Diode
3. Rectifier/Regulator
4. Starter relay
5. Battery
6. Ignitor unit
7. Ignition coil assembly

| SPECIFICATIONS:          | RESISTANCE:                  |
|--------------------------|------------------------------|
| Pickup coil:             | $120\Omega \pm 20\%$         |
| Ignition coil: (Primary) | $2.7\Omega \pm 10\%$         |
| (Secondary)              | $12\text{ k}\Omega \pm 20\%$ |
| Stator coil:             | $0.55\Omega \pm 10\%$        |






## ELECTRICAL COMPONENTS 2

1. Main switch
2. Fuel sender
3. Rear brake switch
4. Neutral switch
5. Oil level switch
6. Relay assembly
7. Horn

| SPECIFICATIONS:    | RESISTANCE:            |
|--------------------|------------------------|
| Fuel gauge: (Full) | $7\ \Omega \pm 5\%$    |
| (Empty)            | $95\ \Omega \pm 7.5\%$ |
| Starter switch:    | $3.5\ \Omega \pm 10\%$ |






## ELECTRIC STARTING SYSTEM

### CIRCUIT DIAGRAM

Below circuit diagram shows starter circuit in wiring diagram.


**NOTE:**

For the encircled numbers and color cords, see page 6-2.






- 3. Main switch
- 4. Main fuse
- 5. Ignition fuse
- 6. "ENGINE STOP" switch
- 9. Clutch switch
- 16. Starter motor
- 17. Starter relay
- 18. "START" switch
- 19. Battery
- 24. Relay assembly
- 37. Neutral switch






# **STARTER MOTOR**

1. O-ring
2. Brush holder assembly



**Removal**  
Refer to Chapter 3. "ENGINE DISASSEMBLY."

**Inspection and Repair****1. Inspect:**

- Commutator (Outer surface)  
Dirty → Clean with #600 grit sandpaper.

**2. Inspect:**


- Mica insulation  
(between commutator segments)  
Out of specification → Scrape mica to proper.  
Use a hacksaw blade that is ground to fit.

**Depth of Insulator:**

1.1 ~ 1.6 mm (0.043 ~ 0.063 in)

**NOTE:**

The mica insulation of the commutator must be undercut to ensure proper operation of the commutator.

**3. Measure:**

- Armature coil ③ resistance/insulation  
Defect(s) → Replace starter motor.

**Resistance ① :**


0.012 Ω at 20°C (68°F)

Insulation ② : ∞ Ω

**4. Inspect:**

- Commutator brushes  
Damage → Replace.

6

**5. Measure:**

- Brush length (Each)  
Out of specification → Replace.

**Minimum Brush Length:**

5.0 mm (0.02 in)

**6. Inspect**

- Brush springs  
Compare with new spring.  
Wear/Damage → Replace.





## BATTERY

## CAUTION:

To insure maximum battery performance be sure to:

- Charge a new battery before use.
- Maintain proper electrolyte level.
- Charge at proper current; 1.2 amps/10hrs. or until the specific gravity reaches 1.280 at 20°C (68°F).

Failure to observe these points will result in a shortened battery life.

## WARNING:

Battery electrolyte is dangerous; it contains sulfuric acid and therefore is poisonous and highly caustic.

Always follow these preventive measures:

- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.
- Wear protective eye gear when handling or working near batteries.

## Antidote (EXTERNAL):

- SKIN — Flush with water.
- EYES — Flush with water for 15 minutes and get immediate medical attention.
- Drink large quantities of water or milk and follow with milk of magnesia, beaten egg, or vegetable oil.

Get immediate medical attention.

Batteries also generate explosive hydrogen gas, therefore you should always follow these preventive measures:



- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks, or open flames (e.g., welding equipment, lighted cigarettes, etc.)
- DO NOT SMOKE when charging or handling batteries.

KEEP BATTERIES AND ELECTROLYTE OUT OF REACH OF CHILDREN.

## Battery Inspection

1. Remove:
  - Battery
  - Disconnect negative lead first.
2. Inspect:
  - Battery fluid level
  - Less than lower level → Add distilled water.

- ① Terminal
- ② Cap
- ③ Insulator
- ④ Separation plate
- ⑤ Negative electrode
- ⑥ Positive electrode



**NOTE:**

Replace the battery if:

- Battery voltage will not rise to a specific value or bubbles fail to rise even after many hours of charging.
- Sulfation of one or more cells occurs, as indicated by the plates turning white, or an accumulation of material exists in the bottom of the cell.
- Specific gravity readings after a long, slow charge indicate one cell to be lower than the rest.
- Warpage or buckling of plates or insulators is evident.

## 3. Measure:

- Specific Gravity:

Less than 1.280 → Recharge battery.

## 4. Install:

- Battery


Connect positive lead first.

## 5. Check:

- Breather pipe ①

Improper routing → Correct.

Obstruction/Damage → Replace.

**Battery Storage**

The battery should be stored if the motorcycle is not to be used for a long period.

## 1. Remove:

- Battery

**Battery Storage and Maintenance Tips:**

- Recharge the battery periodically.
- Store the battery in a cool, dry place.
- Recharge the battery before reinstalling.

| Battery               | 12N12A-4A  |
|-----------------------|--|
| Electrolyte           | Specific gravity: 1.280                            |
| Initial charging rate | 1.2 amp for 10 hours (new battery)                 |
| Recharging rate       | 10 hours (or until specific gravity reaches 1.280) |
| Refill fluid          | Distilled water (to maximum level line)            |
| Refill period         | Check once per month (or more often as required)   |



### Replenishing Battery Fluid

#### 1. Remove:

- Right side cover

#### 2. Check:

- Fluid level




Level should be between the upper ① and lower level ② marks.

#### CAUTION:

Use only distilled water for the battery, never tap water.

#### 3. Install:


- Right side cover




### STARTER RELAY INSPECTION

#### Preparation steps:


- Disconnect starter motor lead ①.
- Remove right side cover and rear brake fluid tank ②.
- Turn ignition switch to "ON".
- Turn engine stop switch to "RUN".
- Move change pedal to "NEUTRAL".
- Connect Pocket Tester leads ③.





## RELAY ASSEMBLY

- Remove:
  - Seat
  - Fuel tank
  - Relay assembly ①
- Check:
  - Relay contacts
 Use 12V battery ③ and Pocket Tester  
 Out of specification → Replace relay.




Battery Connected:  $0\Omega$  ①  
 Battery Disconnected:  $\infty$  ②



## DIODE

- Remove:
  - Seat
  - Diode ①
- Check:
  - Diode continuity/discontinuity



| Checking element | Pocket tester connecting point |             | Good  | Replace (element shorted) | Replace (element opened) |
|------------------|--------------------------------|-------------|-------|---------------------------|--------------------------|
|                  | (+) (red)                      | (-) (black) |       |                           |                          |
| D <sub>1</sub>   | G                              | L/W         | ○     | ○                         | x                        |
|                  | L/W                            | G           | x     | ○                         | x                        |
| D <sub>2</sub>   | W/G                            | W           | ○     | ○                         | x                        |
|                  | W                              | W/G         | x     | ○                         | x                        |
| R                | G                              | B/R         | 8.2 Ω | Out of specification      |                          |

○ : Continuity ( $0\Omega$ )

x : Discontinuity ( $\infty$ )

## NOTE:

The results "O" or "X" should be reversed according to the Pocket Tester polarity.




## CHARGING SYSTEM

### CIRCUIT DIAGRAM

Below circuit diagram shows charging circuit in wiring diagram.


**NOTE:**

For the encircled numbers and color cords, see page 6-2.





1. AC Magneto
2. Rectifier/Regulator
3. Main switch
4. Main fuse
19. Battery



#### GENERATOR VOLTAGE INSPECTION

1. Remove:
  - Right side cover
2. Connect:
  - Pocket tester (to battery terminals)
3. Start the engine and accelerate to about 2,000 rpm or more.
4. Measure:
  - Generator voltage



Generator Voltage:  $14.5 \pm 0.5V$

Out of specification → Check battery, stator coil, and rectifier/Regulator.

#### CAUTION:


Never disconnect the leads from the battery while the generator is operating, otherwise the voltage across the generator terminals will increase and damage the semiconductors.

6




## STATOR AND FIELD COIL INSPECTION

1. Remove:
  - Right side cover
  - Seat
  - Fuel tank
2. Disconnect
  - Stator coil lead
  - Field coil lead
3. Connect:
  - Pocket tester
4. Measure:
  - Field coil resistance
 Out of specification → Replace rotor
5. Measure
  - Coil resistance
 Out of specification → Replace stator coils.



**Field Coil Resistance:**  
 $4.5 \Omega \pm 10\%$  at  $20^\circ\text{C}$  ( $68^\circ\text{F}$ )



**Stator Coil Resistance:**  
 $0.55 \Omega \pm 10\%$  of  $20^\circ\text{C}$  ( $68^\circ\text{F}$ )






## RECTIFIER/REGULATOR

1. Remove:
  - Left side cover
2. Check:
  - Rectifier/Regulator diode
 Refer to the following table.

| Checking element | Pocket tester connecting point |             | Good | Replace (element shorted) | Replace (element opened) |
|------------------|--------------------------------|-------------|------|---------------------------|--------------------------|
|                  | (+) (red)                      | (-) (black) |      |                           |                          |
| D <sub>1</sub>   | ④                              | ①           | ○    | ○                         | x                        |
|                  | ①                              | ④           | x    | ○                         | x                        |
| D <sub>2</sub>   | ④                              | ②           | ○    | ○                         | x                        |
|                  | ②                              | ④           | x    | ○                         | x                        |
| D <sub>3</sub>   | ④                              | ③           | ○    | ○                         | x                        |
|                  | ③                              | ④           | x    | ○                         | x                        |
| D <sub>4</sub>   | ①                              | ⑤           | ○    | ○                         | x                        |
|                  | ⑤                              | ①           | x    | ○                         | x                        |
| D <sub>5</sub>   | ②                              | ⑤           | ○    | ○                         | x                        |
|                  | ⑤                              | ②           | x    | ○                         | x                        |
| D <sub>6</sub>   | ③                              | ⑤           | ○    | ○                         | x                        |
|                  | ⑤                              | ③           | x    | ○                         | x                        |

○ : Continuity (0 Ω)

x : Discontinuity (∞)



- White lead ①  
 White lead ②  
 White lead ③  
 Red lead ④  
 Black lead ⑤  
 Rectifier ⑥  
 Regulator ⑦

Defective element → Replace rectifier.

**CAUTION:**

Do not overcharge rectifier or damage may result.

Avoid:

- A short circuit
- Inverting + and - battery leads
- Direct connection of rectifier to battery

**NOTE:**

The results "O" or "X" should be reversed according to the Pocket Tester polarity.




# IGNITION SYSTEM

## CIRCUIT DIAGRAM


Below circuit diagram shows ignition circuit in wiring diagram.

### NOTE:

For the encircled numbers and color cords, see page 6-2.



- 3. Main switch
- 4. Main fuse
- 5. Ignition fuse
- 6. "ENGINE STOP" switch
- 11. Ignitor unit
- 12. Ignition coil
- 13. Spark plug
- 15. Pickup coil
- 19. Battery







## IGNITION SYSTEM

## CIRCUIT DIAGRAM

Refer to the diagram for the  
ignition system.

## DESCRIPTION

This model is equipped with a battery operated, fully transistorized, breakerless ignition system. By using magnetic pickup coils, the need for contact breaker points is eliminated. This adds to the dependability of the system by eliminating frequent cleaning and adjustment of points and ignition timing. The TCI (Transistor Control Ignition) unit incorporates an automatic advance circuit controlled by signals generated by the pickup coil. This adds to the dependability of the system by eliminating the mechanical advancer. This TCI system consists of two units; a pickup unit and an ignitor unit.



## OPERATION

The TCI functions on the same principle as a conventional DC ignition system with the exception of using magnetic pickup coils and a transistor control box (TCI) in place of contact breaker points.

## ① TCI unit

## PICKUP UNIT


The pickup unit consists of two pickup coils ① and a flywheel mounted onto the crankshaft. When the projection on the flywheel passes a pickup coil, a signal is generated and transmitted to the ignitor unit. The width of the projection on the flywheel determines the ignition advance.

The pickup coils are located in the right crankcase cover.

## IGNITION SYSTEM INSPECTION

The entire ignition system can be checked for misfire and weak spark by using the Electro Tester.

1. Warm up the engine so that all of the electrical components are at operating temperature.



2. Connect:
  - Electro Tester (90890-03021) ①
3. Start the engine, and increase the spark gap until misfire occurs. (Test at various r/min between idle and red line.)
  - ② Spark plug lead
  - ③ Spark plug


## CAUTION:


Do not run the engine in neutral above 6,000 r/min for more than 1 or 2 seconds.

**Minimum Spark Gap: 6 mm (0.24 in)**

Faulty ignition system operation (at the minimum spark gap or smaller) → Follow the troubleshooting chart until the source of the problem is located.

## TROUBLESHOOTING





## IGNITION COIL

## Ignition Coil Spark Gap

1. Remove:
  - Seat
  - Fuel tank
2. Disconnect:
  - Ignition coil leads
  - Spark plug leads
3. Connect:
  - Electro Tester (90890-03021) ①


**NOTE:**

Be sure to use a fully charged battery.

4. Turn the spark plug gap adjuster and increase the gap to the maximum limit unless misfire occurs first.

**Minimum Spark Gap: 6 mm (0.24 in)**

② Battery (12V)



## Ignition Coil Resistance

1. Connect:
    - Pocket Tester (90890-03112) ①
  2. Measure:
    - Primary coil resistance [A]
    - Secondary coil resistance [B]
- Out of specification → Replace.



## Primary Coil Resistance:


$2.7 \Omega \pm 10\%$  at  $20^\circ\text{C}$  ( $68^\circ\text{F}$ )

## Secondary Coil Resistance:

$12 \text{ k}\Omega \pm 20\%$  at  $20^\circ\text{C}$  ( $68^\circ\text{F}$ )

## Spark Plug Cap:

$10 \text{ k}\Omega \pm 10\%$




## PICKUP COIL RESISTANCE

1. Remove:
  - Right side panel
2. Disconnect:
  - Pickup coil connector ①
3. Measure:
  - Pickup coil resistance
 Use a Pocket Tester. (YU-03112)  
 Out of specification → Replace.



**Pickup Coil Resistance:**  
 $120\Omega \pm 10\%$  at 20°C (68°F)  
 No.1 and No.4 cylinder (O-B)  
 No.2 and No.3 cylinder (Gy-B)



## SPARK PLUG

1. Inspect:
  - Plug
 Burns/Fouling/Wear → Replace.
2. Measure:
  - Electrode gap
 Out of specification → Clean off carbon and regap.

**Type:**  
 DR8ES-L (NGK)



**Electrode Gap ① :**  
 0.6 ~ 0.7 mm (0.024 ~ 0.028 in)



**17.5 Nm (1.75 m·kg, 12.5 ft·lb)**

- ② Finger tighten
- ③ Plug wrench


## LIGHTING SYSTEM

### CIRCUIT DIAGRAM

Below circuit diagram shows lighting circuit in wiring diagram.


**NOTE:**

For the encircled numbers and color cords, see page 6-2.





- 3. Main switch
- 4. Main fuse
- 10. "LIGHTS" switch
- 14. "PASS" switch
- 19. Battery
- 31. "LIGHTS" (Dimmer) switch
- 32. Head fuse
- 33. "HIGH BEAM" indicator light
- 34. Headlight
- 35. Meter illumination light
- 36. Brake/Tail light
- 40. Auxiliary light



### LIGHTING TESTS AND CHECK


The battery provides power for operation of the headlight, taillight, and meter lights. If none of the above fail to operate proceed further. Low battery voltage indicates either a faulty battery, low battery fluid level, or a defective charging system.

Also check fuse condition. Replace any "open" fuses. There are individual fuses for various circuits (see complete Circuit Diagram).


#### NOTE:

Check each bulb first before performing the following check.

#### Headlight and High beam light Check



#### Taillight and Auxiliary light Check






## SIGNAL SYSTEM

### CIRCUIT DIAGRAM

Below circuit diagram shows signal circuit in wiring diagram.


**NOTE:**

For the encircled numbers and color cords, see page 6-2.






- |                                |                             |
|--------------------------------|-----------------------------|
| 3. Main switch                 | 24. Relay assembly          |
| 4. Main fuse                   | 25. "TURN" switch           |
| 5. Ignition fuse               | 26. Horn                    |
| 6. "ENGINE STOP" switch        | 27. "HORN" switch           |
| 7. "OIL LEVEL" indicator light | 28. Tachometer              |
| 8. Oil level switch            | 29. Fuel meter              |
| 19. Battery                    | 30. Fuel sender             |
| 20. Signal fuse                | 36. Brake/Tail light        |
| 21. Front brake switch         | 37. Neutral switch          |
| 22. Rear brake switch          | 38. Flasher/Indicator light |
| 23. "NEUTRAL" indicator light  | 39. Reed switch             |





## FLASHER LIGHT

## Troubleshooting



## RELAY ASSEMBLY


The relay assembly turns off the flashers. Generally, the signal will cancel after either 10 seconds of operation or after the motorcycle has traveled 150 meters (490 feet), whichever is greater. At low speed, the cancelling is a function of distance; at high speeds, it's a function of both time and distance.

The flasher switch has three positions: L (left), OFF, and R (right). The switch lever will return to the "OFF" position after being pushed to L or R, but the signal will function. By pushing the lever in, the signal may be cancelled manually.



## REED SWITCH

1. Remove:
  - Seat
  - Fuel tank
2. Disconnect:
  - Relay assembly coupler
3. Connect:
  - Pocket tester
  - Reed switch lead
4. Lift the front wheel and rotate the wheel by hand
5. Measure:
  - Reed switch resistance to relay assembly
 Out of specification → Replace




**Reed Switch Resistance:**  
About 7 Ω

Then return back 0 Ω or ∞ Ω  
when wheel is stopped

## OIL LEVEL INDICATOR LIGHT


### Troubleshooting





## FUEL METER


## Troubleshooting



## FUEL SENDER UNIT

1. Remove:
  - Seat
  - Fuel tank
  - Fuel sender unit
2. Measure:
  - Fuel sender unit resistance.
 Out of specification → Replace

6



6-31



**Fuel Sender Unit Resistance:**  
(Black - Green)


"Full" Position ① :  
 $7\ \Omega \pm 5\%$  at  $20^{\circ}\text{C}$  ( $68^{\circ}\text{F}$ )

"Empty" Position ② :  
 $95\ \Omega \pm 7.5\%$  at  $20^{\circ}\text{C}$  ( $68^{\circ}\text{F}$ )



## NEUTRAL INDICATOR LIGHT

## Troubleshooting



## HORN

| Horn inoperative |  |
|------------------|--|
| Check for:       | 12V on brown lead to horn                                |
|                  | Good ground (horn/pink lead) when horn button is pressed |
|                  | Faulty fuse  |

Defective components → Replace.

There are individual fuses for various circuits (See Complete Circuit Diagram)


## 2. Measure:

- Horn resistance

Out of specification → Replace

| Tester's lead |            | Standard resistance    | Tester's range |
|---------------|------------|------------------------|----------------|
| Red lead      | Black lead |                        |                |
| Brown lead    | Pink lead  | $1.05 \Omega \pm 10\%$ | $R \times 1$   |

6



## 3. Adjust:

- Volume

Turn the adjuster ① in and out so that the volume is maximum at the maximum amperage.

② Battery (12V)



| Tester's lead    |                                | Maximum Amperage | Tester's range |
|------------------|--------------------------------|------------------|----------------|
| Red lead         | Black lead                     |                  |                |
| Battery (+) lead | Horn lead and Battery (-) lead | 2.5A             | DC 5A          |

## BRAKE LIGHT

| Brake light inoperative |  |
|-------------------------|--|
| Check for:              | Defective bulb   |
|                         | 12V on yellow lead to brake light  |
|                         | 12V on brown lead to each brake light switch (Front and rear brake switch) |

## SWITCHES

Check:

- Switches (all)

Use pocket tester on "Ohm x 1" scale.  
Infinite resistance/Short circuit → Replace.

## Main switch


| Switch position | Lead color |    |   |
|-----------------|------------|----|---|
|                 | R          | Br | L |
| ON              | ○          | ○  | ○ |
| OFF             |            |    |   |
| P               | ○          |    | ○ |

## "ENGINE STOP" switch

| Switch position | Lead color |     |
|-----------------|------------|-----|
|                 | R/W        | R/W |
| RUN             | ○          | ○   |
| OFF             |            |     |

## "START" switch

| Switch position | Lead color |   |     |     |
|-----------------|------------|---|-----|-----|
|                 | L/W        | B | R/Y | L/B |
| OFF             |            |   | ○   | ○   |
| ON              | ○          | ○ |     |     |






"LIGHTS" (Dimmer) switch

| Switch position | Lead color |     |   |
|-----------------|------------|-----|---|
|                 | Y          | L/B | G |
| HI              |            |     |   |
| LO              |            |     |   |



"HORN" switch

| Switch position | Lead color |             |
|-----------------|------------|-------------|
|                 | P          | Ground or B |
| ON              |            |             |
| OFF             |            |             |



"TURN" switch

| Switch position | Lead color |      |    |     |   |
|-----------------|------------|------|----|-----|---|
|                 | Dg         | Br/w | Ch | Y/R | B |
| R               |            |      |    |     |   |
| N               | R          |      |    |     |   |
|                 | N          |      |    |     |   |
|                 | L          |      |    |     |   |
| L               |            |      |    |     |   |

Oil level switch

| Switch position | Lead color |        |
|-----------------|------------|--------|
|                 | B/R        | Ground |
| ON              |            |        |
| OFF             |            |        |

Front brake switch

| Switch position | Lead color |     |
|-----------------|------------|-----|
|                 | Br         | G/Y |
| ON              |            |     |
| OFF             |            |     |

Rear brake switch

| Switch position | Lead color |    |
|-----------------|------------|----|
|                 | Y          | Br |
| ON              |            |    |
| OFF             |            |    |





“PASS” switch

| Switch position | Lead color |   |
|-----------------|------------|---|
|                 | R/Y        | Y |
| ON              |            |   |
| OFF             | ○          | ○ |



“LIGHTS” switch


| Switch position | Lead color |   |     |
|-----------------|------------|---|-----|
|                 | R/Y        | L | L/B |
| OFF             |            |   |     |
| PO              | ○          | ○ |     |
| ON              | ○          | ○ | ○   |



# GENERAL SPECIFICATIONS

## SPECIFICATIONS

### GENERAL SPECIFICATIONS

| Item                        | Model   | XJ600RL  |
|-----------------------------|---|--|
| Model:                      |   |  |
| Code Number                 | 49F   |  |
| Frame Starting Number       | 49F-000101  |  |
| Engine Starting Number      | 49F-000101  |  |
| Dimensions:                 |   |  |
| Overall Length              | 2,115 mm (83.4 in)  |  |
| Overall Width               | 735 mm (28.9 in)  |  |
| Overall Height              | 1,225 mm (48.2 in)  |  |
| Seat Height                 | 790 mm (31.1 in)  |  |
| Wheelbase                   | 1,430 mm (56.3 in)  |  |
| Minimum Ground Clearance    | 160 mm (6.3 in)   |  |
| Basic Weight:               |   |  |
| With Oil and Full Fuel Tank | 208 kg (459 lb)   |  |
| Minimum Turning Radius:     | 2,800 mm (110.2 in)   |  |
| Engine:                     |   |  |
| Engine Type                 | Air cooled 4-stroke, gasoline, DOHC   |  |
| Cylinder Arrangement        | 4-cylinder parallel   |  |
| Displacement                | 598 cm <sup>3</sup>   |  |
| Bore x Stroke               | 58.5 x 55.7 mm (2.3 x 2.19 in)  |  |
| Compression Ratio           | 10.0 : 1  |  |
| Compression Pressure        | 1078.8 kPa (11 k/cm <sup>2</sup> , 156.4 psi)                                       |  |
| Starting System             | Electric starter  |  |
| Lubrication System:         | Pressure lubricated, wet sump   |  |
| Engine Oil Type or Grade    |  | SAE 20W40 type SE motor oil<br>SAE 10W30 type SE motor oil |
| Engine Oil Capacity:        |   |  |
| Engine Oil:                 |   |  |
| Periodic Oil Change:        | 2.3 L (2.0 Imp qt, 2.4 US qt)   |  |
| With Oil Filter Replacement | 2.6 L (2.3 Imp qt, 2.7 US qt)   |  |
| Total Amount                | 3.0 L (2.6 Imp qt, 3.2 US qt)   |  |
| Air Filter                  | Dry type element  |  |
| Fuel:                       |   |  |
| Type                        | Regular gasoline  |  |
| Tank Capacity               | 19.0 L (4.18 Imp gal, 5.02 US gal)  |  |
| Reserve Amount              | 2.5 L (0.55 Imp gal, 0.66 US gal)   |  |
| Carburetor:                 |   |  |
| Type                        | BS32X4, Constant velocity   |  |
| Manufacturer                | MIKUNI  |  |

# GENERAL SPECIFICATIONS

APPX



| Item  | Model | XJ600RL  |
|---|-------|--|
| Spark plug:<br>Type/Manufacture<br>Gap  |       | DR8ES-L/NGK<br>0.6 ~ 0.7 mm (0.024 ~ 0.028 in)   |
| Clutch Type:  |       | Wet, multiple-disc   |
| Transmission:<br>Primary Reduction System<br>Primary Reduction Ratio<br>Secondary Reduction System<br>Secondary Reduction Ratio<br>Transmission Type<br>Operation<br>Gear Ratio |       | Spur gear, HY-VO chain<br>22/21 x 65/28 = 2.432<br>Chain drive<br>44/16 (2.750)<br>Constant-mesh, 6-speed<br>Left foot operation<br>41/15 (2.733)<br>37/19 (1.947)<br>34/22 (1.545)<br>31/25 (1.240)<br>29/28 (1.036)<br>27/30 (0.900) |
| Chassis:<br>Frame Type<br>Caster Angle<br>Trail   |       | Tubular steel, double cradle<br>26°<br>106 mm (4.17 in)  |
| Tire: Type<br>Size (Front)<br>Size (Rear)<br>Wear limit   |       | Tubeless<br>90/90-18 51H YOKOHAMA F202<br>MICHELIN A48TL<br>110/90-18 61H YOKOHAMA R202<br>MICHELIN M48TL<br>0.8 mm (0.03 in)  |
| Tire Pressure (Cold tire):<br>Front Tire Pressure<br>Rear Tire Pressure   |       | 177 kPa (1.8 kg/cm <sup>2</sup> , 26 psi)<br>196 kPa (2.0 kg/cm <sup>2</sup> , 28 psi)   |
| Brake:<br>Front Brake Type<br>Operation<br>Rear Brake Type<br>Operation   |       | Dual disc brake<br>Right hand operation<br>Single disc operation<br>Right foot operation   |
| Suspension:<br>Front Suspension<br>Rear Suspension  |       | Telescopic fork<br>Swingarm (New Monocross)  |
| Shock Absorber:<br>Front Shock Absorber<br>Rear Shock Absorber  |       | Coil spring, oil damper<br>Coil spring, oil damper   |
| Wheel Travel:<br>Front Wheel Travel<br>Rear Wheel Travel  |       | 150 mm (5.91 in)<br>100 mm (3.94 in)   |
| Electrical:<br>Ignition System<br>Generator System<br>Battery Type or Model<br>Battery Capacity   |       | T.C.I (Full Transistor ignition)<br>A.C. generator<br>12N12A-4A<br>12V 12AH  |



7








| Item                        | Model | XJ600RL            |
|-----------------------------|-------|--------------------|
| Headlight Type:             |       | Bulb (Quartz bulb) |
| Bulb Wattage/Quantity:      |       |                    |
| Headlight                   |       | 60W/55W            |
| Tail/Brake Light            |       | 8W/27W x 2         |
| Flasher Light               |       | 27W x 4            |
| License Light               |       | 8W x 2             |
| Meter Light                 |       | 3.4W x 6           |
| Auxiliary light             |       | 3.4W x 1           |
| Indicator Light:            |       |                    |
| Wattage/Quantity: "NEUTRAL" |       | 3.4W x 1           |
| "HIGH BEAM"                 |       | 3.4W x 1           |
| "TURN"                      |       | 3.4W x 2           |
| "OIL LEVEL"                 |       | 3.4W x 1           |

## MAINTENANCE SPECIFICATIONS






## Engine

| Item   | Model   | XJ600RL   |
|--|---|---|
| Cylinder Head:<br>Warp Limit   |   | 0.03 mm (0.001 in)<br>*Lines indicate straightedge measurement.   |
| Cylinder:<br>Bore Size<br>Taper Limit<br>Out-of-round Limit  |   | 58.50 mm (2.303 in)<br>0.05 mm (0.002 in)<br>0.01 mm (0.0004 in)  |
| Camshaft:<br>Drive Method<br>Cam Cap Inside Diameter<br>(Cylinder head direct support)<br>Camshaft Outside Diameter<br>Shaft-to-cap Clearance<br>Cam Dimensions: Intake "A"<br>"B"<br>"C"<br>Exhaust "A"<br>"B"<br>"C" |  | Chain drive (Center)<br>$25^{+0.021}_0$ mm (0.9449 $^{+0.0008}_0$ in)<br>$25^{-0.020}_{-0.033}$ mm (0.9448 $^{-0.0008}_{-0.0013}$ in)<br>0.020 ~ 0.054 mm (0.0008 ~ 0.0021 in)<br>36.25 ~ 36.35 mm (1.427 ~ 1.431 in)<br>36.2 mm (1.43 in)<br>28.1 ~ 28.2 mm (1.106 ~ 1.11 in)<br>28.05 mm (1.1 in)<br>8.3 mm (0.327 in)<br>35.75 ~ 35.85 mm (1.408 ~ 1.411 in)<br>35.7 mm (1.41 in)<br>28.05 ~ 28.15 mm (1.104 ~ 1.108 in)<br>28 mm (1.1 in)<br>7.8 mm (0.307 in)<br>7.6 mm (0.299 in) |



| Item  | Model      | XJ600RL  |
|---|------------|--|
| Camshaft Runout Limit<br>Cam Chain Type/Number of Links<br>Cam Chain Adjustment Method  |            | 0.03 mm (0.0012 in)<br>Bush-chain/114<br>Manual  |
| Valve, Valve Seat, Valve Guide:<br>Valve Clearance (Cold)   | IN.<br>EX. | 0.11 ~ 0.15 mm (0.004 ~ 0.006 in)<br>0.16 ~ 0.20 mm (0.006 ~ 0.008 in)   |
|   |            |   |
| "A" Head Dia.   | IN.<br>EX. | 31 $\pm 0.6$ mm (1.220 $\pm 0.0236$ in)<br>27 $\pm 0.1$ mm (1.063 $\pm 0.004$ in)  |
| "B" Face Width  | IN.<br>EX. | 2.26 mm (0.0889 in)<br>2.26 mm (0.0889 in)   |
| "C" Seat Limit Width  | IN.<br>EX. | 1.0 $\pm 0.1$ mm (0.0394 $\pm 0.004$ in)<br>1.0 $\pm 0.1$ mm (0.0394 $\pm 0.004$ in)   |
| "D" Margin Thickness Limit  | IN.<br>EX. | 1.0 $\pm 0.2$ mm (0.0394 $\pm 0.008$ in)<br>1.0 $\pm 0.2$ mm (0.0394 $\pm 0.008$ in)   |
| Stem Outside Diameter   | IN.<br>EX. | 5.975 ~ 5.990 mm (2.2352 ~ 0.2358 in)<br>5.960 ~ 5.975 mm (0.2346 ~ 0.2352 in)   |
| Guide Inside Diameter   | IN.<br>EX. | 6.0 ~ 6.012 mm (0.2362 ~ 0.2367 in)<br>6.0 ~ 6.012 mm (0.2362 ~ 0.2367 in)   |
| Stem-to-guide Clearance   | IN.<br>EX. | 0.010 ~ 0.037 mm (0.0004 ~ 0.0015 in)<br>0.025 ~ 0.052 mm (0.0010 ~ 0.0020 in)   |
| Stem Runout Limit   |            | 0.03 mm (0.001 in)   |
|    |            |  |
| Valve Spring:<br>Free Length  |            |  |
| Inner Spring  | IN.<br>EX. | 35.5 mm (1.398 in)<br>35.5 mm (1.398 in)   |
| Outer Spring  | IN.<br>EX. | 37.2 mm (1.465 in)<br>37.2 mm (1.465 in)   |
| Installed Length (Valve Closed)   |            |  |
| Inner Spring  | IN.<br>EX. | 30.5 mm (1.201 in)<br>30.5 mm (1.201 in)   |
| Outer Spring  | IN.<br>EX. | 32.0 mm (1.260 in)<br>32.0 mm (1.260 in)   |




| Model  |  | XJ600RL   |      |              |       |
|--|--|---|------|--------------|-------|
| Item   |  |   |      |              |       |
| Tilt Limit<br>Inner Spring<br>Outer Spring<br><br><br><br>Direction of Winding<br><br> | IN. & EX.<br>IN. & EX.                                 | 2.5°/1.5 mm (0.063 in)<br>2.5°/1.6 mm (0.063 in)  |      |              |       |
|  |  | Inner spring  |      | Outer Spring |       |
|  |  | IN  | EX   | IN           | EX    |
|  |  | Left  | Left | Right        | Right |
| Piston:<br>Piston Size "D"<br>Measuring Point "H"  |  | 58.50 mm (2.30 in)<br>7.0 mm (0.276 in)<br>(From bottom line of piston skirt)   |      |              |       |
| Clearance Between Piston & Cylinder<br>Oversize:   | 1st<br>2nd<br>3rd<br>4th                               | 0.025 ~ 0.045 mm (0.0010 ~ 0.0018 in)<br>—<br>59.00 mm (2.32 in)<br>—<br>60.00 mm (2.36 in)   |      |              |       |
| Piston Ring:<br>Sectional Sketch   | Top Ring   | Barrel<br>B = 1.0 mm (0.039 in)<br>T = 2.3 mm (0.090 in)  |      |              |       |
|   | 2nd Ring   | Taper<br>B = 1.2 mm (0.047 in)<br>T = 2.3 mm (0.090 in)   |      |              |       |
|   | Oil Ring   | Expander<br>B = 2.5 mm (0.10 in)<br>T = 2.8 mm (0.11 in)  |      |              |       |
|   |  |   |      |              |       |
| End Gap (Installed):   | Top Ring<br><Limit><br>2nd Ring<br><Limit><br>Oil Ring | 0.15 ~ 0.30 mm (0.0059 ~ 0.0118 in)<br>0.7 mm (0.0276 in)<br>0.15 ~ 0.30 mm (0.0059 ~ 0.0118 in)<br>0.7 mm (0.0276 in)<br>0.2 ~ 0.7 mm (0.0079 ~ 0.0276 in) |      |              |       |
| Side Clearance:  | Top Ring<br><Limit><br>2nd Ring<br><Limit><br>Oil Ring | 0.03 ~ 0.07 mm (0.0012 ~ 0.0028 in)<br>0.15 mm (0.0059 in)<br>0.02 ~ 0.06 mm (0.0008 ~ 0.0024 in)<br>0.15 mm (0.0059 in)<br>—                               |      |              |       |

# MAINTENANCE SPECIFICATIONS

# APPX





| Item  | Model<br>XJ600RL  |
|---|---|
| <b>Connecting Rod:</b><br>Oil Clearance<br>Color code (Corresponding Size)<br>1. Blue<br>2. Black<br>3. Brown<br>4. Green   | 0.016 ~ 0.040 mm (0.0006 ~ 0.0016 in)<br><br>$1.5^{+0.004}_0$ mm (0.0591 $^{+0.00016}_0$ in)<br>$1.5^{-0.004}_0$ mm (0.0591 $^{-0.00016}_0$ in)<br>$1.5^{-0.004}_{-0.008}$ mm (0.0591 $^{-0.00016}_{-0.00031}$ in)<br>$1.5^{-0.008}_{-0.012}$ mm (0.0591 $^{-0.00031}_{-0.00047}$ in) |
| <b>Crankshaft:</b><br><br><br>Crank Width "A"<br>Runout Limit "B"<br>Big End Side Clearance "C"<br>Crank journal oil clearance<br>Con-rod oil clearance  | <br><br><br><br><br><br>312.4 ± 0.6 mm (12.30 ± 0.024 in)<br>0.03 mm (0.0012 in)<br>0.16 ~ 0.262 mm (0.006 ~ 0.010 in)<br>0.021 ~ 0.044 mm (0.0008 ~ 0.0017)<br>0.016 ~ 0.040 mm (0.0006 ~ 0.0016 in)   |
| <b>Clutch:</b><br>Friction Plate Thickness/Quantity<br>Wear Limit<br>Clutch Plate Thickness/Quantity<br>Warp Limit<br>Clutch Spring Free Length/Quantity<br>Clutch Spring Minimum Length<br>Clutch Release Method   | 3.0 ± 0.1 mm (0.12 ± 0.0039 in)/8<br>2.7 mm (0.106 in)<br>1.6 mm (0.063 in)/7<br>0.15 mm (0.0059 in)<br>42.8 mm (1.690 in)/5<br>41.8 mm (1.646 in)<br>Outer Pull, Rack & Pinion Pull  |
| <b>Transmission:</b><br>Main Axle Deflection Limit<br>Drive Axle Deflection Limit   | 0.08 mm (0.0031 in)<br>0.08 mm (0.0031 in)  |
| <b>Shifter:</b><br>Shifter Type   | Guide bar   |
| <b>Carburetor:</b><br>Type/Manufact/Quantity<br>I.D.Mark<br>Main Jet (M.J.) (For No.1 and No.2 Cylinder)<br>Main Air Jet (M.A.J.)<br>Jet Needle-clip Position (J.N.) (For No.1, 3,4 Cylinder)<br>Needle Jet (N.J.)<br>Pilot Jet (P.J.)<br>Pilot Outlet Size (P.O.)<br>Pilot Air Jet (P.A.J.)<br>Pilot Screw (P.S.)<br>Valve Seat Size (V.S.)<br>Starter Jet (G.S.)<br>Bypass Size (B.P.)<br>Fuel Level (F.L.) | BS32/MIKUNI/4<br>51J01<br>#105<br>#102.5<br>#70<br><br>4CP3-3<br>4CP7-3<br>N-8<br>#40<br>φ0.80<br>#155<br>2-1/2 turns out<br>φ2.0<br>#42.5 (φ0.6)<br>φ0.8 x 3<br>3.0 ± 1.0 mm (0.12 ± 0.04 in)<br>Below from the carburetor mixing chamber body edge                                  |





| Item  | Model<br>XJ600RL   |
|---|--|
| Engine Idling speed<br>Vacuum Pressure at Idling Speed<br><br>Vacuum Synchronous Difference<br>Lubrication System:<br>Oil Filter Type<br>Oil Pump Type<br>Tip Clearance <Limit><br>Side Clearance <Limit><br>Bypass Valve Setting Pressure<br><br>Relief Valve Operating Pressure | $1,200 \pm 50$ r/min<br>$23.3 \pm 0.667$ kPa<br>$(175 \pm 5 \text{ mmHg}, 6.890 \pm 0.1969 \text{ inHg})$<br>Below 10 kPa (10 mmHg, 0.4 inHg)<br><br>Paper<br>Trochoid pump<br>$0.03 \sim 0.09$ mm (0.0012 ~ 0.0035 in)<br>$0.03 \sim 0.08$ mm (0.0012 ~ 0.0031 in)<br>$98.0 \pm 20$ kPa<br>$(1.0 \pm 0.2 \text{ kg/cm}^2, 14.2 \pm 2.8 \text{ psi})$<br>$490 \pm 49$ kPa<br>$(5.0 \pm 0.5 \text{ kg/cm}^2, 71.1 \pm 7.1 \text{ psi})$ |
| Lubrication Chart   | <div style="text-align: center;"> </div>   |
| Crankcase Tightening Sequence:<br>Upper case  | Lower case   |





## Tightening torque ENGINE:

| Part to be tightened                  | Part name  | Thread size | Q'ty | Tightening torque |      |       | Remarks             |
|---------------------------------------|------------|-------------|------|-------------------|------|-------|---------------------|
|                                       |            |             |      | Nm                | m·kg | ft·lb |                     |
| Cam shaft cap                         | Bolt       | M6 P1.0     | 24   | 10                | 1.0  | 7.2   | Tighten in 3-stages |
| Cylinder (cam chain)                  | Stud bolt  | M6 P1.0     | 4    | 5                 | 0.5  | 3.6   | Apply oil           |
| Cylinder head (Exhaust pipe)          | Stud bolt  | M6 P1.0     | 8    | 10                | 1.0  | 7.2   | Apply oil           |
| Cylinder head                         | Stud bolt  | M6 P1.0     | 4    | 5                 | 0.5  | 3.6   | Apply oil           |
| Cylinder                              | Nut        | M8 P1.25    | 1    | 20                | 2.0  | 14    |                     |
| Cylinder                              | Nut        | M6 P1.0     | 1    | 10                | 1.0  | 7.2   |                     |
| Cylinder head                         | Cap nut    | M8 P1.25    | 12   | 22                | 2.2  | 16    | Apply oil           |
| Spark plug                            |            | M12 P1.25   | 4    | 17.5              | 1.75 | 13    |                     |
| Cylinder head cover                   | Bolt       | M6 P1.0     | 12   | 10                | 1.0  | 7.2   |                     |
| Cylinder                              | Stud bolt  | M8 P1.25    | 1    | 15                | 1.5  | 11    | Apply oil           |
| Cylinder and crank case               | Nut        | M8 P1.25    | 1    | 20                | 2.0  | 14    |                     |
| Connecting rod and rod cap            | Nut        | M7 P0.75    | 8    | 25                | 2.5  | 18    |                     |
| Camshaft and sprocket                 | Bolt       | M7 P1.0     | 4    | 24                | 2.4  | 17    |                     |
| Cam chain tensioner stopper bolt      | Bolt       | M8 P1.0     | 1    | 8                 | 0.8  | 5.7   |                     |
| Cam chain tensioner case and cylinder | Bolt       | M6 P1.0     | 1    | 10                | 1.0  | 7.2   |                     |
| Cam chain tensioner case and cylinder | Nut        | M6 P1.0     | 1    | 10                | 1.0  | 7.2   |                     |
| Cam chain tensioner lock nut          | Nut        | M8 P1.25    | 1    | 9                 | 0.9  | 6.5   |                     |
| Crankcase                             | Plug       | M10 P1.25   | 1    | 10                | 1.0  | 7.2   |                     |
| Rotor housing and pump cover          | Screw      | M6 P1.0     | 1    | 7                 | 0.7  | 5.1   |                     |
| Oil pump ass'y and crankcase          | Screw      | M6 P1.0     | 3    | 7                 | 0.7  | 5.1   |                     |
| Strainer housing and crankcase        | Bolt       | M6 P1.0     | 2    | 10                | 1.0  | 7.2   |                     |
| Strainer cover and crankcase          | Bolt       | M6 P1.0     | 12   | 10                | 1.0  | 7.2   |                     |
| Filter cover and crankcase            | Union bolt | M20 P1.5    | 1    | 15                | 1.5  | 11    |                     |
| Drain bolt                            | Plug       | M14 P1.5    | 1    | 43                | 4.3  | 31    |                     |
| Carburetor joint and Cylinder head    | Bolt       | M6 P1.0     | 8    | 10                | 1.0  | 7.2   |                     |
| Air filter cover                      | Screw      | M5 P0.8     | 4    | 5                 | 0.5  | 3.6   |                     |
| Air filter                            | Bolt       | M6 P1.0     | 3    | 7                 | 0.7  | 5.1   |                     |
| Exhaust pipe and cylinder head        | Nut        | M6 P1.0     | 8    | 10                | 1.0  | 7.2   |                     |
| Exhaust pipe joint                    | Bolt       | M8 P1.25    | 6    | 20                | 2.0  | 14    |                     |
| Muffler                               | Bolt       | M10 P1.25   | 2    | 25                | 2.5  | 18    |                     |
| Adaptor plate and crankcase           | Union bolt | M20 P1.5    | 1    | 50                | 5.0  | 36    |                     |
| Oil cooler and hose                   | Nut        | M18 P       | 2    | 32                | 3.2  | 23    |                     |
| Adaptor plate and hose                | Bolt       | M6 P1.0     | 4    | 12                | 1.2  | 8.6   |                     |
| Oil cooler and frame                  | Bolt       | M6 P1.0     | 2    | 10                | 1.0  | 7.2   |                     |
| Hose clamp                            | Bolt       | M6 P1.0     | 1    | 12                | 1.2  | 8.6   |                     |
| Hose clamp and engine                 | Nut        | M6 P1.0     | 2    | 10                | 1.0  | 7.2   |                     |



| Part to be tightened                  | Part name | Thread size | Q'ty | Tightening torque |      |       | Remarks      |
|---------------------------------------|-----------|-------------|------|-------------------|------|-------|--------------|
|                                       |           |             |      | Nm                | m·kg | ft·lb |              |
| Crankcase                             | Stud bolt | M8 P1.25    | 12   | 13                | 1.3  | 9.4   | Apply oil    |
| Crankcase (upper and lower)           | Bolt      | M8 P1.25    | 11   | 24                | 2.4  | 17    | Apply oil    |
| Crankcase (upper and lower)           | Bolt      | M6 P1.0     | 23   | 12                | 1.2  | 8.7   | Apply oil    |
| Generator cover and crankcase         | Bolt      | M6 P1.0     | 3    | 10                | 1.0  | 7.2   |              |
| Bearing cover plate (crankcase right) | Screw     | M6 P1.0     | 4    | 8                 | 0.8  | 5.7   |              |
| Bearing cover plate (crankcase left)  | Screw     | M6 P1.0     | 4    | 8                 | 0.8  | 5.7   | Use LOCTITE® |
| Clutch cable holder                   | Screw     | M6 P1.0     | 1    | 10                | 1.0  | 7.2   |              |
| Crankcase cover                       | Bolt      | M6 P1.0     | 13   | 10                | 1.0  | 7.2   |              |
| Crankcase (Main gallery blind plug)   | Plug      | M20 P1.5    | 2    | 12                | 1.2  | 8.7   | Apply oil    |
| Clutch pressure plate                 | Bolt      | M6 P1.0     | 5    | 8                 | 0.8  | 5.8   |              |
| Clutch boss                           | Nut       | M20 P1.0    | 1    | 70                | 7.0  | 50    |              |
| Drive sprocket                        | Bolt      | M6 P1.0     | 2    | 10                | 1.0  | 7.2   |              |
| Stopper plate                         | Screw     | M5 P0.8     | 1    | 7                 | 0.7  | 5.1   | Use LOCTITE® |
| Cam segment                           | Bolt      | M6 P1.0     | 1    | 10                | 1.0  | 7.2   | Use LOCTITE® |
| Change pedal                          | Bolt      | M6 P1.0     | 1    | 10                | 1.0  | 7.2   |              |
| A.C. Generator                        | Bolt      | M10 P1.25   | 1    | 35                | 3.5  | 25    |              |
| A.C. Generator (brush)                | Screw     | M6 P1.0     | 2    | 8                 | 0.8  | 5.8   |              |
| Pick up coil base                     | Screw     | M6 P1.0     | 2    | 8                 | 0.8  | 5.8   |              |
| Timing plate                          | Screw     | M8 P1.25    | 1    | 24                | 2.4  | 17    |              |
| Starter motor                         | Bolt      | M6 P1.0     | 2    | 10                | 1.0  | 7.2   |              |
| Neutral switch                        | Screw     | M5 P0.8     | 3    | 3.5               | 0.35 | 2.5   | Use LOCTITE® |
| Oil level gauge switch                | Bolt      | M6 P1.0     | 2    | 7                 | 0.7  | 5.1   |              |
| Relief valve and crankcase            | —         |             | 1    | 20                | 2.0  | 14    |              |
| Hivo chain tensioner                  | Bolt      | M6 P1.0     | 2    | 10                | 1.0  | 7.2   | Use LOCTITE® |
| Primary drive gear                    | Nut       | M16 P       | 1    | 50                | 5.0  | 36    |              |
| Bearing cover plate                   | Screw     | M6 P1.0     | 2    | 10                | 1.0  | 7.2   | Use LOCTITE® |
| Starter clutch                        | Bolt      | M8 P1.25    | 3    | 25                | 2.5  | 18    | Use LOCTITE® |
| Shift shaft stopper                   | Screw     | M8 P1.25    | 1    | 22                | 2.2  | 16    |              |
| Shift cam bearing plate               | Screw     | M6 P1.0     | 1    | 10                | 1.0  | 7.2   |              |


# MAINTENANCE SPECIFICATIONS

APPX




## Chassis

| Item                         |  | Model           | XJ600RL   |   |   |   |   |
|------------------------------|--|-----------------|---|---|---|---|---|
| Steering System:             |  |                 | Ball Bearing  |   |   |   |   |
| Steering Bearing Type        |  |                 | 19 pcs/1/4 in   |   |   |   |   |
| No./Size of Steel Balls:     |  | Upper           | 19 pcs/1/4 in   |   |   |   |   |
|                              |  | Lower           |   |   |   |   |   |
| Front Suspension:            |  |                 | 150 mm (5.9 in)                                       |   |   |   |   |
| Front Fork Travel            |  |                 | 515.5 mm (20.29 in)                                   |   |   |   |   |
| Frok Spring Free Length      |  |                 | K <sub>1</sub> = 40 N/mm (0.4 kg/mm, 22.4 lb/in)      |   |   |   |   |
| Spring Rate/Stroke           |  |                 | 0 ~ 80 mm (0 ~ 3.14 in)                               |   |   |   |   |
|                              |  |                 | K <sub>2</sub> = 57.5 N/mm (0.575 kg/mm, 32.2 lb/in)/ |   |   |   |   |
|                              |  |                 | 80 ~ 150 mm (3.14 ~ 5.91 in)                          |   |   |   |   |
| Optional Spring              |  |                 | No  |   |   |   |   |
| Oil Capacity                 |  |                 | 269 cm <sup>3</sup> (9.47 Imp oz, 9.03 US oz)         |   |   |   |   |
| Oil Grade                    |  |                 | SAE 10W30 type SE motor oil                           |   |   |   |   |
| Rear Suspension:             |  |                 | 40 mm (1.5 in)  |   |   |   |   |
| Shock Absorber Travel        |  |                 | 184 mm (7.24 in)                                      |   |   |   |   |
| Spring Free Length           |  |                 | K <sub>1</sub> = 110 N/mm (11 kg/mm, 616 lb/in)       |   |   |   |   |
| Spring Rate/Stroke           |  |                 | 0 ~ 40 mm (0 ~ 1.57 in)                               |   |   |   |   |
| Optional Spring              |  |                 | No  |   |   |   |   |
| Adjustment                   |  | Spring Position | ← Stiffer   |   |   |   |   |
|                              |  |                 | Std.  |   |   |   |   |
|                              |  |                 | Softer  |   |   |   |   |
|                              |  |                 | 5   | 4 | 3 | 2 | 1 |
| Rear Arm:                    |  |                 | 1.0 mm (0.039 in)                                     |   |   |   |   |
| Swingarm Free Play Limit:    |  | End             | 1.0 mm (0.039 in)                                     |   |   |   |   |
|                              |  | Side            |   |   |   |   |   |
| Wheel:                       |  |                 | Cast Wheel  |   |   |   |   |
| Front Wheel Type             |  |                 | Cast Wheel  |   |   |   |   |
| Rear Wheel Type              |  |                 | MT2.15 x 18/Aluminum                                  |   |   |   |   |
| Front Rim Size/Material      |  |                 | MT2.50 x 18/Aluminum                                  |   |   |   |   |
| Rear Rim Size/Material       |  |                 | 2.0 mm (0.08 in)                                      |   |   |   |   |
| Rim Runout Limit             |  | Vertical        | 2.0 mm (0.08 in)                                      |   |   |   |   |
|                              |  | Lateral         |   |   |   |   |   |
| Drive Chain:                 |  |                 | 50HDL2/DAIDO  |   |   |   |   |
| Type/Manufacturer            |  |                 | 106   |   |   |   |   |
| No. of Links                 |  |                 | 20 ~ 30 mm (0.78 ~ 1.18 in)                           |   |   |   |   |
| Chain Free Play              |  |                 |   |   |   |   |   |
| Front Disc Brake:            |  |                 | Dual disc   |   |   |   |   |
| Type                         |  |                 | 267 x 5 mm (10.5 x 0.2 in)                            |   |   |   |   |
| Outside Dia. x Thickness     |  |                 | 5.5 mm (0.21 in)                                      |   |   |   |   |
| Pad Thickness:               |  |                 | 0.5 mm (0.019 in)                                     |   |   |   |   |
|                              |  | Inner           | 5.5 mm (0.21 in)                                      |   |   |   |   |
|                              |  | <Limit> *       | 0.5 mm (0.019 in)                                     |   |   |   |   |
|                              |  | Outer           | 0.5 mm (0.019 in)                                     |   |   |   |   |
|                              |  | <Limit> *       | 15.87 mm (0.62 in)                                    |   |   |   |   |
| Master Cylinder Inside Dia.  |  |                 | 42.8 mm (1.50 in)                                     |   |   |   |   |
| Caliper Cylinder Inside Dia. |  |                 | DOT #3  |   |   |   |   |
| Brake Fluid Type             |  |                 |   |   |   |   |   |



7

**Chassis**

| Item  | Model<br>XJ600RL   |
|---|--|
| <b>Rear Disc Brake:</b><br>Type<br>Disc Outside Dia. x Thickness<br>Pad Thickness<br><br>Master Cylinder Inside Dia.<br>Caliper Cylinder Inside Dia.<br>Brake Fluid Type | Dual disc<br>267 mm (10.6 in) x 5 mm (0.19 in)<br>5.5 mm (0.21 in)<br>0.5 mm (0.019 in)<br>5.5 mm (0.21 in)<br>0.5 mm (0.019 in)<br>14 mm (0.55 in)<br>38.1 mm (1.49 in)<br>DOT #3 |
| <b>Brake Lever &amp; Brake Pedal:</b><br>Brake Lever Free Play<br>Brake Pedal Free Play<br>Brake Pedal Position   | 5 ~ 8 mm (0.02 ~ 0.03 in)<br>20 ~ 30 mm (0.8 ~ 0.12 in)<br>30 mm (1.2 in)<br>(Vertical height below footrest top)  |
| <b>Clutch Lever Free Play:</b>  | 2 ~ 3 mm (0.08 ~ 0.12 in)  |



## Tightening torque

### CHASSIS:

| Part to be tightened                      | Part name    | Thread size | Q'ty      | Tightening torque |      |       | Remarks |
|---|--------------|-------------|-----------|-------------------|------|-------|---------|
|   |              |             |           | Nm                | m·kg | ft·lb |         |
| Engine Mounting Bolt                      | Front, upper | Nut         | M10 P1.25 | 1                 | 42   | 4.2   | 30      |
|   | Front, under | Bolt        | M10 P1.25 | 2                 | 42   | 4.2   | 30      |
|   | Rear         | Nut         | M12 P1.25 | 1                 | 90   | 9.0   | 65      |
| Engine Mounting Stay                      | Front        | Bolt        | M8 P1.25  | 4                 | 32   | 3.2   | 14      |
| Handle crown & Steering shaft             |              | Bolt        | M14 P1.25 | 1                 | 54   | 5.4   | 39      |
| Handle crown & Inner tube                 |              | Nut cap     | M8 P1.25  | 1                 | 20   | 2.0   | 14      |
| Handle crown & Handlebar                  |              | Bolt        | M12 P1.25 | 2                 | 70   | 7.0   | 51      |
| Under bracket & Inner tube                |              | Bolt        | M12 P1.25 | 2                 | 20   | 2.0   | 14      |
| Front wheel shaft                         |              |             | M14 P1.5  | 1                 | 105  | 10.5  | 75      |
| Front wheel Axle pinch bolt               |              |             | M8 P1.25  | 1                 | 20   | 2.0   | 14      |
| Pivot shaft                               | Nut          | M14 P1.5    | 1         | 90                | 9.0  | 85    |         |
| Rear Wheel shaft                          | Nut castle   | M14 P1.5    | 1         | 105               | 10.5 | 75    |         |
| Sprocket wheel                            | Nut          | M8 P1.25    | 6         | 32                | 3.2  | 23    |         |
| Rear shock absorber (Upper)               | Nut cap      | M10 P1.25   | 1         | 40                | 4.0  | 29    |         |
| Footrest                                  | Bolt         | M10 P1.25   | 2         | 64                | 6.4  | 46    |         |
| Brake disc & Hub                          | Bolt         | M8 P1.25    | 12        | 20                | 2.0  | 14    |         |
| Master cylinder & Brake hose (Front)      | Bolt union   | M10 P1.25   | 1         | 26                | 2.6  | 19    |         |
| Brake hose & Joint                        | Bolt Union   | M10 P1.25   | 1         | 26                | 2.6  | 19    |         |
| Caliper & Brake hose                      | Bolt union   | M10 P1.25   | 1         | 26                | 2.6  | 19    |         |
| Caliper bleed screw                       |              | M8 P1.25    | 1         | 6                 | 0.6  | 4.3   |         |
| Front fender                              | Bolt         | M8 P1.25    | 4         | 10                | 1.0  | 7.2   |         |
| Master cylinder cap                       | Screw        | M5 P0.8     | 2         | 1.8               | 0.18 | 1.3   |         |
| Muffler bracket & Frame                   | Bolt         | M8 P1.25    | 2         | 20                | 2.0  | 14    |         |
| Master cylinder & Master cylinder bracket | Bolt         | M6 P1.0     | 2         | 8.5               | 0.85 | 6.1   |         |
| Steering shaft & Ring nut                 | Nut          | M25 P1.0    | 1         | 54                | 5.4  | 39    |         |
| Sender & Fuel tank                        | Bolt         | M5 P0.8     | 4         | 4.3               | 0.43 | 2.4   |         |
| Relay Arm and Frame                       | Bolt         | M14 P1.25   | 1         | 65                | 6.5  | 47    |         |
| Relay Arm and Arm 1 & 2                   | Bolt         | M12 P1.25   | 1         | 65                | 6.5  | 47    |         |
| Arm 1 and 2                               | Bolt         | M12 P1.25   | 2         | 20                | 2.0  | 14    |         |
| Rear Arm and Arm 1 & 2                    | Bolt         | M10 P1.25   | 2         | 40                | 4.0  | 29    |         |
| Caliper                                   | Bolt         | M10 P1.25   | 2         | 35                | 3.5  | 25    |         |



## Electrical

| Item                           | Model | XJ600RL  |
|--------------------------------|-------|--|
| Voltage                        |       | 12V  |
| Ignition System:               |       |  |
| Ignition Timing (B.T.D.C.)     |       | $10^\circ \pm 1^\circ$ at 1,200 r/min  |
| Advanced Timing (B.T.D.C.)     |       | $36^\circ \pm 2^\circ$ at 8,500 r/min  |
| Advancer Type                  |       | Electrical   |
|                                |       |  |
| T.C.I.:                        |       |  |
| Pickup Coil Resistance (Color) |       | $120\Omega \pm 20\%$ at $20^\circ\text{C}$ ( $68^\circ\text{F}$ ) (Black - Gray)<br>(Black - Orange) |
| T.C.I. Unit-Manufacturer       |       | TID14-31/HITACHI   |
| Ignition Coil:                 |       |  |
| Model/Manufacturer             |       | CM12-23/HITACHI  |
| Minimum Spark Gap              |       | 6 mm (0.24 in) or more at 500 r/min  |
| Primary Winding Resistance     |       | $2.7\Omega \pm 10\%$ at $20^\circ\text{C}$ ( $68^\circ\text{F}$ )                                    |
| Secondary Winding Resistance   |       | $12\text{ k}\Omega \pm 20\%$ at $20^\circ\text{C}$ ( $68^\circ\text{F}$ )                            |
| Spark Plug Cap Resistance      |       | $10\text{ k}\Omega$  |
| Charging System:               |       |  |
| Type                           |       | A.C. Generator   |
| A.C. Generator:                |       |  |
| Model/Manufacturer             |       | LD117-03/HITACHI   |
| Nominal Output                 |       | 14V, 17A at 5,000 r/min  |
|                                |       |  |
| Field Coil Resistance          |       | $4.5\Omega \pm 10\%$ at $20^\circ\text{C}$ ( $68^\circ\text{F}$ ) (Br - G)                           |
| Starter Coil Resistance        |       | $0.55\Omega \pm 10\%$ at $20^\circ\text{C}$ ( $68^\circ\text{F}$ ) (W - W)                           |

# MAINTENANCE SPECIFICATIONS

# APPX



| Item  | Model | XJ600RL   |
|---|-------|---|
| Brush –Overall Length<br><Limit><br>–Spring Force   |       | 17 mm (0.669 in)<br>10 mm (0.394 in)<br>170 ~ 380 gr (5.996 ~ 13.403 oz)  |
| Voltage Regulator:<br>Type<br>Model/Manufacturer<br>No Load Regulated Voltage<br>Rectifier:<br>Model/Manufacturer<br>Capacity<br>Withstand Voltage  |       | Field control<br>SH233-12/SHINDENGEN<br>14.2 ~ 14.8V<br>SH233-12/SHINDENGEN<br>15A<br>300V  |
| Battery:<br>Capacity<br>Specific Gravity  |       | 12V 12AH<br>1.280   |
| Electroc Starter System:<br>Type<br>Starter Motor:<br>Model/Manufacturer<br>Output<br>Armature Coil Resistance<br>Brush –Overall Length<br>– <Limit><br>–Spring Force<br>Commutator Dia.<br>Wear Limit<br>Mic Undercut<br>Starter Relay:<br>Model/Manufacturer<br>Amperage Rating |       | Constant mesh type<br>SM8204/MITSUBA<br>0.5 kw<br>0.012 $\Omega$ $\pm$ 10% at 20°C (68°F)<br>12 mm (0.47 in)<br>5 mm (0.20 in)<br>340 ~ 460 g (12.0 ~ 16.2 oz)<br>28 mm (1.10 in)<br>27 mm (1.06 in)<br>0.8 mm (0.031 in)<br>22U-00/HITACHI<br>100A |
| Horn:<br>Type/Quantity<br>Model/Manufacturer<br>Maximum Amperage  |       | Plane type x 2<br>CF-12/NIKKO<br>2.5 A  |
| Flasher Relay (Relay Assembly):<br>Type<br>Model/Manufacturer<br>Self Cancelling Device<br>Flasher Frequency<br>Wattage   |       | Semi transistor type<br>FX257N/ND<br>Yes<br>85 $\pm$ 10 cycle/min<br>27W x 2 pcs + 3.4W   |
| Safety relay (Relay Assembly):<br>Model/Manufacturer<br>Diode   |       | FX257N/ND<br>No   |
| Oil Level Switch:<br>Model/Manufacturer   |       | 4U8-00/ND   |
| Fuel Gauge:<br>Model/Manufacturer<br>Sender Unit Resistance Full<br>Empty   |       | 33M/NIPPON SEIKI<br>7 $\Omega$ $\pm$ 5% at 20°C (68°F)<br>95 $\Omega$ $\pm$ 7.5% at 20°C (68°F)   |

# 7





| Item   | Model<br>XJ600RL  |
|--|---|
| <b>Circuit Breaker:</b><br>Type<br>Amperage for individual Circuit x Quantity:<br>MAIN<br>HEADLIGHT<br>SIGNAL<br>IGNITION<br>RESERVE | <b>Fuse</b><br>30A x 1<br>20A x 1<br>10A x 1<br>10A x 1<br>30A x 1, 20A x 1 |






### GENERAL TORQUE SPECIFICATIONS

This chart specifies torque for standard fasteners with standard I.S.O. pitch threads. Torque specifications for special components or assemblies are included in the applicable sections of this book. To avoid warpage, tighten multi-fastener assemblies in a crisscross fashion, in progressive stages, until full torque is reached. Unless otherwise specified, torque specifications call for clean, dry threads. Components should be at room temperature.

| A<br>(Nut) | B<br>(Bolt) | General torque specifications |      |       |
|------------|-------------|-------------------------------|------|-------|
|            |             | Nm                            | m·kg | ft·lb |
| 10 mm      | 6 mm        | 6                             | 0.6  | 4.3   |
| 12 mm      | 8 mm        | 15                            | 1.5  | 11    |
| 14 mm      | 10 mm       | 30                            | 3.0  | 22    |
| 17 mm      | 12 mm       | 55                            | 5.5  | 40    |
| 19 mm      | 14 mm       | 85                            | 8.5  | 6.1   |
| 22 mm      | 16 mm       | 130                           | 13.0 | 94    |



A: Distance across flats  
B: Outside threaded diameter



## DEFINITION OF UNITS

| Unit            | Read                  | Definition                           | Measure      |
|-----------------|-----------------------|--------------------------------------|--------------|
| mm              | millimeter            | $10^{-3}$ meter                      | Length       |
| cm              | centimeter            | $10^{-2}$ meter                      | Length       |
| kg              | kilogram              | $10^3$ gram                          | Weight       |
| N               | Newton                | $1 \text{ kg} \times \text{m/sec}^2$ | Force        |
| Nm              | Newton meter          | $\text{N} \times \text{m}$           | Torque       |
| m·kg            | Meter kilogram        | $\text{m} \times \text{kg}$          | Torque       |
| Pa              | Pascal                | $\text{N/m}^2$                       | Pressure     |
| N/mm            | Newton per millimeter | N/mm                                 | Spring rate  |
| L               | Liter                 |                                      | Volume       |
| cm <sup>3</sup> | Cubic centimeter      |                                      | or Capacity  |
| r/min           | Rotation per minute   |                                      | Engine Speed |

## CONVERSION TABLES

| Metric to inch system |                 |                 |
|-----------------------|-----------------|-----------------|
| Known                 | Multiplier      | Result          |
| m·kg                  | 7.233           | ft·lb           |
| m·kg                  | 86.80           | in·lb           |
| cm·kg                 | 0.0723          | ft·lb           |
| cm·kg                 | 0.8680          | in·lb           |
| kg                    | 2.205           | lb              |
| g                     | 0.03527         | oz              |
| km/lit                | 2.352           | mpg             |
| km/hr                 | 0.6214          | mph             |
| km                    | 0.6214          | mi              |
| m                     | 3.281           | ft              |
| m                     | 1.094           | yd              |
| cm                    | 0.3937          | in              |
| mm                    | 0.03937         | in              |
| cc (cm <sup>3</sup> ) | 0.03382         | oz (US liq)     |
| cc (cm <sup>3</sup> ) | 0.06102         | cu in           |
| lit (liter)           | 2.1134          | pt (US liq)     |
| lit (liter)           | 1.057           | qt (US liq)     |
| lit (liter)           | 0.2642          | gal (US liq)    |
| kg/mm                 | 56.007          | lb/in           |
| kg/cm                 | 14.2234         | psi (lb/in)     |
| centigrade (°C)       | $9/5 (°C) + 32$ | Fahrenheit (°F) |


| Inch to metric system |                 |                       |
|-----------------------|-----------------|-----------------------|
| Known                 | Multiplier      | Result                |
| ft·lb                 | 0.13826         | m·kg                  |
| in·lb                 | 0.01152         | m·kg                  |
| ft·lb                 | 13.831          | cm·kg                 |
| in·lb                 | 1.1521          | cm·kg                 |
| lb                    | 0.4535          | kg                    |
| oz                    | 28.352          | g                     |
| mpg                   | 0.4252          | km/lit                |
| mph                   | 1.609           | km/hr                 |
| mi                    | 1.609           | km                    |
| ft                    | 0.3048          | m                     |
| yd                    | 0.9141          | m                     |
| in                    | 2.54            | cm                    |
| in                    | 25.4            | mm                    |
| oz (US liq)           | 29.57           | cc (cm <sup>3</sup> ) |
| cu in                 | 16.387          | cc (cm <sup>3</sup> ) |
| pt (US liq)           | 0.4732          | lit (liter)           |
| qt (US liq)           | 0.9461          | lit (liter)           |
| gal (US liq)          | 3.785           | lit (liter)           |
| lb/in                 | 0.017855        | kg/mm                 |
| psi (lb/in)           | 0.07031         | kg/cm                 |
| Fahrenheit (°C)       | $5/9 (°F - 32)$ | Centigrade (°F)       |



## EXPLODED DIAGRAMS


## CYLINDER HEAD

- |                  |                |
|------------------|----------------|
| 1. Washer        | 5. Valve guide |
| 2. Rubber washer | 6. Circlip     |
| 3. Gasket        | 7. Stud bolt   |
| 4. Spark plug    |                |




**VALVE/CAM CHAIN**

- |                          |                              |                         |
|--------------------------|------------------------------|-------------------------|
| 1. Cam chain             | 9. Guide stopper plate       | 17. Inner spring        |
| 2. Cam sprocket          | 10. Upper chain guide        | 18. Outer spring        |
| 3. Camshaft (Exhaust)    | 11. Exhaust side chain guide | 19. Spring seat         |
| 4. Camshaft (Intake)     | 12. Intake side chain guide  | 20. Oil seal            |
| 5. Chain tensioner body  | 13. Adjusting pad            | 21. Valve               |
| 6. Tensioner lock bolt   | 14. Valve lifter             | 22. Chain guide stopper |
| 7. Tensioner rod (Large) | 15. Valve retainer           | 23. Match mark          |
| 8. Tensioner rod (Small) | 16. Spring seat              |                         |



| A VALVE CLEARANCE (COLD): |         |                                      |
|---------------------------|---------|--------------------------------------|
| B                         | Intake  | 0.11 ~ 0.15 mm<br>(0.004 ~ 0.006 in) |
| C                         | Exhaust | 0.16 ~ 0.20 mm<br>(0.006 ~ 0.008 in) |





## CRANKSHAFT/PISTON

1. Top ring
2. Second ring
3. Oil ring
4. Circlip
5. Piston pin
6. Oil seal
7. Top ring
8. Oil ring (Lower rail)
9. Second ring
10. Oil ring (Upper rail)

**B** RING END GAP:  
0.15 ~ 0.30 mm  
(0.0059 ~ 0.0118 in)

**C** PISTON CLEARANCE:  
0.025 ~ 0.045 mm  
(0.0010 ~ 0.0018 in)

**D** USE A NEW ONE

**A** OIL CLEARANCE:  
0.016 ~ 0.040 mm  
(0.0006 ~ 0.0016 in)

25 Nm (2.5 m·kg, 18.5 ft·lb)

**F** OIL CLEARANCE:  
0.021 ~ 0.044 mm  
(0.0008 ~ 0.0017 in)

|          |  |
|----------|--|
| <b>G</b> | ENGINE OIL CAPACITY:                                     |
| <b>H</b> | Periodic oil change:<br>2.3 L (2.0 Imp qt, 2.4 US qt)    |
| <b>I</b> | Oil filter replacement:<br>2.6 L (2.3 Imp qt, 2.7 US qt) |
| <b>J</b> | Total amount:<br>3.0 L (2.6 Imp qt, 3.2 US qt)           |


## E PISTON RING INSTALLATION






## CLUTCH

- |                        |                       |
|------------------------|-----------------------|
| 1. Plate washer        | 8. Clutch plate       |
| 2. Oil seal            | 9. Clutch boss spring |
| 3. Circlip             | 10. Spring seat       |
| 4. Lock washer         | 11. Thrust plate      |
| 5. Clutch plate (#1)   | 12. Bearing           |
| 6. Friction plate (#1) | 13. Pull rod          |
| 7. Wire clip           | 14. Match mark        |



D CLUTCH PLATE POSITION



70 Nm (7.0 m·kg, 50 ft·lb)

8 Nm (0.8 m·kg, 5.8 ft·lb)

A SPRING FREE LENGTH  
LIMIT:  
41.8 mm (1.646 in)


B CLUTCH PLATE  
WARP LIMIT:  
0.05 mm (0.002 in)

C FRICTION PLATE  
WEAR LIMIT:  
2.8 mm (0.11 in)



## TRANSMISSION


- |                        |                    |                         |
|------------------------|--------------------|-------------------------|
| 1. Circlip             | 8. 3rd wheel gear  | 15. Drive sprocket      |
| 2. Cylindrical bearing | 9. 6th wheel gear  | 16. Drive axle          |
| 3. Plate washer        | 10. 2nd wheel gear | 17. Main axle           |
| 4. 1st wheel gear      | 11. Bearing        | 18. 5th pinion gear     |
| 5. 5th gear            | 12. O-ring         | 19. 3rd/4th pinion gear |
| 6. Washer              | 13. Oil seal       | 20. 6th pinion gear     |
| 7. 4th wheel gear      | 14. Collar         | 21. 2nd pinion gear     |





**OIL COOLER**

1. Grommet
2. Oil cooler assembly
3. O-ring
4. Spacer
5. Plunger
6. Spring
7. Washer
8. Circlip








## CARBURETOR

- |                     |                         |
|---------------------|-------------------------|
| 1. Jet needle cover | 9. Main jet washer      |
| 2. Set spring       | 10. Main jet            |
| 3. Jet needle       | 11. Float               |
| 4. Piston valve     | 12. Float plin          |
| 5. Starter plunger  | 13. Drain screw         |
| 6. Main nozzle      | 14. Float valve         |
| 7. Starter lever    | 15. Synchronizing screw |
| 8. Pilot jet        | 16. O-ring              |
|                     | 17. Pilot air jet       |
|                     | 18. Throttle stop screw |

## SPECIFICATIONS


|                            |                                 |
|----------------------------|---------------------------------|
| Main jet                   |                                 |
| For No.1 and No.2 cylinder | #105                            |
| For No.3 and No.4 cylinder | #102.5                          |
| Jet needle                 |                                 |
| No.1, 3 and 4 cylinder     | 4CP3-3                          |
| No.2 cylinder              | 4CP7-3                          |
| Needle jet                 | N-8                             |
| Starter jet                | #42.5                           |
| Fuel level                 | 3.0 ± 1.0 mm<br>(0.12 ± 0.4 in) |
| Pilot screw                | 2-1/2 turns out                 |
| Float valve seat           | φ2.0                            |
| Engine idle speed          | 1200 ± 50r/min                  |





### FRONT FORK

- |                      |                              |
|----------------------|------------------------------|
| 1. Rubber cap        | 10. Retaining clip           |
| 2. Cap bolt          | 11. Oil seal                 |
| 3. O-ring            | 12. Washer                   |
| 4. Fork spring       | 13. Bushing                  |
| 5. Damper rod spring | 14. Outer fork tube          |
| 6. Damper rod        | 15. Drain bolt               |
| 7. Inner fork tube   | 16. Damper rod securing bolt |
| 8. Taper spindle     | 17. Front fork brace         |
| 9. Dust cover        |                              |






### FRONT WHEEL

1. Front axle
2. Collar
3. Oil seal
4. Bearing
5. Spacer
6. Spacer flange
7. Bearing
8. Meter clutch
9. Clutch retainer
10. Oil seal
11. Gear unit assembly

#### TIRE AIR PRESSURE (COLD):

|  |   |   |
|--|---|---|
| Basic weight:<br>With oil and full fuel tank | 208 kg (459 lb)                                 |   |
| Maximum load*                                | 188 kg (414 lb)                                 |   |
| Cold tire pressure                           | Front   | Rear  |
| Up to 90 kg (198 lb) load*                   | 177 kPa<br>(1.8 kg/cm <sup>2</sup> ,<br>26 psi) | 196 kPa<br>(2.0 kg/cm <sup>2</sup> ,<br>28 psi) |
| 90 kg (198 lb)~<br>Maximum load*             | 196 kPa<br>(2.0 kg/cm <sup>2</sup> ,<br>28 psi) | 226 kPa<br>(2.3 kg/cm <sup>2</sup> ,<br>32 psi) |
| High speed riding                            | 196 kPa<br>(2.0 kg/cm <sup>2</sup> ,<br>28 psi) | 226 kPa<br>(2.3 kg/cm <sup>2</sup> ,<br>32 psi) |


\* Load is the total weight of cargo, rider, passenger, and accessories.




SD 22-42

6302 Z

|             |                  |
|-------------|------------------|
| TIRE SIZE:  |                  |
| A           | 90/90-18 51H     |
| WEAR LIMIT: |                  |
| B           | 0.8 mm (0.03 in) |



1.5 Nm (0.15 m·kg, 1.1 ft·lb)



6302 Z


SD 45-56

|                   |                             |
|-------------------|-----------------------------|
| RIM SIZE:         |                             |
| C                 | MT2.15 x 18                 |
| RIM RUNOUT LIMIT: |                             |
| E                 | Radial<br>2.0 mm (0.08 in)  |
| F                 | Lateral<br>2.0 mm (0.08 in) |



### REAR WHEEL

- |                  |               |
|------------------|---------------|
| 1. Rear axle     | 7. Bearing    |
| 2. Chain puller  | 8. Clutch hub |
| 3. Oil seal      | 9. Collar     |
| 4. Bearing       | 10. Bearing   |
| 5. Spacer flange | 11. Oil seal  |
| 6. Spacer        | 12. Collar    |






### FRONT BRAKE

1. Circlip
2. Bleed screw
3. Caliper piston assembly
4. Pad spring
5. Front brake pad
6. Brake disc
7. Master cylinder kit
8. Brake joint
9. Copper washer
10. Union bolt

\* Install the pad spring with its longer tangs in the disc rotation direction.






## REAR BRAKE

1. Rear brake pad
2. Pad spring
3. Circlip
4. Bleed screw
5. Caliper piston assembly
6. Brake disc
7. Master cylinder kit
8. Copper washer
9. Union bolt

\* Install the pad spring with its longer tangs in the disc rotation direction.




## SWINGARM/REAR SHOCK ABSORBER

1. Spring preload match mark
2. Pivot shaft
3. Thrust cover
4. Plate washer
5. Bearing
6. Bushing
7. Oil seal
8. Collar
9. Arm 1
10. Arm 2
11. Relay arm
12. Dust cover
13. Pulley bracket
14. Pulley

### SPRING PRELOAD ADJUSTMENT:

|                    | H |   |   | STD | S |
|--------------------|---|---|---|-----|---|
| Adjusting position | 5 | 4 | 3 | 2   | 1 |








## ELECTRICAL COMPONENTS 1

1. Fuse
2. Diode
3. Rectifier/Regulator
4. Starter relay
5. Battery
6. Igniter unit
7. Ignition coil assembly








## ELECTRICAL COMPONENTS 2


1. Main switch
2. Fuel sender
3. Rear brake switch
4. Neutral switch
5. Oil level switch
6. Relay assembly
7. Horn


| SPECIFICATIONS:    | RESISTANCE:            |
|--------------------|------------------------|
| Fuel gauge: (Full) | $7\ \Omega \pm 5\%$    |
| (Empty)            | $95\ \Omega \pm 7.5\%$ |
| Starter switch:    | $9.5\ \Omega \pm 10\%$ |





## LUBRICATION DIAGRAM









## CABLE ROUTING (1)


- |                                  |  |
|----------------------------------|--|
| 1. Throttle cable                | 10. A.C.G. lead:                         |
| 2. Handlebar switch lead (Right) | Pass through the A.C.G. lead between the |
| 3. Handlebar switch lead (Left)  | battery box and the air cleaner case.    |
| 4. Starter cable                 | 11. Ignition coil (Right)                |
| 5. Clutch cable                  | 12. Band                                 |
| 6. Front brake hose              | 13. Stop switch                          |
| 7. Front brake stop switch lead  | 14. Starter switch                       |
| 8. Ignitor unit                  |  |
| 9. Earth lead                    |  |





## CABLE ROUTING (2)


- |                                     |                                   |
|-------------------------------------|-----------------------------------|
| 1. Clamp                            | 10. Handlebar switch lead (Right) |
| 2. Front flasher light lead (Left)  | 11. Main switch lead              |
| 3. Front flasher light lead (Right) | 12. Meter lead                    |
| 4. Front brake stop switch lead     |                                   |
| 5. To headlight lens unit           |                                   |
| 6. Handlebar switch lead (Left)     |                                   |
| 7. Wireharness                      |                                   |
| 8. Speedometer cable                |                                   |
| 9. Front brake hose                 |                                   |





## CABLE ROUTING (3)

- |  |   |
|--|---|
| 1. Throttle cable                            | 9. Ignition coil (Left)                                 |
| 2. Ignition coil (Right)                     | 10. Starter cable                                       |
| 3. Flasher light relay                       | 11. Wireharness   |
| 4. Rear flasher light lead (Right)           | 12. Front flasher light lead (Left)                     |
| 5. Rear flasher light lead (Left)            | 13. Rectifier with regulator                            |
| 6. Taillight lead                            | 14. Pass the speedometer cable through the cable guide. |
| 7. Clamp                                     | 15. Front brake hose                                    |
| 8. Clamp the wireharness only with the band. |   |



**CABLE ROUTING (4)**

1. Battery breather pipe
2. Battery
3. Pass the battery breather pipe through the front hole on the relay arm.

